



nx frequency converters

asfiff12

high speed application

NXS

user's manual

INDEX

Document code: ud00735
Software code: ASFIFF12V251
Date: 14.12.2007

1.	General.....	3
2.	Application specific	4
2.1	High speed	4
2.2	Long ramp times.....	4
2.3	Fieldbus.....	4
3.	Control I/O.....	5
3.1	Control signal logic in High Speed Application.....	6
4.	High Speed Application – Parameter lists	7
4.1	Monitoring values (Control keypad: menu M1).....	7
4.2	Basic parameters (Control keypad: Menu M2 → G2.1)	9
4.3	Input signals (Control keypad: Menu M2 → G2.2)	10
4.4	Output signals (Control keypad: Menu M2 → G2.3)	11
4.5	Drive control parameters (Control keypad: Menu M2 → G2.4)	12
4.6	Prohibit frequency parameters (Control keypad: Menu M2 → G2.5)	13
4.7	Motor control parameters (Control keypad: Menu M2 → G2.6)	13
4.8	Protections (Control keypad: Menu M2 → G2.7)	16
4.9	Autorestart parameters (Control keypad: Menu M2 → G2.8).....	17
4.10	High Speed Special parameters (Control keypad: Menu M2 → G2.9).....	18
4.11	Field bus parameters (Control keypad: Menu M2 → G2.10).....	18
4.12	Keypad control (Control keypad: Menu M3).....	19
4.13	System menu (Control keypad: M6).....	20
4.14	Expander boards (Control keypad: Menu M7)	20
5.	Description of parameters.....	21
5.1	Keypad control parameters	56
6.	Appendices	57
6.1	Closed loop parameters (ID's 612 to 621).....	57
6.2	Advanced Open Loop parameters (ID's 622 to 625, 632, 635).....	57
6.3	Parameters of motor thermal protection (ID's 704 to 708):	58
6.4	Parameters of Stall protection (ID's 709 to 712):	58
6.5	Parameters of Underload protection (ID's 713 to 716):.....	59
6.6	Fieldbus control parameters (ID's 850 to 859)	59
7.	Fault codes	60

1. GENERAL

The High Speed Application, ASFIF12, is based on the Standard Application of the All-In-One package.

This application requires licence key if it mend to be used above 1900 Hz. When above 1900 Hz is going to be used contact factory and give description about need. Note that some situations need NXP drive to be used. NXP drive can reach higher frequency than NXS drive.

2. APPLICATION SPECIFIC

2.1 High speed

The maximum frequency for the application is 7200 Hz (default is 50 Hz). The frequency is displayed without decimal. However license code is needed to run above 1900 Hz.

The unit for the motor speed is either rpm or krpm depending on the selected Frequency Scale (P2.1.17). The maximum frequency (7200Hz) is corresponding to the maximum nominal speed of the motor of 432 000 rpm (1 pole pair).

2.1.1 7200Hz

By entering a licence code to parameter P2.9.14 is it possible to run over 1900 Hz.

This code is different for every drive and has to be ordered from Vacon. When ordering the drive with this feature, the code will be calculated before delivery. If the user wants to activate the feature afterwards, he has to inform Vacon about the **serial number of the power unit(s)** for the drive(s) where the feature is wanted.

2.1.2 Fine tuning

It is possible to tune the motor controller for smoother run, especially in high-speed mode, and for PMS motors

See parameter group 9.

And separate parameters: 2.1.17, 2.1.18, 2.4.14, 2.4.15, 2.4.16, 2.6.14,

2.1.3 Trial Time

It is possible to run the drive over 1900Hz, without license key, for 2 weeks. When these 2 weeks has expired will the drive trip and it is not longer possible to run the drive over 1900Hz. Time left can be see from monitoring variable V1.17 Trial Time Left. When in Trial Time mode, the drive will give warning message each time the start command is given.

2.2 Long ramp times

By setting parameter P.2.1.16, Long Ramps, to YES, is it possible to set the acceleration and deceleration -times between 1-30 000s (8h 20min) with one-second resolution.

If No is selected (default) is the max acceleration/deceleration time 0,1-3000s.

2.3 Fieldbus

In this application is it also possible to separately program the ProcessData Output 1-8 for the fieldbus. This is done by setting the ID number of the parameter or value that you want to monitor to Process Data Ouput 1-8.

See parameter group 10




3. CONTROL I/O

		NXOPTA1		
Terminal	Signal	Description		
1	+10V _{ref}	Reference output	Voltage for potentiometer, etc.	
2	AI1+	Analogue input, voltage range 0—10V DC	Voltage input frequency reference	
3	AI1-	I/O Ground	Ground for reference and controls	
4	AI2+	Analogue input, current range 0—20mA	Current input frequency reference	
5	AI2-			
6	+24V	Control voltage output	Voltage for switches, etc. max 0.1 A	
7	GND	I/O ground	Ground for reference and controls	
8	DIN1	Start forward (programmable)	Contact closed = start forward	
9	DIN2	Start reverse (programmable)	Contact closed = start reverse	
10	DIN3	External fault input (programmable)	Contact open = no fault Contact closed = fault	
11	CMA	Common for DIN 1—DIN 3	Connect to GND or +24V	
12	+24V	Control voltage output	Voltage for switches (see #6)	
13	GND	I/O ground	Ground for reference and controls	
14	DIN4	Multi-step speed select 1	DIN4 DIN5 Frequency ref.	
15	DIN5	Multi-step speed select 2	Open Open Ref.U _{in} Closed Open Multi-step ref.1 Open Closed Multi-step ref.2 Closed Closed Ref.I _{in}	
16	DIN6	Fault reset	Contact open = no action Contact closed = fault reset	
17	CMB	Common for DIN4—DIN6	Connect to GND or +24V	
18	AO1+	Output frequency	Programmable	
19	AO1-	Analogue output	Range 0—20 mA/R _L , max. 500Ω	
20	DO1	Digital output READY	Programmable Open collector, I _L ≤50mA, U _L ≤48 VDC	
		NXOPTA2		
21	RO1	Relay output 1 RUN	Programmable	
22	RO1			
23	RO1			
24	RO2	Relay output 2 FAULT	Programmable	
25	RO2			
26	RO2			

Table 3-1. Standard application default I/O configuration.

Note: See jumper selections below. More information in the product's User's Manual.

Jumper block X3: CMA and CMB grounding

-  CMB connected to GND
CMA connected to GND
-  CMB isolated from GND
CMA isolated from GND
-  CMB and CMA internally connected together, isolated from GND

 = Factory default

3.1 Control signal logic in High Speed Application






Figure 3-1. Control signal logic of the High Speed Application

4. HIGH SPEED APPLICATION – PARAMETER LISTS

On the next pages you will find the lists of parameters within the respective parameter groups. The parameter descriptions are given on pages 21 to 56. The descriptions are arranged according to the **ID number** of the parameter.

Column explanations:

Code	= Location indication on the keypad; Shows the operator the present parameter number
Parameter	= Name of parameter
Min	= Minimum value of parameter
Max	= Maximum value of parameter
Unit	= Unit of parameter value; Given if available
Default	= Value preset by factory
Cust	= Customer's own setting
ID	= ID number of the parameter
	= In parameter row: Use TTF method to program these parameters.
	= On parameter code: Parameter value can only be changed after the frequency converter has been stopped.

4.1 Monitoring values (Control keypad: menu M1)

The monitoring values are the actual values of parameters and signals as well as statuses and measurements. Monitoring values cannot be edited.

See the procut's User's Manual for more information.

Code	Parameter	Unit	ID	Description
V1.1	Output frequency	Hz	1	Output frequency to motor
V1.2	Frequency reference	Hz	25	Frequency reference to motor control
V1.3	Motor speed	Rpm / krpm	2	The unit for motor speed is depending on Frequency Scale (P2.1.17)
V1.4	Motor current	A	3	
V1.5	Motor torque	%	4	Calculated shaft torque
V1.6	Motor power	%	5	Motor shaft power
V1.7	Motor voltage	V	6	
V1.8	DC link voltage	V	7	
V1.9	Unit temperature	°C	8	Heatsink temperature
V1.10	Motor temperature	%	9	Calculated motor temperature
V1.11	Analogue input 1	V	13	AI1
V1.12	Analogue input 2	mA	14	AI2
V1.13	DIN1, DIN2, DIN3		15	Digital input statuses
V1.14	DIN4, DIN5, DIN6		16	Digital input statuses
V1.15	DO1, RO1, RO2		17	Digital and relay output statuses
V1.16	Analogue I _{out}	mA	26	AO1
V1.17	Trial time left	H	67	When zero application can not be used without licence key
V1.18	PT100 Temperature	°C	42	Highest temperature of used PT100 inputs
M1.19	Multi Monitoring items			Displays three selectable monitoring values

Table 4-1. Monitoring values

4.1.1 Monitoring values 2 (Control keypad: menu M1.23)

Code	Parameter	Unit	ID	Description
G1.20	Monitor 2			
V1.20.1	Current	A	1113	Unfiltered motor current
V1.20.2	Torque	%	1125	Unfiltered motor torque
V1.20.3	DC Voltage	V	44	Unfiltered DC link voltage
V1.20.4	Status Word		43	

Table 4-2. Monitoring values 2

4.1.2 Fieldbus monitoring values (Control keypad: menu M1.23)

Code	Parameter	Unit	ID	Description
G1.21	Fieldbus			
V1.20.1	Motor Current 1D	A	45	Motor current (drive independent) given with one decimal point
V1.24.5	Last Active Fault		37	

Table 4-3. Fieldbus monitoring values

4.1.3 Application Status Word

Application Status Word combines different drive statuses to one data word. See monitoring value V1.20.4 Status Word.

Application Status Word		
	FALSE	TRUE
b0	-	-
b1	Not in Ready state	Ready
b2	Not Running	Running
b3	No Fault	Fault
b4	-	-
b5	-	-
b6	Run Disabled	Run Enable
b7	No Warning	Warning
b8		
b9		
b10		
b11	No DC brake	DC Brake is active
b12	No Run Request	Run Request
b13	No Limit Controls Active	Limit control Active
b14	-	-
b15		

Table 4-4. Application Status Word Content.

4.2 Basic parameters (Control keypad: Menu M2 → G2.1)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.1.1	Min frequency		P2.1.2	Hz			101	
P2.1.2	Max frequency	P2.1.1		Hz			102	NOTE: If $f_{max} >$ than the motor synchronous speed, check suitability for motor and drive system
P2.1.3	Acceleration time 1	0,1	3000,0	s	3,0		103	See also P2.1.16
P2.1.4	Deceleration time 1	0,1	3000,0	s	3,0		104	See also P2.1.16
P2.1.5	Current limit	0,00	2 x I _H	A	I _L		107	Limit will lower frequency
P2.1.6	Nominal voltage of the motor	180	690	V	NX2: 230V NX5: 400V NX6: 690V		110	Check the rating plate of the motor. Note also used connegtion Delta/Star
P2.1.7	Nominal frequency of the motor			Hz			111	Check the rating plate of the motor
P2.1.8	Nominal speed of the motor			rpm / krpm			112	The default applies for a 4-pole motor and a nominal size frequency converter. The unit for motor speed is depending on Frequency Scale (P2.1.17)
P2.1.9	Nominal current of the motor	0,1x I _H	2 x I _H	A	I _H		113	Check the rating plate of the motor.
2.1.10	Motor cosφ	0,30	1,00		0,85		120	Check the rating plate of the motor
2.1.11	I/O reference	0	3		0		117	0=A11 1=A12 2=Keypad 3=Fieldbus 4=A13
2.1.12	Keypad control reference	0	3		2		121	0=A11 1=A12 2=Keypad 3=Fieldbus 4=A13
2.1.13	Fieldbus control reference	0	3		3		122	0=A11 1=A12 2=Keypad 3=Fieldbus 4=A13
2.1.14	Preset speed 1		P2.1.2	Hz			105	Speeds preset by operator
2.1.15	Preset speed 2		P2.1.2	Hz			106	
2.1.16	Long ramp times	0	1		0		1500	0 = 0,1 s – 3000,0 s 1 = 0 s – 30000 s
2.1.17	Frequency Scale	0	5		1		523	0 = 0-32,000 Hz 1 = 0-320,00 Hz 2 = 0-1900,0 Hz 3 = 0-3200,0 Hz 4 = 0-5200 Hz 5 = 0-7200 Hz
2.1.18	Motor Type	0	1		0		650	0 = Induction Motor 1 = PMS motor

Table 4-5. Basic parameters G2.1

4.3 Input signals (Control keypad: Menu M2 → G2.2)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note	
P2.2.1	Start/Stop logic	0	6		0		300	0 Start fwd 1 Start/Stop 2 Start/Stop 3 Start pulse 4 Start 5 Start fwd* 6 Start*/Stop	Start signal 1 Start signal 2 Reverse Run enable Stop pulse Mot.Pot UP Start rvs* Reverse
P2.2.2	DIN3 function	0	8		1		301	0=Not used 1=Ext. fault, closing cont. 2=Ext. fault, opening cont. 3=Run enable 4=Acc./Dec. time select. 5=Force cp. to IO 6=Force cp. to keypad 7=Force cp. to fieldbus 8=Rvs (if P2.2.1=3)	
P2.2.3	Current reference offset	0	1		1		302	0=0—20mA 1=4—20mA	
P2.2.4	Reference scaling minimum value		P2.2.5	Hz			303	Selects the frequency that corresponds to the min. reference signal 0,00 = No scaling	
P2.2.5	Reference scaling maximum value			Hz			304	Selects the frequency that corresponds to the max. reference signal 0,00 = No scaling	
P2.2.6	Reference inversion	0	1		0		305	0 = Not inverted 1 = Inverted	
P2.2.7	Reference filter time	0,00	10,00	s	0,10		306	0 = No filtering	
P2.2.8	AI1 signal selection	0.1	E.10		A.1		377	TTF programming method used.	
P2.2.9	AI2 signal selection	0.1	E.10		A.2		388	TTF programming method used.	
P2.2.10	AI3 signal selection	0.1	E.10		0.1		389	TTF programming method used.	

Table 4-6. Input signals, G2.2

* = Rising edge required to start

4.4 Output signals (Control keypad: Menu M2 → G2.3)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.3.1	Analogue output 1 signal selection	0			A.1		464	TTF programming method used.
P2.3.2	Analogue output function	0	8		1		307	0=Not used 1=Output freq. (0— f_{max}) 2=Freq. reference (0— f_{max}) 3=Motor speed (0—Motor nominal speed) 4=Motor current (0— I_{nMotor}) 5=Motor torque (0— T_{nMotor}) 6=Motor power (0— P_{nMotor}) 7=Motor voltage (0— U_{nMotor}) 8=DC-link volt (0—1000V)
P2.3.3	Analogue output filter time	0,00	10,00	s	1,00		308	0=No filtering
P2.3.4	Analogue output inversion	0	1		0		309	0 = Not inverted 1 = Inverted
P2.3.5	Analogue output minimum	0	1		0		310	0 = 0 mA 1 = 4 mA
P2.3.6	Analogue output scale	10	1000	%	100		311	
P2.3.7	Digital output 1 function	0	16		1		312	0=Not used 1=Ready 2=Run 3=Fault 4=Fault inverted 5=FC overheat warning 6=Ext. fault or warning 7=Ref. fault or warning 8=Warning 9=Reversed 10=Preset speed 1 11=At speed 12=Mot. regulator active 13=OP freq. limit 1 superv. 14=Control place: IO 15=Thermistor fault/warnng 16=Fieldbus input data
P2.3.8	Relay output 1 function	0	16		2		313	As parameter 2.3.7
P2.3.9	Relay output 2 function	0	16		3		314	As parameter 2.3.7
P2.3.10	Output frequency limit 1 supervision	0	2		0		315	0=No limit 1=Low limit supervision 2=High limit supervision
P2.3.11	Output freq. limit 1; Supervised value			Hz			316	
P2.3.12	Analogue output 2 signal selection	0.1	E.10		0.1		471	TTF programming method used.
P2.3.13	Analogue output 2 function	0	8		4		472	As parameter 2.3.2
P2.3.14	Analogue output 2 filter time	0,00	10,00	s	1,00		473	0=No filtering
P2.3.15	Analogue output 2 inversion	0	1		0		474	0=Not inverted 1=Inverted
P2.3.16	Analogue output 2 minimum	0	1		0		475	0=0 mA 1=4 mA
P2.3.17	Analogue output 2 scaling	10	1000	%	100		476	
P2.3.18	Analogue output 3 signal selection	0.1	E.10		0.1		478	TTF programming method used.
P2.3.19	Analogue output 3 function	0	8		4		479	As parameter 2.3.2

P2.3.20	Analogue output 3 filter time	0,00	10,00	s	1,00		480	0=No filtering
P2.3.21	Analogue output 3 inversion	0	1		0		481	0=Not inverted 1=Inverted
P2.3.22	Analogue output 3 minimum	0	1		0		482	0=0 mA 1=4 mA
P2.3.23	Analogue output 3 scaling	10	1000	%	100		483	
P2.3.24	Analogue output 4 signal selection	0.1	E.10		0.1		484	TTF programming method used.
P2.3.25	Analogue output 4 function	0	8		4		485	As parameter 2.3.2
P2.3.26	Analogue output 4 filter time	0,00	10,00	s	1,00		486	0=No filtering
P2.3.27	Analogue output 4 inversion	0	1		0		487	0=Not inverted 1=Inverted
P2.3.28	Analogue output 4 minimum	0	1		0		488	0=0 mA 1=4 mA
P2.3.29	Analogue output 4 scaling	10	1000	%	100		489	

Table 4-7. Output signals, G2.3

4.5 Drive control parameters (Control keypad: Menu M2 → G2.4)

Code	Parameter	Min	Max	Unit	Default	Cus t	ID	Note
P2.4.1	Ramp 1 shape	0,0	10,0	s	0,0		500	0 = Linear >0 = S-curve ramp time
P2.4.2	Ramp 2 shape	0,0	10,0	s	0,0		501	0 = Linear >0 = S-curve ramp time
P2.4.3	Acceleration time 2	0,1	3000,0	s	10,0		502	
P2.4.4	Deceleration time 2	0,1	3000,0	s	10,0		503	
P2.4.5	Brake chopper	0	4		0		504	0=Disabled 1=Used when running 2=External brake chopper 3=Used when stopped/running 4=Used when running (no testing)
P2.4.6	Start function	0	1		0		505	0=Ramp 1=Flying start
P2.4.7	Stop function	0	3		0		506	0=Coasting 1=Ramp 2=Ramp+Run enable coast 3=Coast+Run enable ramp
P2.4.8	DC braking current	0,4 x I _H	2 x I _H	A	I _H		507	
P2.4.9	DC braking time at stop	0,00	600,00	s	0,00		508	0=DC brake is off at stop
P2.4.10	Frequency to start DC braking during ramp stop	0,10	10,00	Hz	1,50		515	
P2.4.11	DC braking time at start	0,00	600,00	s	0,00		516	0=DC brake is off at start
P2.4.12	Flux brake	0	1		0		520	0=Off 1=On
P2.4.13	Flux braking current	0,4 x I _H	2 x I _H	A	I _H		519	
P2.4.14	Advanced Options 1	0	65536		1		1511	Bitwise settings
P2.4.15	Advanced Options 2	0	65536		1		1516	Bitwise settings
P2.4.16	Advanced Options 4	0	65536		1		1517	Bitwise settings

Table 4-8. Drive control parameters, G2.4

4.6 Prohibit frequency parameters (Control keypad: Menu M2 → G2.5)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.5.1	Prohibit frequency range 1 low limit		P2.5.2	Hz			509	
P2.5.2	Prohibit frequency range 1 high limit			Hz			510	
P2.5.3	Prohibit acc./dec. ramp	0,1	10,0		1,0		518	

Table 4-9. Prohibit frequency parameters, G2.5

4.7 Motor control parameters (Control keypad: Menu M2 → G2.6)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.6.1	Motor control mode	0	1/4		0		600	NXS: 0 =Frequency control 1 =Speed control Additionally for NXP: 2 =Not used 3 =Closed loop speed ctrl 4 =Closed loop torque ctrl
P2.6.2	U/f optimisation	0	1		0		109	0 =Not used 1 =Automatic torque boost
P2.6.3	U/f ratio selection	0	3		0		108	0 =Linear 1 =Squared 2 =Programmable 3 =Linear with flux optim.
P2.6.4	Field weakening point			Hz			602	
P2.6.5	Voltage at field weakening point	10,00	200,00	%	100,00		603	$n\% \times U_{nmot}$
P2.6.6	U/f curve midpoint frequency		P2.6.4	Hz			604	
P2.6.7	U/f curve midpoint voltage	0,00	100,00	%	100,00		605	$n\% \times U_{nmot}$ Parameter max. value = P 2.6.5
P2.6.8	Output voltage at zero frequency	0,00	40,00	%	Varies		606	$n\% \times U_{nmot}$
P2.6.9	Switching frequency	1,0	Varies	kHz	Varies		601	See Table 5-6 for exact values
P2.6.10	Overvoltage controller	0	2		1		607	0 =Not used 1 =Used (no ramping) 2 =Used (ramping)
P2.6.11	Undervoltage controller	0	1		1		608	0 =Not used 1 =Used
P2.6.12	Load drooping	0,00	100,00	%	0,00		620	
P2.6.13	Identification	0	2		0		631	0 =No action 1 =Identification w/o run 2 =Identification with run
P2.6.14	Modulator Type	0	1		0		1518	0 = Default PWM 1 = Space Vector PWM.

Table 4-10. Motor control parameters, G2.6

Closed Loop parameters (Control keypad: Menu M2 → G2.6.13)

Closed Loop parameter group 2.6.13 (NXP only)							
P2.6.15.1	Magnetizing current	0,00	100,00	A	0,00		612
P2.6.15.2	Speed control P gain	0	1000		30		613
P2.6.15.3	Speed control I time	0,0	500,0	ms	30,0		614
P2.6.15.5	Acceleration compensation	0,00	300,00	s	0,00		626
P2.6.15.6	Slip adjust	0	500	%	100		619
P2.6.15.7	Magnetizing current at start	MotCurr Min	MotCurr Max	A	0,00		627
P2.6.15.8	Magnetizing time at start	0,0	600,0	s	0,0		628
P2.6.15.9	0-speed time at start	0	32000	ms	100		615
P2.6.15.10	0-speed time at stop	0	32000	ms	100		616
P2.6.15.11	Start-up torque	0	3		0		621
P2.6.15.12	Start-up torque FWD	-300,0	300,0	s	0,0		633
P2.6.15.13	Start-up torque REV	-300,0	300,0	s	0,0		634
P2.6.15.15	Encoder filter time	0	1000	ms	0		618
P2.6.15.17	Current control P gain	0,00	100,00	%	40,00		617
P2.6.15.18	Current control I gain	0,00	100,00	%	40,00		657

Table 4-11. Closed Loop parameters, G2.6.13

4.7.1 Advanced Open Loop parameters (Control keypad: Menu M2 → G2.6.1)

Advanced Open Loop parameter group 2.6.14 (NXP only)							
P2.6.16.1	Zero speed current	0,0	250,0	%	120,0		625
P2.6.16.2	Minimum current	0,0	100,0	%	80,0		622
P2.6.16.3	Flux reference	0,0	100,0	%	80,0		623
P2.6.16.4	Frequency limit	0,0	100,0	%	20,0		635
P2.6.16.5	U/f boost	0	1		0		632

Table 4-12. Advanced Open Loop parameters, G2.6.14.

4.7.2 Identification parameters (Control keypad: Menu M2 → G2.6.6)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.6.17.1	Flux 10 %	0	2500	%	10		135 5	
P2.6.17.2	Flux 20 %	0	2500	%	20		135 6	
P2.6.17.3	Flux 30 %	0	2500	%	30		135 7	
P2.6.17.4	Flux 40 %	0	2500	%	40		135 8	
P2.6.17.5	Flux 50 %	0	2500	%	50		135 9	
P2.6.17.6	Flux 60 %	0	2500	%	60		136 0	
P2.6.17.7	Flux 70 %	0	2500	%	70		136 1	
P2.6.17.8	Flux 80 %	0	2500	%	80		136 2	
P2.6.17.9	Flux 90 %	0	2500	%	90		136 3	
P2.6.17.10	Flux 100 %	0	2500	%	100		136 4	
P2.6.17.11	Flux 110 %	0	2500	%	110		136 5	
P2.6.17.12	Flux 120 %	0	2500	%	120		136 6	
P2.6.16.13	Flux 130 %	0	2500	%	130		136 7	
P2.6.17.14	Flux 140 %	0	2500	%	140		136 8	
P2.6.17.15	Flux 150 %	0	2500	%	150		136 9	
P2.6.17.16	Rs voltage drop	0	30000		Varies		662	Used for torque calculation in open loop
P2.6.17.17	Ir add zero point voltage	0	30000		Varies		664	
P2.6.17.18	Ir add generator scale	0	30000		Varies		665	
P2.6.17.19	Ir add motoring scale	0	30000		Varies		667	
P2.6.17.20	Iu Offset	-32000	32000		0		668	
P2.6.17.21	Iv Offset	-32000	32000		0		669	
P2.6.17.22	Iw Offset	-32000	32000		0		670	
P2.6.17.23	Speed step	-50,0	50,0	0,0	0,0		125 2	NCDrive speed tuning

Table 4-13. Identification parameters, G2.6.4

4.8 Protections (Control keypad: Menu M2 → G2.7)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.7.1	Response to 4mA reference fault	0	5		0		700	0=No response 1=Warning 2=Warning+Previous Freq. 3=Wrng+PresetFreq 2.7.2 4=Fault,stop acc. to 2.4.7 5=Fault,stop by coasting
P2.7.2	4mA reference fault frequency		P2.1.2	Hz			728	
P2.7.3	Response to external fault	0	3		2		701	0=No response 1=Warning
P2.7.4	Input phase supervision	0	3		0		730	2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.5	Response to undervoltage fault	0	1		0		727	0=Fault stored in history 1=Fault not stored
P2.7.6	Output phase supervision	0	3		2		702	0=No response 1=Warning
P2.7.7	Earth fault protection	0	3		2		703	2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.8	Thermal protection of the motor	0	3		2		704	3=Fault,stop by coasting
P2.7.9	Motor ambient temperature factor	-100,0	100,0	%	0,0		705	
P2.7.10	Motor cooling factor at zero speed	0,0	150,0	%	40,0		706	
P2.7.11	Motor thermal time constant	1	200	min	Varies		707	
P2.7.12	Motor duty cycle	0	100	%	100		708	
P2.7.13	Stall protection	0	3		0		709	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.14	Stall current	0,1	$I_{nMotor} \times 2$	A	I_L		710	
P2.7.15	Stall time limit	1,00	120,00	s	15,00		711	
P2.7.16	Stall frequency limit		P2.1.2	Hz			712	
P2.7.17	Underload protection	0	3		0		713	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.18	Field weakening area load	10	150	%	50		714	
P2.7.19	Zero frequency load	5,0	150,0	%	10,0		715	
P2.7.20	Underload protection time limit	2	600	s	20		716	
P2.7.21	Response to thermistor fault	0	3		2		732	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.22	Response to fieldbus fault	0	3		2		733	See P2.7.21
P2.7.23	Response to slot fault	0	3		2		734	See P2.7.21
P2.7.24	No. of PT100 inputs	0	5		0		739	0=Not used 1=PT100 input 1 2= PT100 input 1 & 2 3= PT100 input 1 & 2 & 3 4= PT100 input 2 & 3 5= PT100 input 3
P2.7.25	Response to PT100 fault	0	3		2		740	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.7.26	PT100 warning limit	-30,0	200,0	C°	120,0		741	
P2.7.27	PT100 fault limit	-30,0	200,0	C°	130,0		742	
P2.7.28	Disable Run Lock	0	1		0		1086	

Table 4-14. Protections, G2.7

4.9 Autorestart parameters (Control keypad: Menu M2 → G2.8)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.8.1	Wait time	0,10	10,00	s	0,50		717	
P2.8.2	Trial time	0,00	60,00	s	30,00		718	
P2.8.3	Start function	0	2		0		719	0=Ramp 1=Flying start 2=According to P 2.4.6
P2.8.4	Number of tries after undervoltage trip	0	10		0		720	
P2.8.5	Number of tries after overvoltage trip	0	10		0		721	
P2.8.6	Number of tries after overcurrent trip	0	3		0		722	
P2.8.7	Number of tries after 4mA reference trip	0	10		0		723	
P2.8.8	Number of tries after motor temperature fault trip	0	10		0		726	
P2.8.9	Number of tries after external fault trip	0	10		0		725	
P2.8.10	Number of tries after underload fault trip	0	10		1		738	

Table 4-15. Autorestart parameters, G2.8

4.10 High Speed Special parameters (Control keypad: Menu M2 → G2.9)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.9.1	Torque Stabilizer Damping	0	1000		900		1504	
P2.9.2	Torque Stabilizer Gain	0	1000		100		1505	
P2.9.3	Torque Stabilizer Gain in FWP	0	1000		50		1506	
P2.9.4	Flux Stabilizer Gain	0	32000		500		1507	
P2.9.5	Voltage Stabilizer Damping	0	1000		900		1508	
P2.8.6	Voltage Stabilizer Gain	0	1000		100		1509	
P2.9.7	Voltage Stabilizer Limit	0	1000		150		1510	
P2.9.8	RS Voltage Drop	0	1000		0		662	
P2.9.9	Synchronous / Asynchronous Modulator	0	1		1		1512	0 = Synchronous modulation 1 = Asynchronous Modulation
P2.9.10	Symmetrical / Asymmetrical Modulation	0	1		0		1513	0 = Asymmetrical 1 = Symmetrical
P2.9.11	Max Voltage Index	50	113	%	105		1503	
P2.9.12	Low speed option	-1	5000		-1		1514	-1 = Disabled
P2.9.13	Disable enable HW Low speed option	0	1		1		1515	0 = Enabled 1 = Disabled
P2.9.14	Licence	0	65535		0		1502	License key needed if >1900Hz is required
P2.9.15	FluxCircStabGain	0	30000		10000		1519	Gain for Flux Circle Stabilizer

Table 1-11. Autorestart parameters, G2.8

4.11 Field bus parameters (Control keypad: Menu M2 → G2.10)

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P2.10.1	Fieldbus min scale			Hz			850	
P2.10.2	Fieldbus max scale			Hz			851	
P2.10.3	Fieldbus process data out 1 selection	0	10000		1		852	Choose monitoring data with parameter ID Def: Output Frequency
P2.10.4	Fieldbus process data out 2 selection	0	10000		2		853	Choose monitoring data with parameter ID Def: Motor Speed
P2.10.5	Fieldbus process data out 3 selection	0	10000		45		854	Choose monitoring data with parameter ID Def: Motor Current to FB
P2.10.6	Fieldbus process data out 4 selection	0	10000		4		855	Choose monitoring data with parameter ID Def: Motor Torque
P2.10.7	Fieldbus process data out 5 selection	0	10000		5		856	Choose monitoring data with parameter ID Def: Motor Power
P2.10.8	Fieldbus process data out 6 selection	0	10000		6		857	Choose monitoring data with parameter ID Def: Motor Voltage
P2.10.9	Fieldbus process data out 7 selection	0	10000		7		858	Choose monitoring data with parameter ID Def: DC-Link Voltage
P2.10.10	Fieldbus process data out 8 selection	0	10000		37		859	Choose monitoring data with parameter ID Def: Last Active Fault

Table 4-16. Field bus parameters, G2.10

4.12 Keypad control (Control keypad: Menu M3)

The parameters for the selection of control place and direction on the keypad are listed below. See the [Keypad control menu](#) in the Vacon NX User's Manual.

Code	Parameter	Min	Max	Unit	Default	Cust	ID	Note
P3.1	Control place	1	3		1		125	1=I/O terminal 2=Keypad 3=Fieldbus
R3.2	Keypad reference	P2.1.1	P2.1.2	Hz				
P3.3	Direction (on keypad)	0	1		0		123	0 = Forward 1 = Reverse
R3.4	Stop button	0	1		1		114	0=Limited function of Stop button 1=Stop button always enabled

Table 4-17. Keypad control parameters, M3

4.13 System menu (Control keypad: M6)

For parameters and functions related to the general use of the frequency converter, such as application and language selection, customised parameter sets or information about the hardware and software, see the product's User's Manual.

4.14 Expander boards (Control keypad: Menu M7)

The **M7** menu shows the expander and option boards attached to the control board and board-related information. For more information, see the product's User's Manual.

5. DESCRIPTION OF PARAMETERS

On the following pages you will find the parameter descriptions arranged according to the individual ID number of the parameter. A shaded parameter ID number (e.g. **377 AI1 Signal SelectionP**) indicates that the *TTF programming method* shall be applied to this parameter.

- 101** **Minimum frequency** (2.1.1)
102 **Maximum frequency** (2.1.2)

Defines the frequency limits of the frequency converter.

The maximum value for these parameters is 5200 Hz.

The software will automatically check the values of parameters ID105, ID106, [ID315](#) and [ID728](#).

- 103** **Acceleration time 1** (2.1.3)
104 **Deceleration time 1** (2.1.4)

These limits correspond to the time required for the output frequency to accelerate from the zero frequency to the set maximum frequency (P ID102).

- 105** **Preset speed 1** (2.1.14)
106 **Preset speed 2** (2.1.15)

Parameter values are automatically limited between the minimum and maximum frequencies (P ID101, ID102).

Note the use of TTF-programming method in the Multi-purpose Control Application. See parameters [ID419](#), [ID420](#) and [ID421](#).

Speed	Multi-step speed sel. 1 (DIN4)	Multi-step speed sel. 2 (DIN5)
Basic speed	0	0
ID105	1	0
ID106	0	1

Table 5-1. Preset speed

- 107** **Current limit** (2.1.5)

This parameter determines the maximum motor current from the frequency converter. The parameter value range differs from size to size.

NOTE! The Max value for this parameter might differ for FR9 and bigger and for NXLC.

108 U/f ration selection (2.6.3)

Linear: The voltage of the motor changes linearly with the frequency in the constant flux area from 0 Hz to the field weakening point where the nominal voltage is supplied to the motor. Linear U/f ration should be used in constant torque applications. **This default setting should be used if there is no special need for another setting.**

Squared: The voltage of the motor changes following a squared curve form with the frequency in the area from 0 Hz to the field weakening point where the nominal voltage is also supplied to the motor. The motor runs undermagnetised below the field weakening point and produces less torque and electro-mechanical noise. Squared U/f ratio can be used in applications where torque demand of the load is proportional to the square of the speed, e.g. in centrifugal fans and pumps.




Figure 5-1. Linear and squared change of motor voltage

Programmable U/f curve: The U/f curve can be programmed with three different points. Programmable U/f curve can be used if the other settings do not satisfy the needs of the application.




Figure 5-2. Programmable U/f curve

Linear with flux optimisation:

- 3** The frequency converter starts to search for the minimum motor current in order to save energy, lower the disturbance level and the noise. This function can be used in applications with constant motor load, such as fans, pumps etc.

109 **U/f optimisation** (2.6.2)

Automatic torque boost The voltage to the motor changes automatically which makes the motor produce sufficient torque to start and run at low frequencies. The voltage increase depends on the motor type and power. Automatic torque boost can be used in applications where starting torque due to starting friction is high, e.g. in conveyors.

NOTE! This feature is not usable if ID662 = 0.

EXAMPLE:

What changes are required to start with load from 0 Hz?

- ◆ First set the motor nominal values (Parameter group 2.1).

Option 1: Activate the Automatic torque boost.

Option 2: Programmable U/f curve

To get torque you need to set the zero point voltage and midpoint voltage/frequency (in parameter group 2.6) so that the motor takes enough current at low frequencies. First set ID108 to *Programmable U/f curve* (value 2). Increase zero point voltage (ID606) to get enough current at zero speed. Set then the midpoint voltage (ID605) to $1.4142 \cdot \text{ID606}$ and midpoint frequency (ID604) to value $\text{ID606}/100\% \cdot \text{ID111}$.

NOTE! In high torque – low speed applications – it is likely that the motor will overheat. If the motor has to run a prolonged time under these conditions, special attention must be paid to cooling the motor. Use external cooling for the motor if the temperature tends to rise too high.

110 **Nominal voltage of the motor** (2.1.6)

Find this value U_n on the rating plate of the motor. This parameter sets the voltage at the field weakening point (ID603) to $100\% \cdot U_{n\text{Motor}}$.

111 **Nominal frequency of the motor** (2.1.7)

Find this value f_n on the rating plate of the motor. This parameter sets the field weakening point (ID602) to the same value.

112 **Nominal speed of the motor** (2.1.8)

Find this value n_n on the rating plate of the motor.

113 **Nominal current of the motor** (2.1.9)

Find this value I_n on the rating plate of the motor.

NOTE! The Max value for this parameter might differ for FR9 and bigger, and for NXW.

117 I/O frequency reference selection (2.1.11)

Defines which frequency reference source is selected when controlled from the I/O control place.

Applic.	ASFIFF12
Sel.	
0	Analogue volt.ref. Terminals 2-3
1	Analogue curr.ref. Terminals 4-5
2	Keypad reference (Menu M3)
3	Fieldbus reference
4	AI3

Table 5-2. Selections for parameter ID117

120 Motor cos phi (2.1.10)

Find this value “cos phi” on the rating plate of the motor.

121 Keypad frequency reference selection (2.1.12)

Defines which frequency reference source is selected when controlled from the keypad.

Applic.	ASFIFF12
Sel.	
0	Analogue volt.ref. Terminals 2–3
1	Analogue curr.ref. Terminals 4–5
2	Keypad reference (Menu M3)
3	Fieldbus reference*
4	AI3

Table 5-3. Selections for parameter ID121

*FBSpeedReference

122 Fieldbus frequency reference selection (2.1.13)

Defines which frequency reference source is selected when controlled from the fieldbus. For selections in different applications, see ID121.

300

Start/Stop logic selection

(2.2.1)

- 0 DIN1: closed contact = start forward
- DIN2: closed contact = start reverse




Figure 5-3. Start forward/Start reverse

- ① The first selected direction has the highest priority.
- ② When the DIN1 contact opens the direction of rotation starts the change.
- ③ If Start forward (DIN1) and Start reverse (DIN2) signals are active simultaneously the Start forward signal (DIN1) has priority.

- 1 DIN1: closed contact = start open contact = stop
- DIN2: closed contact = reverse open contact = forward
- See below.




Figure 5-4. Start, Stop, Reverse

- 2 DIN1: closed contact = start open contact = stop
- DIN2: closed contact = start enabled open contact = start disabled and drive stopped if running

- 3 3-wire connection (pulse control):
 DIN1: closed contact = start pulse
 DIN2: open contact = stop pulse
 (DIN3 can be programmed for reverse command)
 See Figure 5-5.




Figure 5-5. Start pulse/ Stop pulse.

The selections including the text **'Rising edge required to start'** shall be used to exclude the possibility of an unintentional start when, for example, power is connected, re-connected after a power failure, after a fault reset, after the drive is stopped by Run Enable (Run Enable = False) or when the control place is changed. The Start/Stop contact must be opened before the motor can be started.

- 4 DIN1: closed contact = start forward (**Rising edge required to start**)
 DIN2: closed contact = start reverse (**Rising edge required to start**)
- 5 DIN1: closed contact = start (**Rising edge required to start**)
 open contact = stop
 DIN2: closed contact = reverse
 open contact = forward
- 6 DIN1: closed contact = start (**Rising edge required to start**)
 open contact = stop
 DIN2: closed contact = start enabled
 open contact = start disabled and drive stopped if running

301 *DIN3 function* (2.2.2)

- 0** Not used
- 1** External fault, closing contact = Fault is shown and motor is stopped when the input is active.
- 2** External fault, opening contact = Fault is shown and motor is stopped when the input is not active.
- 3** Run enable, contact open = Motor start disabled and the motor is stopped
 contact closed = Motor start enabled
- 4** Acc./Dec contact open = Acceleration/deceleration time 1 selected
 time select. contact closed = Acceleration/deceleration time 2 selected
- 5** Closing contact: Force control place to I/O terminal
- 6** Closing contact: Force control place to keypad
- 7** Closing contact: Force control place to fieldbus
 When the control place is forced to change the values of Start/Stop, Direction and Reference valid in the respective control place are used (reference according to parameters [ID117](#), [ID121](#) and [ID122](#)).
 Note: The value of parameter [ID125](#) Keypad Control Place does not change. When DIN3 opens the control place is selected according to parameter 3.1.
- 8** Reverse contact open = Forward
 contact closed = Reverse

Can be used for reversing if parameter [ID300](#) has value 3.

302 *Reference offset for current input* (2.2.3)

- 0** No offset: 0—20mA
- 1** Offset 4 mA (“living zero”), provides supervision of zero level signal. In Standard Application, the response to 4 mA reference fault can be programmed with parameter [ID700](#).

303 *Reference scaling, minimum value* (2.2.4)

304 *Reference scaling, maximum value* (2.2.5)

Setting value limits: $0 \leq P \text{ ID303} \leq P \text{ ID304} \leq P \text{ ID102}$. If parameter $\text{ID303} = 0$ scaling is set off. The minimum and maximum frequencies are used for scaling.




Figure 5-6. *Left: Reference scaling; Right: No scaling used (P ID303 = 0).*

305 Reference inversion

Inverts reference signal:
 Max. ref. signal = Min. set freq.
 Min. ref. signal = Max. set freq.

- 0 No inversion
- 1 Reference inverted

(2.2.6)




Figure 5-7. Reference invert.

306 Reference filter time

Filters out disturbances from the incoming analogue U_{in} signal.
 Long filtering time makes regulation response slower.

(2.2.7)




Figure 5-8. Reference filtering

307 Analogue output function (2.3.2)

This parameter selects the desired function for the analogue output signal.

308 Analogue output filter time (2.3.3)

Defines the filtering time of the analogue output signal. Setting this parameter value **0** will deactivate filtering.




Figure 5-9. Analogue output filtering

309 Analogue output inversion (2.3.4)

Inverts the analogue output signal:

Maximum output signal = Minimum set value
 Minimum output signal = Maximum set value

See parameter [ID311](#) below.




Figure 5-10. Analogue output invert

310 Analogue output minimum (2.3.5)

Defines the signal minimum to either 0 mA or 4 mA (living zero). Note the difference in analogue output scaling in parameter [ID311](#) (Figure -11).

- 0** Set minimum value to 0 mA
- 1** Set minimum value to 4 mA

311 Analogue output scale 234567 (2.3.6)

Scaling factor for analogue output.

Signal	Max. value of the signal
Output frequency	Max frequency (ID102)
Freq. Reference	Max frequency (ID102)
Motor speed	Motor nom. speed $1 \times n_{mMotor}$
Output current	Motor nom. current $1 \times I_{nMotor}$
Motor torque	Motor nom. torque $1 \times T_{nMotor}$
Motor power	Motor nom. power $1 \times P_{nMotor}$
Motor voltage	$100\% \times U_{nMotor}$
DC-link voltage	1000 V

Table 5-4. Analogue output scaling




Figure 5-11. Analogue output scaling

312 Digital output function (2.3.7)

313 Relay output 1 function (2.3.83)

314 Relay output 2 function (2.3.9)

Setting value	Signal content
0 = Not used	Out of operation
	<u>Digital output DO1 sinks the current and programmable relay (RO1, RO2) is activated when:</u>
1 = Ready	The frequency converter is ready to operate
2 = Run	The frequency converter operates (motor is running)
3 = Fault	A fault trip has occurred
4 = Fault inverted	A fault trip <u>not</u> occurred
5 = Vacon overheat warning	The heat-sink temperature exceeds +70°C
6 = External fault or warning	Fault or warning depending on P ID701
7 = 4mA reference fault or warning	Fault or warning depending on P ID700 - if analogue reference is 4—20 mA and signal is <4mA
8 = Warning	Always if a warning exists
9 = Reversed	The reverse command has been selected
10 = Preset speed 1 (Applications 2) 10 = Jogging speed (Applications 3456)	The preset speed has been selected with digital input The jogging speed has been selected with digital input
11 = At speed	The output frequency has reached the set reference
12 = Motor regulator activated	Overvoltage or overcurrent regulator was activated
13 = Output frequency limit supervision	The output frequency goes outside the set supervision low limit/high limit (see parameter ID's 315 and 316 below)
14 = Control from I/O terminals (Appl. 2)	I/O control mode selected (in menu M3)
15 = Thermistor fault or warning (Appl.2)	The thermistor input of option board indicates overtemperature. Fault or warning depending on par ID732.
16 = Fieldbus input data	Fieldbus input data (FBFixedControlWord) to DO/RO.

Table 5-5. Output signals via DO1 and output relays RO1 and RO2.

315 **Output frequency limit supervision function** (2.3.101)

- 0** No supervision
- 1** Low limit supervision
- 2** High limit supervision

If the output frequency goes under/over the set limit (ID316) this function generates a warning message via the digital output DO1 or via the relay output RO1 or RO2 depending on the settings of parameters ID312...ID314.

316 **Output frequency limit supervision value** (2.3.11)

Selects the frequency value supervised by parameter ID315. See Figure 5-12




Figure 5-12. Output frequency supervision

377 **AI1 signal selection** (2.2.8)

Connect the AI1 signal to the analogue input of your choice with this parameter. For more information about the TTF programming method.

388 **AI2 signal selection** (2.2.9)

Connect the AI2 signal to the analogue input of your choice with this parameter. For more information about the TTF programming method.

- 500 **Acceleration/Deceleration ramp 1 shape** (2.4.1)
 501 **Acceleration/Deceleration ramp 2 shape** (2.4.2)

The start and end of acceleration and deceleration ramps can be smoothed with these parameters. Setting value **0** gives a linear ramp shape which causes acceleration and deceleration to act immediately to the changes in the reference signal. Setting value 0.1...10 seconds for this parameter produces an S-shaped acceleration/deceleration. The acceleration time is determined with parameters [ID103/ID104](#) (ID502/ID503).




Figure 5-13. Acceleration/Deceleration (S-shaped)

- 502 **Acceleration time 2** (2.4.3)
 503 **Deceleration time 2** (2.4.4)

These values correspond to the time required for the output frequency to accelerate from the zero frequency to the set maximum frequency ([ID102](#)). These parameters give the possibility to set two different acceleration/deceleration time sets for one application. The active set can be selected with the programmable signal DIN3 ([ID301](#)).

- 504 **Brake chopper** (2.4.5)

- 0 = No brake chopper used
- 1 = Brake chopper in use and tested when running. Can be tested also in READY state
- 2 = External brake chopper (no testing)
- 3 = Used and tested in READY state and when running
- 4 = Used when running (no testing)

When the frequency converter is decelerating the motor, the inertia of the motor and the load are fed into an external brake resistor. This enables the frequency converter to decelerate the load with a torque equal to that of acceleration (provided that the correct brake resistor has been selected). See separate Brake resistor installation manual.

505 Start function (2.4.6)

Ramp:

- 0** The frequency converter starts from 0 Hz and accelerates to the set reference frequency within the set [acceleration time](#). (Load inertia or starting friction may cause prolonged acceleration times).

Flying start:

- 1** The frequency converter is able to start into a running motor by applying a small torque to motor and searching for the frequency corresponding to the speed the motor is running at. Searching starts from the maximum frequency towards the actual frequency until the correct value is detected. Thereafter, the output frequency will be increased/decreased to the set reference value according to the set acceleration/deceleration parameters.

Use this mode if the motor is coasting when the start command is given. With the flying start it is possible to ride through short mains voltage interruptions.

506 Stop function (2.4.7)Coasting:

- 0** The motor coasts to a halt without any control from the frequency converter, after the Stop command.

Ramp:

- 1** After the Stop command, the speed of the motor is decelerated according to the set deceleration parameters.
If the regenerated energy is high it may be necessary to use an external braking resistor for faster deceleration.

Normal stop: Ramp/ Run Enable stop: coasting

- 2** After the Stop command, the speed of the motor is decelerated according to the set deceleration parameters. However, when Run Enable is selected, the motor coasts to a halt without any control from the frequency converter.

Normal stop: Coasting/ Run Enable stop: ramping

- 3** The motor coasts to a halt without any control from the frequency converter. However, when Run Enable signal is selected, the speed of the motor is decelerated according to the set deceleration parameters. If the regenerated energy is high it may be necessary to use an external braking resistor for faster deceleration.

507 DC-braking current (2.4.8)

Defines the current injected into the motor during DC-braking.

NOTE! The Max value for this parameter might differ for FR9 and bigger, and for NXLC.

508 DC-braking time at stop (2.4.9)

Determines if braking is ON or OFF and the braking time of the DC-brake when the motor is stopping. The function of the DC-brake depends on the stop function, parameter [ID506](#).

- 0** DC-brake is not used
>0 DC-brake is in use and its function depends on the Stop function, (param. [ID506](#)). The DC-braking time is determined with this parameter.

ID506 = 0; Stop function = Coasting:

After the stop command, the motor coasts to a stop without control of the frequency converter.

With DC-injection, the motor can be electrically stopped in the shortest possible time, without using an optional external braking resistor.

The braking time is scaled according to the frequency when the DC-braking starts. If the frequency is \geq the nominal frequency of the motor, the set value of parameter ID508 determines the braking time. When the frequency is $\leq 10\%$ of the nominal, the braking time is 10% of the set value of parameter ID508.




Figure 5-14. DC-braking time when Stop mode = Coasting.

ID506 = 1; Stop function = Ramp:

After the Stop command, the speed of the motor is reduced according to the set deceleration parameters, as fast as possible, to the speed defined with parameter ID515, where the DC-braking starts.

The braking time is defined with parameter ID508. If high inertia exists, it is recommended to use an external braking resistor for faster deceleration. See Figure 5-15.




Figure 5-15. DC-braking time when Stop mode = Ramp

509 **Prohibit frequency area 1; Low limit 234567** (2.5.1)

510 **Prohibit frequency area 1; High limit 234567** (2.5.2)

In some systems it may be necessary to avoid certain frequencies because of mechanical resonance problems. With these parameters it is possible to set limits for the "skip frequency" region. See Figure 5-16.




Figure 5-16. Example of prohibit frequency area setting.

515 **DC-braking frequency at stop** (2.4.10)

The output frequency at which the DC-braking is applied. See Figure 5-16.

516 **DC-braking time at start** (2.4.11)

DC-brake is activated when the start command is given. This parameter defines the time before the brake is released. After the brake is released, the output frequency increases according to the set start function by parameter [ID505](#).

518 **Acceleration/deceleration ramp speed scaling ratio between prohibit frequency limits** (2.5.3)

Defines the acceleration/deceleration time when the output frequency is between the selected prohibit frequency range limits (parameters [ID509](#) and [ID510](#)). The ramping speed (selected acceleration/ deceleration time 1 or 2) is multiplied with this factor. E.g. value 0.1 makes the acceleration time 10 times shorter than outside the prohibit frequency range limits.




Figure 5-17. Ramp speed scaling between prohibit frequencies

519 Flux braking current (2.4.13)

Defines the flux braking current value. This value can be set between $0.4 \cdot I_H$ and the [Current limit](#).

NOTE! The Max value for this parameter might differ for FR9 and bigger, and for NXLC.

520 Flux brake (2.4.12)

Instead of DC braking, flux braking is a useful way to raise the braking capacity in cases where additional brake resistors are not needed. When braking is needed, the frequency is reduced and the flux in the motor is increased, which in turn increases the motor's capability to brake. Unlike DC braking, the motor speed remains controlled during braking.

The flux braking can be set ON or OFF.

0 = Flux braking OFF
1 = Flux braking ON

Note: Flux braking converts the energy into heat at the motor, and should be used intermittently to avoid motor damage.

523 Frequency Scale (2.1.17)

By changing the Frequency Scale will the internal variables for setting the decimals, and max values for eg MaxFreq, Motor Nominal Freq/Speed, be set automatically.

Freq Scale Sel.	Frequency Area
0	0-32,000 Hz
1	0-320,00 Hz
2	0-1900,0 Hz
3	0-3200,0 Hz
4	0-5200 Hz
5	0-7200 Hz

600 Motor control mode (2.6.1)**NXS:**

- 0** Frequency control: The I/O terminal and keypad references are frequency references and the frequency converter controls the output frequency (output frequency resolution = 0.01 Hz)
- 1** Speed control: The I/O terminal and keypad references are speed references and the frequency converter controls the motor speed compensating the motor slip (accuracy $\pm 0,5\%$).

The following selections are available for Vacon NXP drives only, except for selection **2** which is available in the Multi-Purpose Control Application for NXS drives also.

- 2** Torque control In torque control mode, the references are used to control the motor torque.
- 3** Speed ctrl (closed loop) The I/O terminal and keypad references are speed references and the frequency converter controls the motor speed very accurately comparing the actual speed received from the tachometer to the speed reference (accuracy $\pm 0.01\%$).
- 4** Torque ctrl (closed loop) The I/O terminal and keypad references are torque references and the frequency converter controls the motor torque.
- 5** Frequency control (advanced open loop)
Frequency control with better performance at lower speeds.
- 6** Speed control (advanced open loop)
Speed control with better performance at lower speeds.

601 Switching frequency (2.6.9)

Motor noise can be minimised using a high switching frequency. Increasing the switching frequency reduces the capacity of the frequency converter unit.

The range of this parameter depends on the size of the frequency converter:

Type	Min. [kHz]	Max. [kHz]	Default [kHz]
0003—0061 NX_2 0003—0061 NX_5	1.0	16,0	10.0
0075—0205 NX_2	1.0	10.0	3.6
0072—0520 NX_5	1.0	6.0	3.6
0004—0208 NX_6	1.0	6.0	1.5

Table 5-6. Size-dependent switching frequencies

602 Field weakening point (2.6.4)

The field weakening point is the output frequency at which the output voltage reaches the set ([ID603](#)) maximum value.

- 603** ***Voltage at field weakening point*** (2.6.5)
- Above the frequency at the field weakening point, the output voltage remains at the set maximum value. Below the frequency at the field weakening point, the output voltage depends on the setting of the U/f curve parameters. See parameters ID109, ID108, ID604 and ID605.
- When the parameters ID110 and ID111 (nominal voltage and nominal frequency of the motor) are set, the parameters ID602 and ID603 are automatically given the corresponding values. If you need different values for the field weakening point and the maximum output voltage, change these parameters **after** setting the parameters ID110 and ID111.
- 604** ***U/f curve, middle point frequency*** (2.6.6)
- If the programmable U/f curve has been selected with parameter ID108 this parameter defines the middle point frequency of the curve. See Figure 5-2.
- 605** ***U/f curve, middle point voltage*** (2.6.7)
- If the programmable U/f curve has been selected with the parameter ID108 this parameter defines the middle point voltage of the curve. See Figure 5-2.
- 606** ***Output voltage at zero frequency*** (2.6.8)
- If the programmable U/f curve has been selected with the parameter ID108 this parameter defines the zero frequency voltage of the curve. NOTE: If the value of parameter ID108 is changed this parameter is set to zero. See Figure 5-2.
- 607** ***Overvoltage controller*** (2.6.10)
- These parameters allow the under-/overvoltage controllers to be switched out of operation. This may be useful, for example, if the mains supply voltage varies more than -15% to +10% and the application will not tolerate this over-/undervoltage. In this case, the regulator controls the output frequency taking the supply fluctuations into account.
- 0 Controller switched off
 - 1 Controller switched on (no ramping) = Minor adjustments of OP frequency are made
 - 2 Controller switched on (with ramping) = Controller adjusts OP freq. up to max.freq.
- 608** ***Undervoltage controller*** (2.6.11)
- See ID607.
- Note:** Over-/undervoltage trips may occur when controllers are switched out of operation.
- 0 Controller switched off
 - 1 Controller switched on

- 612** **CL: Magnetizing current** (2.6.14.1)
Set here the motor magnetizing current (no-load current). See chapter 6.1.
- 613** **CL: Speed control P gain** (2.6.14.2)
Sets the gain for the speed controller in % per Hz. See chapter 6.1.
- 614** **CL: Speed control I time** (2.6.14.3)
Sets the integral time constant for the speed controller. Increasing the I-time increases stability but lengthens the speed response time. See chapter 6.1.
- 615** **CL: Zero speed time at start** (2.6.14.9)
After giving the start command the drive will remain at zero speed for the time defined by this parameter. The ramp will be released to follow the set frequency/speed reference after this time has elapsed from the instant where the command is given. See chapter 6.1.
- 616** **CL: Zero speed time at stop** (2.6.14.10)
The drive will remain at zero speed with controllers active for the time defined by this parameter after reaching the zero speed when a stop command is given. This parameter has no effect if the selected stop function ([ID506](#)) is *Coasting*. See chapter 6.1.
- 617** **CL: Current control P gain** (2.6.14.17)
Sets the gain for the current controller. This controller is active only in closed loop and advanced open loop modes. The controller generates the voltage vector reference to the modulator. See chapter 6.1.
- 618** **CL: Encoder filter time** (2.6.14.15)
Sets the filter time constant for speed measurement.
The parameter can be used to eliminate encoder signal noise. Too high a filter time reduces speed control stability. See chapter 6.1.
- 619** **CL: Slip adjust** (2.6.14.6)
The motor name plate speed is used to calculate the nominal slip. This value is used to adjust the voltage of motor when loaded. The name plate speed is sometimes a little inaccurate and this parameter can therefore be used to trim the slip. Reducing the slip adjust value increases the motor voltage when the motor is loaded. See chapter 6.1.
- 620** **Load drooping** (2.6.12)
The drooping function enables speed drop as a function of load. This parameter sets that amount corresponding to the nominal torque of the motor.

- 621** **CL: Startup torque** (2.6.14.11)
Choose here the startup torque.
Torque Memory is used in crane applications. Startup Torque FWD/REV can be used in other applications to help the speed controller. See chapter 6.1.
0 = Not Used
1 = TorqMemory
2 = Torque Ref
3 = Torq.Fwd/Rev
- 622** **AOL: Minimum current** (2.6.15.2)
Minimum current to the motor in the current control frequency region. Larger value gives more torque, but increases losses. See chapter 6.2.
- 623** **AOL: Flux reference** (2.6.15.3)
Reference for flux below the frequency limit. Larger value gives more torque, but increases losses. See chapter 6.2.
- 625** **AOL: Zero speed current** (2.6.15.1)
At very low frequencies, this parameter defines the constant current reference to the motor. See chapter 6.2.
- 626** **CL: Acceleration compensation** (2.6.14.5)
Sets the inertia compensation to improve speed response during acceleration and deceleration. The time is defined as acceleration time to nominal speed with nominal torque. This parameter is active also in advanced open loop mode.
- 627** **CL: Magnetizing current at start** (2.6.14.7)
- 628** **CL: Magnetizing time at start** (2.6.14.8)
Set here the rise time of magnetizing current.

631 Identification (2.6.2)

Identification Run is a part of tuning the motor and the drive specific parameters. It is a tool for commissioning and service of the drive with the aim to find as good parameter values as possible for most drives. The automatic motor identification calculates or measures the motor parameters that are needed for optimum motor and speed control.

0 = No action

No identification requested.

1 = Identification without motor run

The drive is run without speed to identify the motor parameters. The motor is supplied with current and voltage but with zero frequency. U/f ratio is identified.

2 = Identification with motor run

The drive is run with speed to identify the motor parameters. U/f ratio and magnetization current is identified.

Note: It is required to do the this identification run with no load on the motor shaft for accurate results.

The basic motor name plate data has to be set correctly before performing the identification run:

- ID110 Nominal voltage of the motor (par. 2.1.6)*
- ID111 Nominal frequency of the motor (par. 2.1.7)*
- ID112 Nominal speed of the motor (par. 2.1.8)*
- ID113 Nominal current of the motor (par. 2.1.9)*
- ID120 Motor cos phi (par. 2.1.10)*

When in closed loop and with an encoder installed, also the parameter for pulses / revolutions (in Menu M7) has to be set.

The automatic identification is activated by setting this parameter to the appropriate value followed by a start command in the requested direction. The start command to the drive has to be given within 20 s. If no start command is given within 20 s the identification run is cancelled and the parameter will be reset to its default setting. The identification run can be stopped any time with normal stop command and the parameter is reset to its default setting. In case identification run detects fault or other problems, the identification run is completed if possible. After the identification is finished, the application checks the status of the identification and generates fault/ warning if any.

During Identification Run, the brake control is disabled (see chapter **Error! Reference source not found.**).

Note: After identification is made drive requires rising edge of start command.

- 632** **AOL: U/f boost** (2.6.15.5)
Boost voltage at Frequency Limit to increase flux and torque. See chapter 6.2.
- 633** **CL: Start-up torque, forward** (2.6.14.12)
Sets the start-up torque for forward direction if selected with P ID621.
- 634** **CL: Start-up torque, reverse** (2.6.14.13)
Sets the start-up torque for reverse direction if selected with P ID621.
- 635** **AOL: Frequency limit** (2.6.15.4)
Corner frequency for transition to standard U/f control. The value is given in % of motor nominal frequency. See chapter 6.2.
- 650** **Motor Type** (2.1.18)
Select used motor type with this parameter.
0 = Induction motor
1 = Permanent magnet synchronous motor
- 657** **Current control Ti**
Current controller integrator time constant (0 ... 1000) = 0...100.0 ms
- 662** **RS Voltage Drop**
This parameter defines the motor stator resistance as a voltage drop at the nominal current. Parameter value is defined according to motor nominal voltage and the current and the actual stator resistance as

$$RsVoltageDrop = 2560 \frac{I_n}{U_n} R_s$$
- 662** **Measured voltage drop** (2.6.5.18)
The measured voltage drop at stator resistance between two phases with the nominal current of the motor. This parameter is identified during ID run. Adjust this value to gain optimum torque calculation for open loop low frequencies.
- 664** **Ir: Add zero point voltage** (2.6.5.20)
Defines how much voltage is applied to motor in zero speed when torque boost is used.
- 665** **Ir: Add generator scale** (2.6.5.21)
Defines scaling factor for generator side IR-compensation when torque boost is used
- 667** **Ir: Add motoring scale** (2.6.5.22)
Defines scaling factor for motoring side IR-compensation when torque boost is used
- 668** **IU Offset** (2.6.5.23)
669 **IV Offset** (2.6.5.24)
670 **IW Offset** (2.6.5.25)
Offsets value for phase current measurement.

- 700** **Response to the 4mA reference fault** (2.7.1)
- 0 = No response
1 = Warning
2 = Warning, the frequency from 10 seconds back is set as reference
3 = Warning, the Preset Frequency (P ID728) is set as reference
4 = Fault, stop mode after fault according to ID506
5 = Fault, stop mode after fault always by coasting
A warning or a fault action and message is generated if the 4...20 mA reference signal is used and the signal falls below 3.5 mA for 5 seconds or below 0.5 mA for 0.5 seconds. The information can also be programmed into digital output DO1 or relay outputs RO1 and RO2.
- 701** **Response to external fault** (2.7.3)
- 0 = No response
1 = Warning
2 = Fault, stop mode after fault according to ID506
3 = Fault, stop mode after fault always by coasting
A warning or a fault action and message is generated from the external fault signal in the programmable digital inputs DIN3. The information can also be programmed into digital output DO1 and into relay outputs RO1 and RO2.
- 702** **Output phase supervision** (2.7.6)
- 0 = No response
1 = Warning
2 = Fault, stop mode after fault according to ID506
3 = Fault, stop mode after fault always by coasting
Output phase supervision of the motor ensures that the motor phases have an approximately equal current.
- 703** **Earth fault protection** (2.7.7)
- 0 = No response
1 = Warning
2 = Fault, stop mode after fault according to ID506
3 = Fault, stop mode after fault always by coasting
Earth fault protection ensures that the sum of the motor phase currents is zero. The overcurrent protection is always working and protects the frequency converter from earth faults with high currents.
- 704** **Motor thermal protection** (2.7.8)
- 0 = No response
1 = Warning
2 = Fault, stop mode after fault according to ID506
3 = Fault, stop mode after fault always by coasting
- If tripping is selected the drive will stop and activate the fault stage. Deactivating the protection, i.e. setting parameter to 0, will reset the thermal stage of the motor to 0%. See chapter 6.3.

705 Motor thermal protection: Motor ambient temp. factor (2.7.9)

The factor can be set between -100.0%—100.0%. See chapter 6.3.

706 Motor thermal protection: Motor cooling factor at zero speed (2.7.10)


The current can be set between 0—150.0% $\times I_{nMotor}$. This parameter sets the value for thermal current at zero frequency. See Figure 5-18.

The default value is set assuming that there is no external fan cooling the motor. If an external fan is used this parameter can be set to 90% (or even higher).

Note: The value is set as a percentage of the motor name plate data, P ID113 (Nominal current of motor), not the drive's nominal output current. The motor's nominal current is the current that the motor can withstand in direct on-line use without being overheated.

If you change the parameter Nominal current of motor, this parameter is automatically restored to the default value.

Setting this parameter does not affect the maximum output current of the drive which is determined by parameter ID107 alone. See chapter 6.3.



or thermal current I_T curve

707 Motor thermal protection: Time constant (2.7.11)

This time can be set between 1 and 200 minutes.

This is the thermal time constant of the motor. The bigger the motor, the bigger the time constant. The time constant is the time within which the calculated thermal stage has reached 63% of its final value.

The motor thermal time is specific to the motor design and it varies between different motor manufacturers.

If the motor's t_6 -time (t_6 is the time in seconds the motor can safely operate at six times the rated current) is known (given by the motor manufacturer) the time constant parameter can be set basing on it. As a rule of thumb, the motor thermal time constant in minutes equals to $2 \times t_6$. If the drive is in stop stage the time constant is internally increased to three times the set parameter value. The cooling in the stop stage is based on convection and the time constant is increased. See also Figure 5-19.

708 Motor thermal protection: Motor duty cycle (2.7.12)

Defines how much of the nominal motor load is applied.
The value can be set to 0%...100%. See chapter 6.3.




Figure 5-19. Motor temperature calculation

709 Stall protection (2.7.13)

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to [ID506](#)
- 3 = Fault, stop mode after fault always by coasting

Setting the parameter to **0** will deactivate the protection and reset the stall time counter. See chapter 6.4.

710 Stall current limit (2.7.14)

The current can be set to 0.1... I_{nMotor}^*2 . For a stall stage to occur, the current must have exceeded this limit. See Figure 5-20. The software does not allow entering a greater value than I_{nMotor}^*2 . If parameter [ID113 Nominal current of motor](#) is changed, this parameter is automatically restored to the default value (I_L). See chapter 6.4.




Figure 5-20. Stall characteristics settings

711 Stall time (2.7.15)

This time can be set between 1.0 and 120.0s.
 This is the maximum time allowed for a stall stage. The stall time is counted by an internal up/down counter.
 If the stall time counter value goes above this limit the protection will cause a trip (see ID709). See chapter 6.4.




Figure 5-21. Stall time count

712 Stall frequency limit (2.7.16)

The frequency can be set between $1-f_{\max}$ (ID102).
 For a stall state to occur, the output frequency must have remained below this limit. See chapter 6.4.

713 Underload protection (2.7.17)

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to ID506
- 3 = Fault, stop mode after fault always by coasting

If tripping is set active the drive will stop and activate the fault stage.
 Deactivating the protection by setting the parameter to 0 will reset the underload time counter to zero. See chapter 6.5.

714 Underload protection, field weakening area load (2.7.18)

The torque limit can be set between 10.0—150.0 % $\times T_{nMotor}$.
 This parameter gives the value for the minimum torque allowed when the output frequency is above the field weakening point. See Figure 5-22.

If you change parameter ID113 (Motor nominal current) this parameter is automatically restored to the default value. See chapter 6.5.




Figure 5-22. Setting of minimum load

715 Underload protection, zero frequency load (2.7.19)

The torque limit can be set between 5.0—150.0 % x TnMotor.
This parameter gives value for the minimum torque allowed with zero frequency. See Figure 5-22.

If you change the value of parameter [ID113](#) (Motor nominal current) this parameter is automatically restored to the default value. See chapter 6.5.

716 Underload time (2.7.20)

This time can be set between 2.0 and 600.0 s.
This is the maximum time allowed for an underload state to exist. An internal up/down counter counts the accumulated underload time. If the underload counter value goes above this limit the protection will cause a trip according to parameter [ID713](#)). If the drive is stopped the underload counter is reset to zero. See Figure 5-23 and chapter 6.5.




Figure 5-23. Underload time counter function

717 Automatic restart: Wait time (2.8.1)

Defines the time before the frequency converter tries to automatically restart the motor after the fault has disappeared.

718 Automatic restart: Trial time (2.8.2)

The Automatic restart function restarts the frequency converter when the faults selected with parameters [ID720](#) to [ID725](#) have disappeared and the waiting time has elapsed.




Figure 5-24. Example of Automatic restarts with two restarts

Parameters ID720 to ID725 determine the maximum number of automatic restarts during the trial time set by parameter ID718. The time count starts from the first autorestart. If the number of faults occurring during the trial time exceeds the values of parameters ID720 to ID725 the fault state becomes active. Otherwise the fault is cleared after the trial time has elapsed and the next fault start the trial time count again.

If a single fault remains during the trial time, a fault state is true.

719 **Automatic restart: Start function** (2.8.3)

The Start function for Automatic restart is selected with this parameter. The parameter defines the start mode:

- 0 = Start with ramp
- 1 = Flying start
- 2 = Start according to ID505

720 **Automatic restart: Number of tries after undervoltage fault trip** (2.8.4)

This parameter determines how many automatic restarts can be made during the trial time set by parameter ID718 after and undervoltage trip.

- 0 = No automatic restart
- >0 = Number of automatic restarts after undervoltage fault. The fault is reset and the drive is started automatically after the DC-link voltage has returned to the normal level.

721 Automatic restart: Number of tries after overvoltage trip (2.8.5)

This parameter determines how many automatic restarts can be made during the trial time set by parameter [ID718](#) after an overvoltage trip.

- 0** = No automatic restart after overvoltage fault trip
- >0** = Number of automatic restarts after overvoltage fault trip. The fault is reset and the drive is started automatically after the DC-link voltage has returned to the normal level.

722 Automatic restart: Number of tries after overcurrent trip (2.8.6)

(NOTE! IGBT temp fault also included)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0** = No automatic restart after overcurrent fault trip
- >0** = Number of automatic restarts after overcurrent trip, saturation trip and IGBT temperature faults.

723 Automatic restart: Number of tries after 4mA reference trip (2.8.7)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0** = No automatic restart after 4mA reference fault trip
- >0** = Number of automatic restarts after the analogue current signal (4...20mA) has returned to the normal level ($\geq 4\text{mA}$)

725 Automatic restart: Number of tries after external fault trip (2.8.9)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0** = No automatic restart after External fault trip
- >0** = Number of automatic restarts after External fault trip

726 Automatic restart: Number of tries after motor temperature fault trip (2.8.8)

This parameter determines how many automatics restarts can be made during the trial time set by [ID718](#).

- 0** = No automatic restart after Motor temperature fault trip
- >0** = Number of automatic restarts after the motor temperature has returned to its normal level

727 Response to undervoltage fault (2.7.5)

- 0** = Fault stored in fault history
- 1** = Fault not stored in fault history

For the undervoltage limits, see the product's User's Manual, Table 4-4.

- 728** **4mA reference fault: preset frequency reference** (2.7.2)
 If the value of parameter [ID700](#) is set to 3 and the 4mA fault occurs then the frequency reference to the motor is the value of this parameter.
- 730** **Input phase supervision** (2.7.4)
0 = No response
1 = Warning
2 = Fault, stop mode after fault according to [ID506](#)
3 = Fault, stop mode after fault always by coasting
- The input phase supervision ensures that the input phases of the frequency converter have an approximately equal current.
- 732** **Response to thermistor fault** (2.7.21)
0 = No response
1 = Warning
2 = Fault, stop mode after fault according to [ID506](#)
3 = Fault, stop mode after fault always by coasting
- Setting the parameter to **0** will deactivate the protection.
- 733** **Response to fieldbus fault** (2.7.22)
 Set here the response mode for the fieldbus fault if a fieldbus board is used. For more information, see the respective Fieldbus Board Manual.
- See parameter [ID732](#).
- 734** **Response to slot fault** (2.7.23)
 Set here the response mode for a board slot fault due to missing or broken board.
- See parameter [ID732](#).
- 738** **Automatic restart: Number of tries after underload fault trip** (2.8.10)
 This parameter determines how many automatic restarts can be made during the trial time set by parameter [ID718](#).
- 0** = No automatic restart after Underload fault trip
>0 = Number of automatic restarts after Underload fault trip

739 **Number of PT100 inputs in use** (2.7.24)

If you have a PT100 input board installed in your frequency converter you can choose here the number of PT100 inputs in use. See also the Vacon I/O boards manual.

- 0 = Not used
- 1 = PT100 input 1
- 2 = PT100 input 1 & 2
- 3 = PT100 input 1 & 2 & 3
- 4 = PT100 input 2 & 3
- 5 = PT100 input 3

Note: If the selected value is greater than the actual number of used PT100 inputs, the display will read 200°C. If the input is short-circuited the displayed value is -30°C.

740 **Response to PT100 fault F56** (2.7.25)

- 0 = No response
- 1 = Warning
- 2 = Fault, stop mode after fault according to [ID506](#)
- 3 = Fault, stop mode after fault always by coasting

741 **PT100 warning limit** (2.7.26)

Set here the limit at which the PT100 warning (W56) will be activated.

742 **PT100 fault limit** (2.7.27)

Set here the limit at which the PT100 fault (F56) will be activated.

1500 Long ramp times

By setting parameter P.2.1.16, Long Ramps, to YES, is it possible to set the acceleration and deceleration -times between 1-30 000s (8h 20min) with one-second resolution. If No is selected (default) is the max acceleration/deceleration time 0,1-3000s.

1502 Licence

By entering a license code to parameter P2.9.14 is it possible to run up to 7200Hz. This code is different for every drive and has to be purchased from Vacon. When ordering the drive with this feature, the code will be calculated before delivery. If the user wants to activate the feature afterwards, he has to inform Vacon about the serial number of the power unit(s) for the drive(s) where the feature is wanted.

1503 Max Voltage Index

This parameter can be used to limit the drive operating point not to exceed the linear modulation range in which case the over modulation range is not allowed. 100% is the limit for the linear modulation. Six-step modulation requires the set value minimum of 113%

1504 Torque Stabilizer Damping Coefficient

The function of the torque stabilizer is to damp the speed oscillations, which occur especially at light loads, by damping the torque oscillations. This parameter defines the damping coefficient for the torque stabilizer. In general, the higher the inertia of the system with respect the motor torque, the lower the oscillations are in frequency and the closer the value should be 1000. The torque stabilizer affects directly the output frequency of the drive.

1505 Torque Stabilizer Gain At Aero Frequency

This parameter defines the additional gain of the torque stabilizer at the zero frequency. The actual gain at zero frequency is $(P2.9.2 + P2.9.3)$. The higher the gain, the stronger effect the stabilizer has at zero frequency. Too high gain may result in problems with stability.

1506 Torque Stabilizer Gain in FWP

This parameter defines the gain of the torque stabilizer at the field weakening point frequency. The gain changes linearly with the frequency between zero and the field weakening point frequency.

1507 Flux Stabilizer Gain

The flux stabilizer is used to damp the oscillations in motor magnetizing current part. This parameter defines the gain of the flux stabilizer. The flux stabilizer works like the torque stabilizer but affects directly the output voltage instead of the frequency. The higher the gain the stronger effect the stabilizer has. Too high gain may result in problems with stability.

1508 Voltage Stabilizer Damping Coefficient

Voltage stabilizer acts like the torque stabilizer preventing the speed from oscillating at light loads. The voltage stabilizer prevents speed oscillations by damping especially the DC-link voltage oscillations. The damping coefficient affects like the damping coefficient in a torque stabilizer. The voltage stabilizer affects also directly the output frequency of the drive.

1509 Voltage Stabilizer Gain

This parameter defines the voltage stabilizer gain at the light load. The gain is internally reduced when the torque increases. The higher the gain the stronger effect the stabilizer has. Too high gain may result in problems with stability. The actual gain is zero if the motor torque is higher than 50% of motor nominal torque.

1510 Voltage Stabilizer Limit

This parameter sets the limit for the voltage stabilizer output frequency.

1511 Advanced Options 1

By changing the value of this WORD -type variable is it possible to activate different bits of the Advanced Options1 variable.

	Advanced options 1
Sel.	
B0	Disable synchronous modulation
B1	Use encoder speed for slip compensation
B2	Disable encoder supervision
B3	Disable slip compensation for reverse direction
B4	Increase output frequency range up to 3900Hz
B5	Increment

1512 Synchronous / Asynchronous Modulation

In a synchronous modulation mode the ratio of the switching frequency and the drive output frequency i.e. the pulse number is an integer.

1513 Symmetrical / Asymmetrical Modulation

In a synchronous modulation mode it is also possible to use the symmetrical modulation. In this case, the ratio of the switching frequency and the drive output frequency i.e. the pulse number is restricted to certain values so that the motor voltages are more symmetrical and balanced. The actual switching frequency depends on the drive frequency and may change in steps and drop much below the switching frequency set value. Hence, there may be problems with motors having a sinus-filter, if too low switching frequency set value is used.

1514 Low Speed Option

This parameter has to be connected off (= value -1) when running over 100-150Hz otherwise may the motor operation go unstable. When running the motor under this frequency, the value can be changed between 2000 and 3000. In drives with internal optical communication link (Fr9 -> or Ch61 ->) it is recommended to use 3000 and with other units value 2000. Both ID1514 and ID1515 have to be switched off when not in use.

1515 Low Speed Option HW

Hardware based Low Speed Option, 0 = enabled, 1 = disabled
 The intention is to improve operation in low frequencies (<100Hz)
 The parameter is only usable with Fr10 and bigger, and CH61 and bigger.
 Both ID1514 and ID1515 have to be switched off when not in use.

1516 Advanced Options 2

By changing the value of this WORD -type variable is it possible to activate different bits of the Advanced Options 2 variable.

Advanced options 2	
Sel.	
B0	Sensor less control = 1
B1	1 = Master controlled Id-control in sync. master/follower. applications 0 = independent Id-control in master and followers
B2	Reserved
B3	Reserved
B4	PM motor; 1 = enable start-positioning damping
B5	Enable

1517 Advanced Options 4

By changing the value of this WORD -type variable is it possible to activate different bits of the Advanced Options 4 variable.

Advanced options 4	
Sel.	
B0	1 = activate roll-back prevention control
B1	1 = do PMSM start angle ID only once after power up
B2	1 = enable sin/cos interpolation (for sin/cos encoder testing)
B3	1 = enable dc-compensation (fast OL)

1518 Modulator Type

Advanced options 4	
Sel.	
0	Default PWM
1	Space Vector PWM

5.1 Keypad control parameters

Unlike the parameters listed above, these parameters are located in the **M3** menu of the control keypad. The reference parameters do not have an ID number.

114 **Stop button activated** (3.4, 3.6)

If you wish to make the Stop button a "hotspot" which always stops the drive regardless of the selected control place, give this parameter the value **1**.

See also parameter ID125.

125 **Control Place** (3.1)

The active control place can be changed with this parameter. For more information, see the product's User's Manual.

Pushing the *Start button* for 3 seconds selects the control keypad as the active control place and copies the Run status information (Run/Stop, direction and reference).

123 **Keypad Direction** (3.3)

0 Forward: The rotation of the motor is forward, when the keypad is the active control place.

1 Reverse: The rotation of the motor is reversed, when the keypad is the active control place.

For more information, see the product's User's Manual.

R3.2 **Keypad Reference** (3.2)

The frequency reference can be adjusted from the keypad with this parameter.

The output frequency can be copied as the keypad reference by pushing the *Stop button* for 3 seconds when you are on any of the pages of menu **M3**. For more information, see the product's User's Manual.

6. APPENDICES

In this chapter you will find additional information on special parameter groups. Such groups are:

- *Closed Loop parameters (Chapter 6.1)*
- *Advanced Open Loop parameters (Chapter 6.2)*
- *Parameters of Motor thermal protection (Chapter 6.3)*
- *Parameters of Stall protection (Chapter 6.4)*
- *Parameters of Underload protection (Chapter 6.5)*
- *Fieldbus control parameters (Chapter 6.6)*

6.1 Closed loop parameters (ID's 612 to 621)

Note: It is not possible to run >320Hz in Close Loop.

Select the Closed loop control mode by setting value **3** or **4** for parameter **ID600**.

Closed loop control mode (see page 37) is used when enhanced performance near zero speed and better static speed accuracy with higher speeds are needed. Closed loop control mode is based on "rotor flux oriented current vector control". With this controlling principle, the phase currents are divided into a torque producing current portion and a magnetizing current portion. Thus, the squirrel cage induction machine can be controlled in a fashion of a separately excited DC motor.

Note: These parameters can be used with Vacon NXP drive only.

EXAMPLE:

Motor Control Mode = 3 (Closed loop speed control)

This is the usual operation mode when fast response times, high accuracy or controlled run at zero frequencies are needed. Encoder board should be connected to slot C of the control unit. Set the encoder P/R-parameter (P7.3.1.1). Run in open loop and check the encoder speed and direction (V7.3.2.2). Change the direction parameter (P7.3.1.2) or switch the phases of motor cables if necessary. Do not run if encoder speed is wrong. Program the no-load current to parameter **ID612** and set parameter **ID619** (Slip Adjust) to get the voltage slightly above the linear U/f-curve with the motor frequency at about 66% of the nominal motor frequency. The Motor Nominal Speed parameter (**ID112**) is critical. The Current Limit parameter (**ID107**) controls the available torque linearly in relative to motor nominal current.

6.2 Advanced Open Loop parameters (ID's 622 to 625, 632, 635)

Select the Advanced Open Loop control mode by setting value **5** or **6** for parameter **ID600**.

The Advanced Open Loop control mode finds similar implementations as the Closed Loop control mode above. However, the control accuracy of the Closed Loop control mode is higher than that of the Advanced Open Loop control mode.

EXAMPLE:

Motor Control Mode = 5 Frequency control (Advanced open loop) and 6 Speed control (Advanced open loop)

The motor is running at current vector control at low frequencies. At frequencies above the frequency limit, the motor is in frequency control. The default current value is 120% at zero frequency. Use linear U/f-curve (**ID108**). 120% starting torque should now be possible. Sometimes increasing the frequency limit (**ID635**) will improve the run. The Frequency limit is the critical point. Increase the zero frequency point to get enough current at frequency limit.

6.3 Parameters of motor thermal protection (ID's 704 to 708):

General

The motor thermal protection is to protect the motor from overheating. The Vacon drive is capable of supplying higher than nominal current to the motor. If the load requires this high current there is a risk that the motor will be thermally overloaded. This is the case especially at low frequencies. At low frequencies the cooling effect of the motor is reduced as well as its capacity. If the motor is equipped with an external fan the load reduction at low speeds is small.

The motor thermal protection is based on a calculated model and it uses the output current of the drive to determine the load on the motor.

The motor thermal protection can be adjusted with parameters. The thermal current I_T specifies the load current above which the motor is overloaded. This current limit is a function of the output frequency.

The thermal stage of the motor can be monitored on the control keypad display. See the product's User's Manual.



CAUTION! *The calculated model does not protect the motor if the airflow to the motor is reduced by blocked air intake grill.*

6.4 Parameters of Stall protection (ID's 709 to 712):

General

The motor stall protection protects the motor from short time overload situations such as one caused by a stalled shaft. The reaction time of the stall protection can be set shorter than that of motor thermal protection. The stall state is defined with two parameters, [ID710 \(Stall current\)](#) and [ID712 \(Stall frequency limit\)](#). If the current is higher than the set limit and output frequency is lower than the set limit, the stall state is true. There is actually no real indication of the shaft rotation. Stall protection is a type of overcurrent protection.

6.5 Parameters of Underload protection (ID's 713 to 716):

General

The purpose of the motor underload protection is to ensure that there is load on the motor when the drive is running. If the motor loses its load there might be a problem in the process, e.g. a broken belt or a dry pump.

Motor underload protection can be adjusted by setting the underload curve with parameters [ID714](#) (Field weakening area load) and [ID715](#) (Zero frequency load), see below. The underload curve is a squared curve set between the zero frequency and the field weakening point. The protection is not active below 5Hz (the underload time counter is stopped).

The torque values for setting the underload curve are set in percentage which refers to the nominal torque of the motor. The motor's name plate data, parameter motor nominal current and the drive's nominal current I_H are used to find the scaling ratio for the internal torque value. If other than nominal motor is used with the drive, the accuracy of the torque calculation decreases.

6.6 Fieldbus control parameters (ID's 850 to 859)

The Fieldbus control parameters are used when the frequency or the speed reference comes from the fieldbus (Modbus, Profibus, DeviceNet etc.). With the Fieldbus Data Out Selection 1...8 you can monitor values from the fieldbus.

7. FAULT CODES

The fault codes, their causes and correcting actions are presented in the table below. The shadowed faults are A faults only. The items written in white on black background present faults for which you can program different responses in the application. See parameter group Protections.

Note: When contacting distributor or factory because of a fault condition, always write down all texts and codes on the keypad display.

Fault code	Fault	Possible cause	Correcting measures
1	Overcurrent	Frequency converter has detected too high a current ($>4 \cdot I_H$) in the motor cable: <ul style="list-style-type: none"> - sudden heavy load increase - short circuit in motor cables - unsuitable motor Subcode in T.14 : S1 = Hardware trip S2 = reserved S3 = Current controller supervision	<ul style="list-style-type: none"> - Check loading. - Check motor. - Check cables. - Make Identification run
2	Overvoltage	The DC-link voltage has exceeded the drive limit. See User manual. <ul style="list-style-type: none"> - Too short a deceleration time - high overvoltage spikes in supply Subcode in T.14 : S1 = Hardware trip S2 = Overvoltage control supervision	<ul style="list-style-type: none"> - Make the deceleration time longer. - Use brake chopper or brake resistor (available as options) - Activate over voltage controller. - Check input voltage
3	Earth fault	Current measurement has detected that the sum of motor phase current is not zero. <ul style="list-style-type: none"> - insulation failure in cables or motor 	- Check motor cables and motor.
5	Charging switch	The charging switch is open, when the START command has been given. <ul style="list-style-type: none"> - faulty operation - component failure 	<ul style="list-style-type: none"> - Reset the fault and restart. - Should the fault re-occur, contact your local distributor.
6	Emergency stop	Stop signal has been given from the option board.	- Check emergency stop circuit
7	Saturation trip	Various causes: <ul style="list-style-type: none"> - defective component - brake resistor short-circuit or overload 	<ul style="list-style-type: none"> - Cannot be reset from the keypad. - Switch off power. - DO NOT RE-CONNECT POWER! - Contact your local distributor. - If this fault appears simultaneously with Fault 1, check motor cables and motor
8	System fault	<ul style="list-style-type: none"> - component failure - faulty operation Note exceptional fault data record Subcode in T.14 : S1 = Reserved S2 = Reserved S3 = Reserved S4 = Reserved S5 = Reserved S6 = Reserved S7 = Charging switch S8 = No power to driver card S9 = Power unit communication (TX) S10 = Power unit communication (Trip) S11 = Power unit comm. (Measurement)	Reset the fault and restart. Should the fault re-occur, contact your local distributor.

Fault code	Fault	Possible cause	Correcting measures
9	Undervoltage	DC-link voltage is under the drive fault voltage limit. See user manual. <ul style="list-style-type: none"> – most probable cause: too low a supply voltage – frequency converter internal fault – One of input fuse is broken. – External charge switch have not been closed. Subcode in T.14 : S1 = DC-link too low during run S2 = No data from power unit S3 = Undervoltage control supervision	<ul style="list-style-type: none"> - In case of temporary supply voltage break, reset the fault and restart the frequency converter. - Check the supply voltage. - If it is adequate, an internal failure has occurred. - Check input fuses - Check DC charge function - Contact your local distributor.
10	Input line supervision	Input line phase is missing. Subcode in T.14 : S1 = Phase supervision diode supply S2 = Phase supervision active front end	Check supply voltage, fuses and cable.
11	Output phase supervision	Current measurement has detected that there is no current in one motor phase.	Check motor cable and motor.
12	Brake chopper supervision	<ul style="list-style-type: none"> – no brake resistor installed – brake resistor is broken – brake chopper failure 	<ul style="list-style-type: none"> - Check brake resistor and cabling. - If ok, the chopper is faulty. Contact your local distributor.
13	Frequency converter under-temperature	Heatsink temperature is under -10°C	
14	Frequency converter over-temperature	Heatsink temperature is over 90°C Overtemperature warning is issued when the heatsink temperature exceeds 85°C .	<ul style="list-style-type: none"> - Check the correct amount and flow of cooling air. - Check the heatsink for dust. - Check the ambient temperature. - Make sure that the switching frequency is not too high in relation to ambient temperature and motor load.
15	Motor stalled	Motor stall protection has tripped.	Check motor and load.
16	Motor over-temperature	Motor overheating has been detected by frequency converter motor temperature model. Motor is overloaded.	Decrease the motor load. If no motor overload exists, check the temperature model parameters.
17	Motor underload	Motor underload protection has tripped.	Check load.
18	Unbalance (Warning only)	Unbalance between power modules in paralleled units. Subcode in T.14 : S1 = Current unbalance S2 = DC-Voltage unbalance	Should the fault re-occur, contact your local distributor.
22	EEPROM checksum fault	Parameter save fault <ul style="list-style-type: none"> – faulty operation – component failure 	Should the fault re-occur, contact your local distributor.
24	Counter fault	Values displayed on counters are incorrect	Have a critical attitude towards values shown on counters.
25	Microprocessor watchdog fault	<ul style="list-style-type: none"> – faulty operation – component failure 	Reset the fault and restart. Should the fault re-occur, contact your local distributor.
26	Start-up prevented	- Start-up of the drive has been prevented.	- Cancel prevention of start-up if this can be done safely.

Fault code	Fault	Possible cause	Correcting measures
		- Run request is ON when new application is loaded to drive	- Remove Run Request.
29	Thermistor fault	The thermistor input of option board has detected too high a motor temperature	Check motor cooling and loading Check thermistor connection (If thermistor input of the option board is not in use it has to be short circuited)
31	IGBT temperature (hardware)	IGBT Inverter Bridge overtemperature protection has detected too high a short term overload current	- Check loading. - Check motor size. - Make identification Run
32	Fan cooling	Cooling fan of the frequency converter does not start, when ON command is given	Contact your local distributor.
34	CAN bus communication	Sent message not acknowledged.	Ensure that there is another device on the bus with the same configuration.
35	Application	Problem in application software	Contact your distributor. If you are application programmer check the application program.
37	Device changed (same type)	Option board or power unit changed. New device of same type and rating.	Reset. Device is ready for use. Old parameter settings will be used.
38	Device added (same type)	Option board added.	Reset. Device is ready for use. Old board settings will be used.
39	Device removed	Option board removed.	Reset. Device no longer available.
40	Device unknown	Unknown option board or drive. Subcode in T.14: S1 = Unknown device S2 = Power1 not same type as Power2	Contact the distributor near to you.
41	IGBT temperature	IGBT Inverter Bridge overtemperature protection has detected too high a short term overload current	- Check loading. - Check motor size. - Make Identification run
43	Encoder fault	Problem detected in encoder signals. Sub code in T.14: 1 =Encoder 1 channel A is missing 2 =Encoder 1 channel B is missing 3 =Both encoder 1 channels are missing 4 =Encoder reversed 5 =Encoder board missing	- Check encoder channel connections. - Check the encoder board. - Check encoder frequency in open loop
44	Device changed (different type)	Option board or power unit changed. New device of different type or different rating than the previous one.	Reset Set the option board parameters again if option board changed. Set converter parameters again if power unit changed.
45	Device added (different type)	Option board of different type added.	Reset Set the option board parameters again.
49	Div by zero in application	A division by zero has occurred in the application program.	Contact your distributor if fault accrues while frequency converter is in run state. If you are application programmer check the application program.
50	Analogue input $I_{in} < 4\text{mA}$ (sel. signal range 4 to 20 mA)	Current at the analogue input is $< 4\text{mA}$. - signal source has failed - control cable is broken or loose	Check the current loop circuitry.
51	External fault	Digital input fault.	- Remove fault situation from external device.
52	Keypad	The connection between the control	Check keypad connection and possible

Fault code	Fault	Possible cause	Correcting measures
	communication fault	keypad or NCDrive and the frequency converter is broken.	keypad cable.
53	Fieldbus fault	The data connection between the fieldbus Master and the fieldbus board is broken	Check installation. If installation is correct contact the nearest Vacon distributor.
54	Slot fault	Defective option board or slot	Check board and slot. Contact the nearest Vacon distributor.
56	PT100 board temp. fault	Temperature limit values set for the PT100 board parameters have been exceeded	Find the cause of temperature rise
57	Identification (Warning only)	Identification run have been failed	- Run command was removed before identification was ready - Motor is not connected to frequency converter. - There is load on motor shaft.
58	Brake	Actual status of the brake is opposite than control signal.	Check mechanical brake condition and connections.
59	Follower Communication	SystemBus or CAN communication is broken between master and follower	Check parameters from expanderboard and optical fibre or CAN cable.
60	Cooling	Liquid cooled drive cooling circulation have been failed	Check reason for cooling failure from external system.
61	Speed Error	Motor speed is not the same than reference.	-Check encoder connegtion - PMS motor has been gone over pull out torque.
62	Run Disable	- Run Enable signal is Low	- Check reason for Run Enable signal.
63	Emergency stop (Warning only)	Digital input or fieldbus have give command to make emergency stop	New run command is accepted after emergency stop is reset.
64	Input switch open	Drive input switch is opened	Check the main power switch of the drive.
72	Trial Time	Application is used without licence key. You have given too high frequency value as maximum frequency.	Contact Vacon factory to get licence key. Use application below 1700 Hz

Table 7-1. Fault codes

Vaasa

Vacon Oyj (Headquarters and Production)
Runsorintie 7, 65380 Vaasa
firstname.lastname@vacon.com
tel. +358 (0) 201 2121
fax: +358 (0) 201 212 205

Helsinki

Vacon Oyj
Äyritie 12, 01510 Vantaa
tel. +358 (0)201 212 600
fax: +358 (0)201 212 699

Tampere

Vacon Oyj
Alasniitynkatu 30, 33700 Tampere
tel. +358 (0)201 2121
fax: +358 (0)201 212 750

Rotatek Finland Oy

Laserkatu 6, 53850 Lappeenranta
tel. +358 (0)5 6243 870
fax: +358 (0)5 6243 871

Vacon Traction Oy

Alasniitynkatu 30, 33700 Tampere
tel. +358 (0)201 2121
fax: +358 (0)201 212 710

sales companies and representative offices:**Austria**

Vacon AT Antriebssysteme GmbH
Aumühlweg 21
2544 Leobersdorf
vacon.austria@vacon.com
tel. +43 2256 651 66
fax: +43 2256 651 66 66

Belgium

Vacon Benelux NV/SA
Interleuvenlaan 62
3001 Heverlee (Leuven)
info@vacon.be
tel. +32 (0)16 394 825
fax: +32 (0)16 394 827

France

Vacon France s.a.s.
Batiment le Sextant
462 rue Benjamin Delessert
ZI de Moissy Cramayel
BP 83
77 554 Moissy Cramayel
www.vacon-france.fr
tel. +33 (0)1 64 13 54 11
fax: +33 (0)1 64 13 54 21

Germany

Vacon GmbH
Gladbecker Str. 425
45329 Essen
tel. +49 (0)201/80670-0
fax: +49 (0)201/80670-93

Great Britain

Vacon Drives (UK) Ltd.
18 Maizefield
Hinckley Fields Industrial Estate
Hinckley
LE10 1YF Leicestershire
vacon.uk@vacon.com
tel. +44 (0)1455 611 515
fax: +44 (0)1455 611 517

Italy

Vacon S.p.A.
Via F.lli Guerra, 35
42100 Reggio Emilia
info@vacon.it
tel. +39 0522 276811
fax: +39 0522 276890

The Netherlands

Vacon Benelux BV
Weide 40, 4206 CJ Gorinchem
vacon.benelux@vacon.com
tel. +31 (0)183 642 970
fax: +31 (0) 183 642 971

Norway

Vacon AS
Langgata 2
3080 Holmestrand
vacon@vacon.no
tel. +47 330 96120
fax: +47 330 96130

PR China

Vacon Plc
Beijing Representative Office
A205, Grand Pacific Garden Mansion
8A Guanhua Road
Beijing 100026
www.vacon.com.cn
vacon.china@vacon.com
tel. +86 10 6581 3734
fax: +86 10 6581 3754

Russia

ZAO Vacon Drives
Bolshaja Jakimanka 31
stroenie 18
109180 Moscow
www.ru.vacon.com
tel. +7 (095) 974 1541
fax: +7 (095) 974 1554
ZAO Vacon Drives
2ya Sovetskaya 7, office 210A
191036 St. Petersburg
www.ru.vacon.com
tel. +7 (812) 332 1114
fax: +7 (812) 279 9053

Singapore

Vacon Plc
Singapore Representative Office
102F Pasir Panjang Road
#02-06 Citilink Warehouse Complex
Singapore 118530
vacon.singapore@vacon.com
tel. +65 6278 8533
fax: +65 6278 1066

Spain

Vacon Drives Ibérica S.A.
Miquel Servet, 2. P.I. Bufalvent
08240 Manresa
www.vacon.es
info@vacon.es
tel. +34 93 877 45 06
fax: +34 93 877 00 09

Sweden

Vacon AB
Torget 1
172 67 Sundbyberg
tel. +46 (0)8 293 055
fax: +46 (0)8 290 755

Vacon distributor: