

# SERVICE BULLETIN

Carrier Corporation



**Carrier**

A United Technologies Company

**Number:** C0313 (Revision 1)

**Date:** 10/13/05

**Supersedes:** 8/25/2003

**Title:** Replacing an IQ-1000 Motor Protection Relay with an MP-3000 Relay

**Author:** Ted Libera

**Dept:** CCS Technical Support

**Category:** General

## **MODELS AFFECTED:**

17 & 19 Series chillers with PIC I controls and Cutler-Hammer Starters.

## **SITUATION:**

From the mid-1990's until PIC II controls eliminated the need for overload relays in the starter, Cutler-Hammer used the IQ-1000 Motor Protection Relay as the overload device in the starters it supplied to Carrier. Because this device has many features other than overload protection, configuration information was published in bulletin C9632.

The IQ-1000 is no longer in production and has been replaced by the MP-3000 Motor Protection Relay. As with the IQ-1000, it has many functions, which must be configured. This bulletin gives the recommended configuration settings for that device. More complete information can be found in the manual packed with the MP-3000 relay and which can be downloaded as a PDF file from the Cutler-Hammer website.

## **WHEN ORDERING AN MP-3000**

The MP-3000 is available for use with current transformers having a nominal secondary current of either 5 amperes or 1 ampere. It is most likely that the current transformers in the starter will have a 5 amp secondary but it should be confirmed before ordering the relay.

For reliable motor protection with a 5 ampere CT set, the CT must deliver between 2.5 and 4 amperes at 100% RLA. For example, a 400:5 CT and 300 amps RLA:  $300 \text{ amps} \times 5/400 = 3.75$  amperes.

With a 1 ampere CT set, the CT must deliver between 0.5 and 0.8 amperes at 100% RLA. With a 400:1 CT and a 300 RLA motor:  $300 \times 1/400 = 0.75$  amps.

**FILE:** CONTROLS - WIRING

## **INSTALLATION :**

The connections between the starter and the MP-3000 are on the back of the MP-3000 and when it is installed in the starter, opening the starter enclosure door can access them. You will find that the terminal numbers used on the MP-3000 are the same as used on the IQ-1000 so changing wires from one to the other should be straightforward.

The IQ 1000 had a dedicated output assigned for the transition function and a discrete input assigned for incomplete sequence on transition. The MP-3000's inputs and outputs are user configurable for a variety of functions. If the Transition and Incomplete Sequence functions are enabled, then the input and output corresponding to the IQ 1000 configuration is assigned to these functions exclusively. These setting will keep the same wiring connections when replacing the IQ-1000 with an MP-3000

If the ground fault protection feature of the MP-3000 is used, terminals 15 and 16 are used as the ground fault trip contacts. Normally, they would be wired in series with the main trip contacts (terminals 12 & 13)

The alarm contacts are not used.

Terminals for the current transformers are located at the top rear of the MP-3000. The running current CT's are the leftmost six terminals and the ground fault CT connects to the right two terminals. The ratio of the current transformers should be given to the vendor when the relay is ordered.

On the IQ-1000 you will find a 25 $\Omega$  resistor between terminals 24 and 25. This resistor must be moved to the MP-3000 terminals 24 and 25. It converts a 4-20mA output to a voltage output that can be read by the SMM. It is the PIC motor current input.

Terminal 24 of the MP-3000 must connect to terminal 21 of the SMM and terminal 25 of the MP-3000 must connect to terminal 22 of the SMM.

Power to the MP-3000 is applied at terminals 4 (120/240 vac) and terminal 7 (neutral). Be careful not to connect to terminal 6. That is a 120vac source FROM the MP-3000 to read contacts connected to its discrete inputs. It is a 120 source whether 120 or 240 volts power the MP-3000.

## **Programming:**

Open the security door on the front of the MP-3000 and press the **Prog** button to put the relay into Program mode. The programming worksheet (filled in) follows in this bulletin to provide the configurations to enter. Use the Page and Line pushbuttons to navigate through the Program

mode, and the Value pushbuttons to change the setting values. You can see the page and line positions of the configurations on the worksheet.

The Help pushbutton provides a scrolling explanation of the displayed message, including units of measure, for any of the messages from the MP-3000.

It is Carrier policy to program the relay so that it cannot be reprogrammed while the motor is running. Line 6 of page 12 should be set to STOP PGM for this reason.

### **CALIBRATION OF THE PIC CONTROL:**

The Motor Current Setting on the chiller LID panel must be calibrated at two points: both with the machine not running and with the machine running at 70-100% RLA. This calibration must be performed because the MP-3000 creates a 4-20 mA signal, which must be converted (by RES1 25 Ohm resistor) to 0.1 to 0.5 volts to supply the proper signal to the SMM.

Some of the first 19XR/XRT chillers were shipped with Cutler-Hammer starters equipped with a 0.15 Ohm resistor (RES2, which is connected across terminals 21 and 22 by a 1M auxiliary contact as shown in Figure 1). The purpose of RES2 was to drop the voltage to the SMM to 0 so a Shunt Trip was not initiated. If this resistor is present, it must be removed from the circuit before calibration. It can be eliminated because after zero point calibration the PIC will interpret 0.1 volts as zero amps. The final production diagram with RES2 removed is shown in Figure 2.

#### **Zero Point calibration:**

Step 1. Make sure that the compressor rated load amps in the Service1 table is correct.

Step 2. Enter the Status1 table, highlight the amps value, and press SELECT. Press INCREASE or DECREASE to bring the amps value on the LID to 0. Press ENTER on the LID when completed.

#### **Range Point calibration (performed with machine running):**

Proceed according to the amps calibration procedure in the Start-Up Operation and Maintenance Instructions for the chiller.

### **NOTES:**

1. (Program page 1, line 5 & 6) All displayed information is the same for either of the two types of MP-3000 relays. When CT ratios are to be set, the value entered is the *numerator* of the main

CT ratio. The denominator is assumed to be 5 or 1, depending on the rating of the CTs and relay in use.


For example, a set of three 400:5 CT's might be used with an MP-3000 specified for 5A CTs. The phase CT ratio is then set to 400. Alternatively, a set of three 400:1 CTs could be used with an MP-3000 rated for 1 A CTs. Use a setting of 400 for this case as well.

2. (Program page 3, line 1) THE GROUND FAULT TRIP SETTING DOES NOT USE RLA AS THE BASIS FOR THE SETTING. This is different from the PIC controls, which do use RLA as the basis for this setting.

The Ground Fault Trip Level is set in percent of the ground CT numerator (CT rated primary current). For example, with a 50:5 ground fault CT and a setting of 24%, the GFT function will pick up at 24% of 50A or 12A actual ground fault current. The start and/or delays must expire before the trip occurs.

3. (Program page 3, line 4) If the starter is equipped with a circuit breaker set to OFF. Otherwise set it to the lower of 1600% or  $(1020 * PCT / RLA)$  where PCT is the Phase CT Ratio numerator (program page 1, line 5)





TD 17297B

IQ-1000 II






Figure 3

— Wiring Plan Drawing (partial plan)




— IQ-1000 II Rear Panel Terminals



Typical Ct Circuits and Motor Control Wiring

Figure 4



The following data is presented in the same order as in the Settings/Mode Worksheet as found in the MP-3000 Instruction Book.

VOLTS = Motor Nameplate voltage

FLA = Nameplate Rated Load Amps

LRC= Nameplate Locked Rotor Current at Delta

<i>Line No.</i>	<i>Display</i>	<i>Help Message</i>	<i>Selected Value</i>
<b>Page 1</b>	<b>SP MOTOR</b>	<b>SP MOTOR SETTINGS FOR MOTOR CONSTANTS</b>	
1	FLA XXX	FULL LOAD AMPS	RLA
2	LRC XXXX	LOCKED ROTOR CURRENT % OF FLA	(LRAD/LRA)/ 100
3	LRT XXX	MAXIMUM ALLOWABLE STALL TIME IN SECONDS	5
4	UTC XXX	ULTIMATE TRIP CURRENT IN % FLA	108
5	PCT XXX	PHASE CT NUMERATOR IN PRIMARY AMP	See note 1
6	GCT XXXX	GROUND CURRENT RATIO NUMERATOR IN PRIMARY AMP	See note 1
7	FREQ XX	50 OR 60 HERTZ LINE FREQUENCY	PER LOCATION
8	REV OR NON-REV	REVERSING OR NON REVERSING STARTER	NONREV
<b>Page 2</b>	<b>SP RTD</b>	<b>SETTINGS FOR RTD INPUTS</b>	
1	RTD IN C RTD IN F	DISPLAYED IN DEGREES C OR F	NON APPLICABLE
2	WD T XXX	WINDING TEMP TRIP	OFF
3	WD A XXX	WINDING TEMP ALARM	OFF
4	MB T XXX	MOTOR BEARING TRIP	OFF
5	MB A XXX	MOTOR BEARING ALARM	OFF
6	LB T XXX	LOAD BEARING TRIP	OFF
7	LB A XXX	LOAD BEARING ALARM	OFF
8	AX T XXX	AUXILIARY TRIP	OFF
9	AX A XXX	AUXILIARY ALARM	OFF
10	DIAG ON DIAG OFF	ALARM ON FAILURE DIAGNOSTIC	DIAG OFF

<b>Page 3</b>			
<b>SP TRIP</b>		<b>SETTINGS FOR TRIP EVENTS</b>	
1	GFT XXX	GROUND FAULT TRIP LEVEL IN % OF GROUND CT RATIO NUMERATOR	<b>24%</b> <b>See note 2</b>
2	GFSD XX	GROUND FAULT START DELAY IN CYCLES	<b>5</b>
3	GFRD XX	GROUND FAULT RUN DELAY IN CYCLES	<b>5</b>
4	IOC XXXX	INSTANTANEOUS OVERCURRENT IN % FLA	<b>See note 3</b>
5	IOCSX XX	INSTANTANEOUS OVERCURRENT START DELAY IN CYCLES	<b>2</b>
6	JMT XXX	JAM TRIP LEVEL IN % FLA	<b>OFF</b>
7	JMSD XXX	JAM TRIP AND ALARM START DELAY IN SECONDS	<b>1200</b>
8	JMTR XXX	JAM TRIP RUN DELAY IN SECONDS	<b>240</b>
9	ULT XXX	UNDERLOAD TRIP LEVEL IN % FLA	<b>OFF</b>
10	ULSD XXX	UNDERLOAD TRIP AND ALARM STAART DELAY IN SECONDS	<b>60</b>
11	ULTR XXX	UNDERLOAD TRIP RUN DELAY IN SECONDS	<b>11</b>
12	UBT XXX	PHASE UNBALANCE TRIP LEVEL	<b>20%</b>
13	UBSD XXX	PHASE UNBALANCE TRIP AND ALARM START DELAY IN SECONDS	<b>5</b>
14	UBTR XXX	PHASE UNBALANCE TRIP RUN DELAY IN SECONDS	<b>5</b>
<b>Page 4</b>			
<b>SP ALARM</b>		<b>SETTINGS FOR ALARM EVENTS</b>	
1	GFA XXX	GROUND FAULT ALARM LEVEL IN % OF GROUND CT RATIO NUMERATOR	<b>OFF</b>
2	I2TA XXX	I2T ALARM LEVEL IN % FULL OF I2T TRIP CAPACITY	<b>OFF</b>
3	JMA XXX	JAM ALARM LEVEL IN % FLA	<b>OFF</b>
4	JMAR	JAM ALARM RUN DELAY IN SECONDS	<b>OFF</b>
5	ULA XXX	UNDERLOAD ALARM LEVEL IN % FLA	<b>OFF</b>
6	ULAR XXX	UNDERLOAD ALARM RUN DELAY IN SECONDS	<b>OFF</b>
7	UBA XXX	PHASE UNBALANCE ALARM LEVEL	<b>OFF</b>
8	UBAR XXX	PHASE UNBALANCE ALARM RUN DELAY IN SECONDS	<b>10</b>
<b>Page 5</b>			
<b>SP START</b>		<b>SETTINGS FOR START EVENTS</b>	
1	ST/T XXX	STARTS PER TIME ALLOWED	<b>1</b>
2	TS/T XXX	TIME ALLOWED FOR STARTS COUNT IN SECONDS	<b>OFF</b>
3	TBS XXX	TIME BETWEEN STARTS IN MINUTES	<b>OFF</b>
4	NOCS X	NUMBER OF COLD STRTS ALLOWED	<b>5</b>

5	TRNC XXX	MOTOR START TRANSITION CURRENT LEVEL IN % FLA	<b>50</b>
6	TRNT XXX	MOTOR START TRANSITION TIME IN SECONDS	<b>10</b>
7	Choose transition type	TRN T/C ON TIME AND CUTTENT	<b>TRN T/C</b>
8	INSQ XXX	INCOMPLETE SEQUENCE REPORT BACK TIME IN SECONDS ON DISCRETE INPUT 2	<b>2</b>
9	INSQ TRN Or INSQ ST	INCOMPLETE SEQUENCE START TIMER EVENT INSQ TRN – START TO RUN TRANSITION	<b>INSQ TRN</b>
10	LAT XXX	LONG ACCELERATION TIME IN SECONDS <b>DO NOT TURN THIS ON. THIS FUNCTION IS CAPABLE OF BLOCKING THERMAL PROTECTION DURING A START AND DESTROYING THE MOTOR</b>	<b>OFF</b>
11	ZSW ON Or ZSW OFF	ZERO SPEED SWITCH ON DISCREETTE INPUT 1 ON OR OFF	<b>ZSW OFF</b>
12	ABK XXXX	ANTI-BACKSPIN DELAY TIME IN SECONDS	<b>OFF</b>
<b>Page 6</b>	<b>SP DI 1</b>	<b>SETTING FOR DISCRETE INPUT NUMBER 1</b>	
1	Choose REM TRIP	CONFIGURE DISCRETE INPUT 1 REM TRIP – REMOTE TRIP	<b>REM TRIP</b>
<b>Page 7</b>	<b>SP DI 2</b>	<b>SETTING FOR DISCRETE INPUT NUMBER 2</b>	
1	Choose INC SEQ	CONFIGURE DISCRETE INPUT 2 INCSEQ- INCOMPLETE SEQUENCE	<b>INC SEQ</b>
<b>Page 8</b>	<b>SP AREL</b>	<b>SETTING FOR ALARM RELAY OUTPUT CONFIGURATION</b>	
1	GF A ON GF T ON Or GF OFF	ENABLE GROUND FAULT ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>GF OFF</b>
2	I2T A ON I2T T ON or I2T OFF	ENABLE I2T ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>I2T OFF</b>
3	JAM A ON JAM T ON Or JAM OFF	ENABLE JAM ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>JAM OFF</b>

4	UL A ON UL T ON Or UL OFF	ENABLE UNDERLOAD ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>UL OFF</b>
5	B A ON UB T ON Or UB OFF	ENABLE PHASE UNBALANCE ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>UB OFF</b>
6	WD A ON WD T ON Or WD OFF	ENABLE WINDING TEMP ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>WD OFF</b>
7	MB A ON MB T ON Or MB OFF	ENABLE MOTOR BEARING ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>MB OFF</b>
8	LB A ON LB T ON Or LB OFF	ENABLE LOAD BEARING ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>LB OFF</b>
9	AX A ON AX T ON Or AX OFF	ENABLE AUXILIARY RTD TEMP ALARM OR TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>AX OFF</b>
10	SX A ON SX T ON Or SX OFF	ENABLE STARTS PER TIME TRIP OR ALARM TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>SX OFF</b>
11	BS T ON Or TBS OFF	ENABLE TIME BETWEEN STARTS TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>TBS OFF</b>
12	RTDF ON Or RTDF OFF	ENABLE INDIVIDUAL RTD CHANNEL FAILURE TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>RTDF OFF</b>

13	RCOM ON Or RCOM OFF	ENABLE RTD MODULE COMMUNICATION FAILURE TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>RCOM OFF</b>
14	IOCT OFF Or IOCT OFF	ENABLE INSTANTANEOUS TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>IOCT OFF</b>
15	PH R ON Or PH R OFF	ENABLE PHASE REVERSAL TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>PHR OFF</b>
16	INSQ ON Or INSQ OFF	ENABLE INCOMPLETE SEQUENCE TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>INSQ OFF</b>
17	REMT ON Or REMT OFF	ENABLE REMOTE TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>REMT OFF</b>
18	DIFT ON Or DIFT OFF	ENABLE DIFFERENTIAL TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>DIFT OFF</b>
19	INCT ON Or INCT OFF	ENABLE INCOM TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>INCT OFF</b>
20	TRNT ON Or TRNT OFF	ENABLE TRANSITION TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>TRNT OFF</b>
21	ZSWT ON Or ZSWT OFF	ENABLE ZERO SPEED SWITCH TRIP TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>ZSWT OFF</b>
22	TBYP ON Or TBYP OFF	ENABLE TRIP BYPASS TO ACTIVATE ALARM RELAY OUTPUT OR DISABLE	<b>TBYP OFF</b>
<b>Page 9</b>	<b>SP AUX1</b>	<b>SETTINGS FOR AUX1 RELAY OUTPUT CONFIGURATION</b>	
1	LSPU XXX	LOAD SHED PICK-UP CURRENT AS % OF FLA	<b>OFF</b>
2	LSDO XXX	LOAD SHED DROP-OUT CURRENT AS % OF FLA	<b>OFF</b>
3	LSDL XX	LOAD SHED DELAY IN SECONDS	<b>1</b>

4	GF A ON GF T ON Or GF OFF	ENABLE GROUND FAULT ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>GF OFF</b>
5	I2T A ON I2T T ON Or I2T OFF	ENABLE I2T ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>I2T T ON</b>
6	JAM A ON JAM T ON Or JAM OFF	ENABLE JAM ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>JAM OFF</b>
7	UL A ON UL T ON Or UL OFF	ENABLE UNDERLOAD ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>UL OFF</b>
8	UB A ON UB T ON Or UB OFF	ENABLE PHASE UNBALANCE ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>UB T ON</b>
9	WD A ON WD T ON Or WD OFF	ENABLE WINDING TEMP ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>WD OFF</b>
10	MB A ON MB T ON Or MB OFF	ENABLE MOTOR BEARING TEMP ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>MB OFF</b>
11	LB A ON LB T ON Or LB OFF	ENABLE LOAD BEARING TEMP ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>LB OFF</b>
12	AX A ON AX T ON Or AX OFF	ENABLE AUXILIARY RTD TEMP ALARM OR TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>AX OFF</b>

13	SX A ON SX T ON Or SX OFF	ENABLE STARTS PER TIME TRIP OR ALARM TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>SX OFF</b>
14	TBS T ON Or TBS OFF	ENABLE TIME BETWEEN STARTS TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>TBS OFF</b>
15	RTDF ON Or RTDF OFF	ENABLE RTD FAILURE DIAGNOSTIC TO ACTIBATE AUX1 RELAY OUTPUT OR DISABLE	<b>RTDF OFF</b>
16	RCOM ON Or RCOM OFF	ENABLE RTD MODULE COMMUNICA-TION FAILURE TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>RCOM OFF</b>
17	IOCT ON Or IOCT OFF	ENABLE INSTANTANEOUS OVERCURRENT TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>IOCT ON</b>
18	PH R ON Or PH R OFF	ENABLE PHASE REVERSAL TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>PR R OFF</b>
19	INSQ ON Or INSQ OFF	ENABLE INCOMPLETE SEQUENCE TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>INSQ OFF</b>
20	REMT ON Or REMT OFF	ENABLE REMOTE TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>REMT OFF</b>
21	DIFT ON Or DIFT OFF	ENABLE DIFFERENTIAL TRIP TO ACTI-VATE AUX1 RELAY OUTPUT OR DISABLE	<b>DIFT OFF</b>
22	INCT ON Or INCT OFF	ENABLE INCOM TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>INCT OFF</b>
23	TRNT ON Or TRNT OFF	ENABLE TRANSITION TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>TRNT OFF</b>

24	ZSWT ON Or ZSWT OFF	ENABLE ZERO SPEED SWITCH TRIP TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>ZSWT OFF</b>
25	TBYP ON Or TBYP OFF	ENABLE TRIP BYPASS TO ACTIVATE AUX1 RELAY OUTPUT OR DISABLE	<b>TBYP OFF</b>
<b>Page 10</b>	<b>SP AUX2</b>	<b>SETTINGS FOR AUX2 RELAY OUTPUT CONFIGURATION</b>	
1	TRN ON Or TRN OFF	ENABLE TRANSITION OUTPUT IF ENABLED ALL OTHER FUNCTIONS FOR AUX 2 ARE DISABLED	<b>TRN ON</b>
2	GF A ON GF T ON Or GF OFF	ENABLE GROUND FAULT ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>GFT ON</b>
3	12T A ON 12T T ON or 12T OFF	ENABLE 12T ALARM OR TRIP TO ACTI-VATE AUX2 RELAY OUTPUT OR DISABLE	<b>12T OFF</b>
4	JAM A ON JAM T ON Or JAM OFF	ENABLE JAM ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>JAM OFF</b>
5	UL A ON UL T ON Or UL OFF	ENABLE UNDERLOAD ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>UL OFF</b>
6	UB A ON UB T ON Or UB OFF	ENABLE PHASE UNBALANCE ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>UB OFF</b>
7	WD A ON WD T ON Or WD OFF	ENABLE WINDING TEMP ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>WD OFF</b>

8	MB A ON MB T ON Or MB OFF	ENABLE MOTOR BEARING TEMP ALARM OR TRIP TO ACTIVATE AUS2 RELAY OUTPUT OR DISABLE	<b>MB OFF</b>
9	LB A ON LB T ON Or LB OFF	ENABLE LOAD BEARING TEMP ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>LB OFF</b>
10	AX A ON AX T ON Or AX OFF	ENABLE AUXILIARY RTD TEMP ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>AX OFF</b>
11	SX A ON SX T ON Or SX OFF	ENABLE STARTS PER TIME TRIP OR ALARM TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>SX OFF</b>
12	TBS T ON Or TBS OFF	ENABLE TIME BETWEEN STARTS TRIP OR TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>TBS OFF</b>
13	RTDF ON Or RTDF OFF	ENABLE RTD FAILURE DIAGNOSTIC TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>RTDF OFF</b>
14	RCOM ON Or RCOM OFF	ENABLE RTD MODULE COMMUNICA-TION FAILUR TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>RCOM OFF</b>
15	IOC A ON IOC T ON Or IOC OFF	ENABLE INSTANTANEOUS OVERCURRENT ALARM OR TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>IOCT OFF</b>
16	PH R ON Or PH R OFF	ENABLE PHASE REVERSAL TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>PH R OFF</b>
17	INSQ ON Or INSQ OFF	ENABLE INCOMPLETE SEQUENCE TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>INSQ OFF</b>

18	REMT ON Or REMT OFF	ENABLE REMOTE TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>REMT OFF</b>
19	DIFT ON Or DIFT OFF	ENABLE DIFFERENTIAL TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>DIFT OFF</b>
20	INCT ON Or INCT OFF	ENABLE INCOM TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>INCT OFF</b>
21	TRNT ON Or TRNT OFF	ENABLE TRANSITION TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>TRNT OFF</b>
22	ZSWT ON Or ZSWT OFF	ENABLE ZERO SPEED SWITCH TRIP TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>ZSWT OFF</b>
23	TBYP ON Or TBYP OFF	ENABLE TRIP BYPASS TO ACTIVATE AUX2 RELAY OUTPUT OR DISABLE	<b>TBYP OFF</b>
<b>Page 11</b>	<b>SP A OUT</b>	<b>SETTING FOR ANALOG OUTPUT CONFIGURATION</b>	
1	MAX 100 MAX 125 MAX WRTD MAX %12T	4-20 MA OUTPUT MAX 100 – 20 MA FOR 100% FLA MAX 125 – 20 MA FOR 125% FLA MAX WRTD – 20 MA FOR TRIP LEVEL MAX %12T – 20 MA FOR 100% 12T	<b>MAX 125</b>
<b>Page 12</b>	<b>SP SYS</b>	<b>SETTING FOR SYSTEM CONFIGURATION</b>	
1	TP MODE X	CONFIGURE TRIP RELAY OUTPUT TO BE MODE 1 – TRIP RELAY ENERGIZES ON TRIP EVENT OR MODE 2 – TRIP RELAY ENERGIZES ON POWER UP AND DE-ENERGIZES ON TRIP EVENT	<b>MAX 125</b>
2	AL MODE X	CONFIGURE ALARM RELAY OUTPUT TO BE MODE 1 – ALARM RELAY ENERGIZES ON ALARM EVENT OR MODE 2 – ALARM RELAY ENERGIZES ON POWER UP AND DE-ENERGIZES ON ALARM EVENT	<b>TP MODE 2</b>
3	AX1 MOD X	CONFIGURE AUX1 RELAY OUTPUT TO BE MODE 1 – AUX 1 RELAY ENERGIZES ON AUX1 EVEN OR MODE 2 – AUX1 RELAY ENERGIZES ON POWER UP AND DE-ENERGIZES ON AUX1 EVENT	<b>AX1 MODE 2</b>

4	AX2 MOD X	CONFIGURE AUX2 RELAY OUTPUT TO BE MODE 1 – AUX2 RELAY ENERGIZES ON AUX2 EVENT OR MODE 2 – AUX2 RELAY ENERGIZES ON POWER UP AND DE-ENERGIZES ON AUX2 EVENT	<b>AX2 MODE 1</b>
5	MAN 12T Or AUTO 12T	AUTO OR MANUAL 12T RESET	<b>MAN 12T</b>
6	RUN PGM Or STOP PGM	ENABLES UNIT TO BE PROGRAMMED WHILE MOTOR IS RUNNING	<b>STOP PGM</b>
8	12 HOUR or 24 HOUR	SET REAL TIME CLOCK DISPLAY 12 HOUR – AM/PM TIME DISPLAYED 13 24 HOUR – 24 HOUR TIME DISPLAYED	<b>12 HOUR</b>
9	MONTH XX	SET REAL TIME CLOCK MONTH	
10	DAY XX	SET REAL TIME CLOCK DAY	
11	YEAR XX	SET REAL TIME CLOCK YEAR	
12	HOUR XX	SET REAL TIME CLOCK HOUR	
13	MIN XX	SET REAL TIME CLOCK MINUTE	
14	M D Y Or D M Y	SET REAL TIME DATE DISPLAY MONTH DAY YEAR OR DAY MONTH YEAR	
15	IQ2 EN Or IQ2 DIS	EMPACC COMMUNICATION MODE IQ2 EN – IQ1000II EMULATION IQ2 DIS – MP-3000 COMMUNICATION	<b>I2T EN</b>
16	RLYF TRP RLYF ALM Or RLYF T+A	INTERNAL DIAGNOSTIC FAILURE ACTIVATES TRIP AND OR ALARM RELAY	<b>RLYF T+A</b>
17	INCT DIS Or INCT EN	INCOM TRIP DISABLED OR ENABLED	<b>INCT DIS</b>
18	DISARMED Or ARMED	ARM OR DISARM TRIP RELAY WARNING DISARM WILL NOT ALLOW TRIP RELAY TO FUNCTION TRIP WARNING MP-3000 WILL BE DISARMED UPON EXIT OF PROGRAM MODE AND WILL NOT PROTECT THE MOTOR-ENTER ARMED INTO SETTING TO PROTECT THE MOTOR	<b>ARMED</b>

<b>Page 13</b>	<b>SP TEST</b>	<b>SETTINGS FOR TESTING INPUTS AND OUTPUTS</b>	
1	3 PHASE or 1 PHASE	SINGLE PHASE TEST MODE OR THREE PHASE PROTECTION MODE	<b>3-PHASE</b>