




# Installation – Electrical Information

---

## Water-Cooled CenTraVac™ With CH530



### Required Installation Information:

CVHE-SVN01A-EN – General Information

CVHE-SVN02A-EN – Piping Information

CVHE-SVN03A-EN – Electrical Information



# Warnings and Cautions

---

## Notice

Warnings and Cautions appear at appropriate locations throughout this manual.

Read these carefully.

**Warning:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**Caution:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices and where property-damage-only accidents could occur.

## Contents

---

<b>Warnings and Cautions</b>	<b>2</b>
<b>General Requirements</b>	<b>4</b>
<b>Adaptive Frequency Drive Option</b>	<b>4</b>
<b>Field Wiring Requirements</b>	<b>5</b>
<b>Power Supply Wiring</b>	<b>6</b>
<b>3-Phase Power Source</b>	<b>6</b>
<b>Circuit Breakers and Fusible Disconnects</b>	<b>6</b>
<b>Optional PFCCs</b>	<b>7</b>
<b>Interconnecting Wiring</b>	<b>8</b>
<b>Starter to Motor (Remote-Mounted Starters Only)</b>	<b>10</b>
<b>Starter to UCP (Remote-Mounted Starters Only)</b>	<b>10</b>
<b>UCP Electrical Specifications</b>	<b>10</b>
<b>Water Pump Interlock Circuits &amp; Flow Switch Input</b>	<b>12</b>
<b>Temperature Sensor Circuits</b>	<b>13</b>
<b>Optional Relay Circuits</b>	<b>13</b>
<b>Optional Tracer Communication Interface</b>	<b>13</b>
<b>Unit Start-Up</b>	<b>13</b>
<b>Forms Information</b>	<b>13</b>
<b>Schematic Wiring Drawing List</b>	<b>15</b>
<b>Legend</b>	<b>51</b>
<b>Field Wiring Layout</b>	<b>52</b>
<b>Connection Diagrams</b>	<b>54</b>

# Electrical Information

---

**Note:** Unit-mounted starters are available as an option on most CVHE, CVHF, and CVHG units with wye delta, and solid-state starters, with nominal voltages of up to 600 volts and unit mounted medium voltage across-the-line starters..

While this option eliminates most field-installed wiring requirements, the electrical contractor must still complete the electrical connection for: (1) Power supply wiring to the starter, (2) Other unit control options present, and (3) Any field-supplied control devices.

## General Requirements

### **⚠ WARNING**

#### **HAZARDOUS VOLTAGE!**

**Use extreme caution when measurements, adjustments, or other service-related work is performed with power on. Failure to use caution could cause death or serious injury.**

### **⚠ WARNING**

#### **ROTATING PARTS!**

**Use extreme caution when measurements, adjustments, or other service-related work is performed with power on. Failure to use caution could cause death or serious injury.**

As you review this manual, along with the wiring instructions presented in this section, keep in mind that:

Typical field connection requirements for remote-mounted starters are shown at the end of the manual, and summarized in Table 1.

All field-installed wiring must conform to National Electric Code (NEC) guidelines, as well as to any applicable state and local codes. Be sure to satisfy proper equipment grounding requirements per NEC.

All field-installed wiring must be checked for proper terminations, and for possible shorts or grounds.

**Note:** The typical customer connection diagrams shown in this manual are representative of standard CVHE, CVHF and CVHG units, and are provided only for general reference. Always refer to the actual wiring diagrams that shipped with the chiller for specific as built electrical schematic and connection information.

## Adaptive Frequency Drive Option

The following information is recommended when installing a drive.

Do not modify or cut Adaptive Frequency Drive enclosure to provide electrical access. Removable panels have been provided for this purpose. Modify these panels only; away from enclosure. Refer to installation information shipped with the adjustable frequency drive or submittal drawings.

### **CAUTION**

**TO AVOID DAMAGE TO STARTER COMPONENTS, remove debris inside the starter panel. Failure to do so may cause an electrical short that seriously damages the starter components.**

# Electrical Information

**Table 1 – CVHE, CVHF, and CVHG Standard and Optional Field Wiring Requirements**

<b>Power Supply wiring (to Starter Panel)</b> Standard wiring: (To Terminal Block) (2X3) 3-Phase Power Supply Starter and Motor Junction Box Interconnection (Remote starter only)	<b>Starter Panel Terminals</b>  2X3-L1, L2, L3, GROUND T1 thru T6, GROUND (as applicable by starter type)		
<b>Alternate Wiring:</b> (To Circuit Breaker) (2Q1)	2Q1-L1,L2,L3, GROUND		
<b>Starter to UCP 120VAC control wiring</b>	<b>Starter Panel Terminals</b>	<b>Unit Control Panel Terminations</b>	
120VAC Power Supply	2X1-1, 2X1-2, GROUND	1X1-1, 1X1-12	
High Pressure Cutout (3S1)	2X1-4, 2X1-6	1X1-4, 1X1-3	
Oil Pump Interlock (2K11)	2X1-7, 2X1-8	1A7-J2-4, 1A7-J2-2	
<b>UCP Control Wiring (120 VAC)</b>	<b>Unit Control Panel Terminations</b>	<b>Input or Output Type</b>	<b>Contacts</b>
<b>Standard Circuits:</b>			
Chilled Water Flow Proving Input (5S1)	1X1-5 to 1A6-J3-2	Binary Input	Normally Open, closure with flow
Condenser Water Flow Proving Input (5S2)	1X1-6 to 1A6-J2-2	Binary Input	Normally Open, closure with flow
Chilled Water Pump Relay Output	1A5-J2- 4 to 6	Binary Output	Normally Open
Condenser Water Pump Relay Output	1A5-J2-1 to 3	Binary Output	Normally Open
<b>Optional Circuits</b>			
Alarm Relay MAR (Non-Latching) Output	1A8-J2-1 to 3	Binary Output	Normally Open
Limit Warning Relay Output	1A8-J2-4 to 6	Binary Output	Normally Open
Alarm Relay MMR (Latching) Output	1A8-J2-7 to 9	Binary Output	Normally Open
Compressor Running Relay Output	1A8-J2-10 to 12	Binary Output	Normally Open
Maximum Capacity Relay Output	1A9-J2-1 to 3	Binary Output	Normally Open
Head Relief Request Relay Output	1A9-J2-4 to 6	Binary Output	Normally Open
Purge Alarm Relay Output	1A9-J2-7 to 9	Binary Output	Normally Open
Ice Making Relay Output	1A10-J2-4 to 6	Binary Output	Normally Open
Free Cooling Relay Output	1A11-J2-4 to 6	Binary Output	Normally Open
<b>Low Voltage Circuits (less than 30 VAC)</b>	<b>Unit Control Panel Terminations</b>	<b>Input or Output Type</b>	
<b>Standard Circuits</b>			
External Auto Stop Input	1A13-J2-1 to 2	Binary Input	Closure required for normal operation
Emergency Stop Input	1A13-J2-3 to 4	Binary Input	Closure required for normal operation
<b>Optional Circuits</b>			
External Base Loading Enable Input	1A18-J2-1 to 2	Binary Input	Normally Open
External Hot Water Control Enable Input	1A18-J2-3 to 4	Binary Input	Normally Open
External Ice Machine Control Enable Input	1A19-J2-1 to 2	Binary Input	Normally Open
Free Cooling Input Enable Input	1A20-J2-1 to 2	Binary Input	Normally Open
RLA Compressor Output	1A15-J2-1 to 3	Analog Output	2-10 vdc, or 4-20 mA
External Condenser Pressure Output or Refrigerant Differential Pressure output	1A15-J2-4 to 6	Analog Output	2-10 vdc, or 4-20 mA
External Current Limit Setpoint Input	1A16-J2-2 to 3	Analog Input	2-10 vdc, or 4-20 mA
External Chilled Water Setpoint	1A16-J2-5 to 6	Analog Input	2-10 vdc, or 4-20 mA
External Base Load Setpoint Signal	1A17-J2-2 to 3	Analog Input	2-10 vdc, or 4-20 mA
Generic Refrigerant Monitor Input	1A17-J2-4 to 6	Analog Input	2-10 vdc, or 4-20 mA
Outdoor Air Temperature sensor	IPC bus Connection and sensor	Communication and sensor.	

# Electrical Information

## Power Supply Wiring

To assure that power supply wiring to the starter panel is properly installed and connected, review and follow the guidelines outlined below.

### 3-Phase Power Source

1. Verify that the starter nameplate ratings are compatible with the power supply characteristics and with the electrical data on the unit nameplate.
2. If the starter enclosure must be cut to provide electrical access, exercise care to prevent debris from falling inside the enclosure. If the starter cabinet has a removable panel, be sure to remove the panel from the unit before drilling holes.

### CAUTION

**TO AVOID DAMAGE TO STARTER COMPONENTS**, remove debris inside the starter panel. Failure to do so may cause an electrical short that seriously damages the starter components.

3. Use copper conductors to connect the 3-phase power supply to the remote or unit-mounted starter panel.

### CAUTION

**USE ONLY COPPER CONDUCTORS FOR TERMINAL CONNECTIONS.** Failure to do so may cause corrosion or overheating, and starter damage.

4. Size the power supply wiring in accordance with the Minimum Circuit Ampacity (MCA) shown on the unit nameplate. (MCA = (RLA × 1.25) + Control Power Load)
5. Make sure that the incoming power wiring is properly phased; each power supply conduit run to the starter must carry the correct number of conductors to ensure equal phase representation. See Figure 1.

6. As you install the power supply conduit, make sure that this position does not interfere with the serviceability of any of the unit components, nor with structural members and equipment.


Also, assure that the conduit is long enough to simplify any servicing that may be necessary in the future (e.g., starter removal).

**Note:** Use flexible conduit to enhance serviceability and minimize vibration transmission.

### Circuit Breakers and Fusible Disconnects

Size the circuit breaker or fuse disconnect in compliance with NEC or local guidelines.

*Figure 1 – Proper Phasing for Starter Power Supply Wiring and Conduit Loading*



# Electrical Information

## Optional PFCCs

Power factor correction capacitors (PFCCs) are designed to provide power factor correction for the compressor motor. They are available as an option.

**Note:** Remember that the PFCC nameplate voltage rating must be greater than or equal to the compressor voltage rating stamped on the unit nameplate. See Table 2 to determine what PFCC is appropriate for each compressor voltage application.


### CAUTION

**PFCCS MUST BE WIRED INTO THE STARTER CORRECTLY! Failure to do so may cause misapplication of these capacitors and result in a loss of motor overload protection and subsequently cause motor damage.**

**Table 2 – PFCC Design Voltage Sizing per Compressor Voltage Application**

PFCC Design Voltage	Compressor Motor Rating (See Unit Nameplate)
240/60 Hz	208V/60 Hz
480V/60 Hz	380V/60 Hz 440V/60 Hz 460V/60 Hz 480V/60 Hz
600V/60 Hz	575V/60 Hz 600V/60 Hz
2400V/60 Hz	2300V/60 Hz 2400V/60 Hz
PFCC Rating	Compressor Motor Rating (See Unit Nameplate)
480V/50 Hz	346V/50 HZ 380V/50 HZ 400V/50 Hz 415V/50 Hz
4160V/60 Hz	3300V/60 Hz 4160V/60 Hz

**Figure 2 – PFCC Leads Routed through Overload Current Transformer**



**Note:** See the attached wiring diagram for more detail.


# Electrical Information

## Interconnecting Wiring

Typical equipment room conduit layouts with and without unit-mounted starters are shown in Figures 3 and 4, respectively.

Keep in mind that the interconnecting wiring between the starter panel, compressor and UCP control panel is factory-installed with unit-mounted starters but must be field-installed when a remote-mounted starter is used.


**Figure 3 – Typical Equipment Room Layout with Unit-Mounted, Wye-Delta**



**Note:**  
See Starter submittal drawing for location of incoming wiring to the starter.

# Electrical Information

**Figure 4 – Typical Equipment Room Layout with Remote-Mounted Wye-Delta Starter**



**Notes:**

1. Refer to the unit field connection diagram for approximate UCP knockout locations.
2. 115-volt conduit must enter the higher than 30 Vdc Class I portion of the unit control panel.
3. IPC circuit conduit must enter the Low Voltage Class II portion of the UCP.
4. See starter submittal drawing for location of incoming wiring to the starter.

# Electrical Information

## Starter to Motor (Remote-Mounted Starters Only)

### Ground Wire Terminal Lugs

Ground wire lugs are provided in the motor terminal box and in the starter panel.

### Terminal Clamps

Terminal clamps are supplied with the motor terminals to accommodate either bus bars or standard motor terminal wire lugs. Terminal clamps provide additional surface area to minimize the possibility of improper electrical connections.

### Wire Terminal Lugs

Wire terminal lugs must be field-supplied.

1. Use field-provided crimp-type wire terminal lugs properly sized for the application.

**Note:** Wire size ranges for the starter line and load-side lugs are listed on the starter submittal drawings supplied by the starter manufacturer or Trane. Carefully review the submitted wire lug sizes for compatibility with the conductor sizes specified by the electrical engineer or contractor.

2. A terminal clamp with a 3/8" bolt is provided on each motor terminal stud; use the factor-supplied Belleville washers on the wire lug connections.

Figure 5 illustrates the juncture between a motor terminal stud and terminal clamp.

3. Tighten each bolt to 24 foot-pounds.
4. Install but do not connect the power leads between the starter and compressor motor. (These connections will be completed under supervision of a qualified Trane service engineer after the prestart inspection).

## CAUTION

**ENSURE THE POWER SUPPLY WIRING AND OUTPUT TO MOTOR WIRING ARE CONNECTED TO THE PROPER TERMINALS. Failure to do so will cause catastrophic failure of the starter and, or motor**

### Bus Bars

Install the bus bars between the motor terminals when a low-voltage "across-the-line", "primary reactor/resistor," "auto transformer" or customer-supplied solid-state, or customer-supplied AFD.

Be sure to bus motor terminal T1 to T6, T2 to T4, and T3 to T5.

**Note:** Bus bars are not needed in high-voltage applications since only 3 terminals are used in the motor and starter.

## Starter to UCP (Remote-Mounted Starters Only)

Electrical connections required between the remote-mounted starter and the unit control panel are shown in an example of a point-to-point starter-to-UCP connection diagram as shown at the end of the manual.

**Note:** Install control voltage conduit into control voltage section of chiller control panel and starter panel. Do not route with low voltage (30 volts) conduit wires.

When sizing and installing the electrical conductors for these circuits, follow the guidelines listed.

## CAUTION

**TO AVOID DAMAGE TO STARTER COMPONENTS, remove debris inside the starter panel. Failure to do so may cause an electrical short that seriously damages the starter components.**

1. If the starter enclosure must be cut to provide electrical access, exercise care to prevent debris from falling inside the enclosure. Do not cut AFD enclosure.

2. Use only shielded twisted pair for the interprocessor communication (IPC) circuit between the starter and the UCP on remote mounted starters. Recommended wire is Beldon Type 8760, 18 AWG for runs up to 1000 feet.

**Note:** The polarity of the IPC wire pair is critical for proper operation.

3. Separate low-voltage (less than 30V) wiring from the 115V wiring by running each in its own conduit.
4. As you route the IPC circuit out of the starter enclosure, make sure that it is at least 6" from all wires carrying a higher voltage.
5. For UCP IPC shielded twisted pair wiring, the shield should be grounded on one end only at UCP at 1X1-G. The other end should be unterminated and taped back on the cable sheath to prevent any contact between shield and ground.

Refer to Figure 6 for wiring information on UCP Control Panel connections.

## NOTE

**MAINTAIN AT LEAST 6 INCHES BETWEEN LOW-VOLTAGE (<30V) AND HIGH VOLTAGE CIRCUITS. Failure to do so could result in electrical noise that may distort the signals carried by the low-voltage wiring, including the IPC.**

# Electrical Information

Figure 5 – Terminal Stud, Clamp and Lug Assembly





Figure 6 – UCP Control Panel Connections

**Trane-Supplied Remote Starter Connections**

*1X1-		2X1-
1	1A-115VAC (H)	1
12	2A-115VAC (N)	2
3	3B-Run Relay	6
4	4B- Start Relay	4
1A7-J2-4	9A- Oil Pump Interlock	7
1A7-2-2	10A-Oil Pump Interlock	8

**\*Note:** The wire is retained in the clamp by the force of the spring which pushes the wire against the connecting bar. Use care to ensure full insertion of screwdriver into terminal block wire release mechanism. Proper tool engagement is required to release the tension for wire insertion.

Unit Control Panel to Starter Panel Interprocessor Communications Link.



Ground Shield at UCP end only.

## Electrical Information

---

### UCP Electrical Specifications

Following is a requirements list for the UCP in the control panel:

Note that the control panel is designed to receive input from the secondary of a power transformer in the starter panel.

1. **Nominal Voltage:** 115/110 VAC, 60/50 Hz with operating range of 98 to 127 VAC, inclusive.
2. **Maximum VA:** 4K VA (40-amp fuse) for units with the refrigerant pump
3. Power input wiring must be at least 6" [152 mm] from low-voltage, less than 30V wiring.
4. All signal inputs are low-voltage less than 30V.
5. UCP Storage Range: -40°F to 158°F (-40°C to 70°C) i.e., not applicable for chiller.

### Water Pump Interlock Circuits and Flow Switch Input

**Chilled Water Pump.** Wire the evaporator water pump contactor (5K1) to a separate 120 volt single phase power supply with 14 AWG, 600 volt copper wire, then connect this circuit to 1A5-J2-6. Then use 1A5-J2-4 120 VAC output to allow the UCP to control the evaporator water pump, or wire the 5K1 contactor to operate remotely and independently of the UCP.

### Chilled Water Proof of Flow

Wire the auxiliary contacts of the evaporator water pump contactor (5K1) in series with the flow switch (5S1) installed in the evaporator supply pipe. Use 14 AWG, 600-volt copper wire.

Connect this circuit to UCP terminals 1X1-5 to 1A6-J3-2.

When installed properly, the chilled water interlock circuit will only allow compressor operation if the evaporator pump is running and providing at least the minimum water flow required.

**Condenser Water Pump.** Wire the condenser water pump contactor (5K2) to a separate 120-volt, single-phase power supply with 14 AWG, 600-volt copper wire; then connect this circuit to UCP terminals 1A5-J2-3. Then use 1A5-J2-1 120 VAC output to allow UCP to control the condenser pump.

### Condenser Water Proof of Flow

Next, use 14 AWG, 600-volt copper wire to connect the auxiliary contacts of the condenser water pump contactor (5K2) in series with the flow switch (5S2) installed in the condenser supply pipe.

Connect this circuit to UCP terminals 1X1-6 to 1A6-J2-2.

When installed properly, the condenser water lock circuit will only allow the compressor to operate if the condenser pump is running and providing at least the minimum water flow required.

## Electrical Information

### Temperature Sensor Circuits

All temperature sensors are factory-installed except the optional outdoor air temperature sensor. This sensor is required for the outdoor air temperature type of chilled water reset. Follow the guidelines below to locate and mount the outdoor air temperature sensor. Mount the sensor probe where needed, however, mount the sensor module in the UCP.

The outdoor temperature sensor similar to the unit mounted temperature sensors in that it consists of the sensor probe and the module. A four-wire IPC bus is connected to the module for 24 vdc power and the communications link.

We recommend mounting the sensor module within the UCP and the sensor two wire leads be extended and routed to the outdoor temperature sensor probe sensing location. This assures the four wire IPC bus protection and provides access to the module for configuration at start-up.

The sensor probe lead wire between the sensor probe and the module can be separated by cutting the two wire probe lead leaving equal lengths of wire on each device; the sensor probe and the sensor module. Note this sensor and module are matched and must remain together or inaccuracy may occur. These wires can then be spliced to with two 14-18 AWG 600V wires of sufficient length to reach the desired outdoor location, maximum length 1000 feet (305 meters). The module four-wire bus must be connected to the UCP four-wire bus using the Trane approved connectors provided.

The sensor will be configured (given its identity and become functional) at start-up when the serviceman performs the start-up configuration.

It will not be operational until that time.

**Note:** If shielded cable is used to extend the sensor leads, be sure to tape off the shield wire at the junction box and ground it at the UCP. If the added length is run in conduit, do not run them in the same conduit with other circuits carrying 30 or more volts.

### NOTE

**MAINTAIN AT LEAST 6 INCHES BETWEEN LOW-VOLTAGE (<30V) AND HIGH VOLTAGE CIRCUITS. Failure to do so could result in electrical noise that may distort the signals carried by the low-voltage wiring, including the IPC.**

### Optional Relay Circuits

#### Optional Control and Output Circuits

Install various optional wiring as required by the owner's specifications.

### Optional Tracer Communication Interface

This control options allows the UCP to exchange information such as chiller status and operating set points with a Tracer system.

Figure 7 illustrates how such a communication/control network might appear.

**Note:** The circuit must be run in separate conduit to prevent electrical noise interference.

Additional information about the Tracer Comm option is published in the installation manual and operator's guide that ships with the Tracer.

### Unit Start-Up

All phases of initial unit start-up must be conducted under the supervision of a qualified local service engineer.

This includes pressure testing, evacuation, electrical checks, refrigerant charging, actual start-up and operator instruction.

Advance notification is required to assure that initial start-up is scheduled as close to the requested date as possible.

### Starter Module Configuration

The starter module configuration settings will be checked (and configured for Remote Starters) during start-up commissioning. To configure starter module, and perform other starter checks, it is recommended that the line voltage three phase power be turned off and secured (locked out), and then a separate source control power (115 vac) be utilized to power up the control circuit. To do this, remove control coil circuit fuse, typically 2F4, and then connect separate source power cord to starter terminal block 2X1-1 (H), 2X1-2 (N), and Ground. Use the "as-built starter schematic" to assure correct fuse and terminals. Verify correct fuse is removed, control circuit connections are correct, then apply the 115 vac separate source power to service the controls.

### Forms Information


Samples of start-up and operating forms along with other helpful forms are found in the Operation Maintenance manual which can be obtained from the nearest Trane office.

It is recommended that the serviceman contact the local Trane office to obtain the most recent printing date of the form. The forms in the operation and maintenance manual are only current at the time of printing of the manual.

After obtaining the most recent form, complete all the information and forward it to your local Trane office..

# Electrical Information

Figure 7 – Illustrates Communication/Control Network to Chiller Units with CH530



# Wiring Drawings

## Schematic Wiring Drawings

The following pages consist of typical wiring drawings for an CVHE, CVHF or CVHG chiller. However, please refer to the submittals and drawings that actually shipped with the unit.

Refer to the chiller operation and maintenance manual for an example of a typical sequence of operation for a Unit Mounted Wye-Delta Starter.

In the starter drawings, shown in this manual, all starter variables are the same in the Sequence of Operation except the Maximum Acceleration Time.

Table 3 provides a listing of included schematics, connection diagrams and field wiring drawings to follow.

Table 3 also shows variables of the Maximum Acceleration Time for all starter drawings in this manual.

**Table 3 – Wiring Addendum**

Type of Drawing	Drawing Number	Maximum Acceleration Time (seconds)
<b>Field Wiring Layout Drawings</b>		
Legend (Unit Mounted Wye-Delta Starter)	2309-4922-B	–
Unit Mounted Wye-Delta Starter	2309-4902-A	27
Unit Mounted Solid-State Starter	2309-4904-A	15
Unit Mounted Across-the-Line	2309-4906-A	6
Unit Mounted Adaptive Frequency Drive	2309-4912-B	30
Remote Wye-Delta Starter	2309-4903-A	27
Remote Mounted Solid-State Starter	2309-4905-A	15
Remote Across-the-Line Starter	2309-4909-A	6
Remote Primary Reactor Starter	2309-4910-A	11
Remote Auto Transformer Starter	2309-4911-A	11
Customer Supplied Wye-Delta Starter	2309-4913-A	27
Customer Supplied Primary Reactor and Auto Transformer Starter	2309-4914-A	11
Customer Supplied Across-the-Line Starter	2309-4915-A	6
Customer Supplied Solid-State Starter	2309-4916-A	20
Purge Schematic	2309-4917-A	–
Aftermarket Purge Schematic	2309-4918-A	–
Unit Controls Schematic	2309-4919-A	–
System Controls Schematic	2309-4920-C	–
Options Schematic	2309-4921-A	–
<b>Connection Diagrams</b>		
Standard Connection Diagram Panel with Options	2309-4923-A	–
Field Connection Trane Starter	2309-4935-A	–
Customer Supplied Starter	2309-4936-A	–
Unit Wiring – Standard	2309-4937-A	–
Unit Wiring – Optional	2309-4938-A	–
Purge Control Panel (Unit Mounted)	2309-4939-A	–
Purge Control Panel (Aftermarket)	2309-4940-A	–

**Note:** These are typical drawings only. Refer to specific as-built schematics for actual unit drawings which represent the unit wiring as shipped.






# 2309-4903

## CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG REMOTE MOUNTED WYE-DELTA STARTER

REMOTE WYE-DELTA STARTER

- PREFIX CODE**  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = PURGE  
 4 = UNIT MOUNTED DEVICE  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS







# 2309-4904

## CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG UNIT MOUNTED SOLID STATE STARTER


UNIT MOUNTED SOLID STATE STARTER

PREFIX CODE  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = MAIN CONTROL DEVICE  
 4 = PROVIDED BY OTHERS  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS















# 2309-4909 A

## CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG REMOTE MOUNTED ACROSS THE LINE STARTER

REMOTE MOUNTED ACROSS THE LINE STARTER

- PREFIX CODE  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = LINE MOUNTED DEVICE  
 4 = UNIT MOUNTED DEVICE  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS







CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
 REMOTE MOUNTED PRIMARY REACTOR STARTER

2309-4910 A

REMOTE PRIMARY REACTOR STARTER






- 15 —
- 16 —
- 17 —
- 18 —
- 19 —
- 20 —
- 21 —
- 22 —
- 23 —
- 24 —
- 25 —
- 26 —
- 27 —
- 28 —
- 29 —
- 30 —
- 31 —
- 32 —
- 33 —
- 34 —
- 35 —
- 36 —
- 37 —
- 38 —
- 39 —
- 40 —
- 41 —
- 42 —
- 43 —
- 44 —
- 45 —
- 46 —


CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
 REMOTE MOUNTED AUTO-TRANSFORMER STARTER

2309-4911 A

REMOTE AUTO-TRANSFORMER STARTER



- PREFIX CODE  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = PURGE  
 4 = UNIT MOUNTED DEVICE  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS







23 —  
 24 —  
 25 —  
 26 —  
 27 —  
 28 —  
 29 —  
 30 —  
 31 —  
 32 —  
 33 —  
 34 —  
 35 —  
 36 —  
 37 —  
 38 —  
 39 —  
 40 —  
 41 —  
 42 —  
 43 —  
 44 —  
 45 —  
 46 —  
 47 —  
 48 —  
 49 —  
 50 —  
 51 —  
 52 —  
 53 —  
 54 —  
 55 —





CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
 CUSTOMER SUPPLIED WYE-DELTA STARTER

2309-4913 A

CUSTOMER SUPPLIED WYE-DELTA STARTER


- PREFIX CODE  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = PURGE  
 4 = UNIT MOUNTED DEVICE  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS





CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
 CUSTOMER SUPPLIED PRIMARY REACTOR OR AUTO-TRANSFORMER STARTER

2309-4914 A







CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
 CUSTOMER SUPPLIED ACROSS THE LINE STARTER

2309-4915 A

CUSTOMER SUPPLIED ACROSS THE LINE STARTER

PREFIX CODE  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = PURGE  
 4 = UNIT MOUNTED DEVICE  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS





TRANSFORMER NOT REQUIRED  
IF PRIMARY 600 VAC  
OR LESS - 3 SINGLE PHASE  
REQ. IF OVER 4800 V.

FROM 5T1,2 & 3  
(LINE 11)

SEE LINE 141

IPC BUS


- 14 —
- 15 —
- 16 —
- 17 —
- 18 —
- 19 —
- 20 —
- 21 —
- 22 —
- 23 —
- 24 —
- 25 —
- 26 —
- 27 —
- 28 —
- 29 —
- 30 —
- 31 —
- 32 —
- 33 —
- 34 —
- 35 —
- 36 —
- 37 —
- 38 —
- 39 —
- 40 —
- 41 —
- 42 —
- 43 —
- 44 —
- 45 —


CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
CUSTOMER SUPPLIED SOLID STATE STARTER

2309-4916 A

CUSTOMER SUPPLIED SOLID STATE STARTER

PREFIX CODE  
 1 = MAIN CONTROL PANEL  
 2 = STARTER PANEL  
 3 = PURGE  
 4 = UNIT MOUNTED DEVICE  
 5 = PROVIDED BY OTHERS  
 DASHED LINES INDICATE WIRING BY OTHERS







- 19 —
- 20 —
- 21 —
- 22 —
- 23 —
- 24 —
- 25 —
- 26 —
- 27 —
- 28 —
- 29 —
- 30 —
- 31 —
- 32 —
- 33 —
- 34 —
- 35 —
- 36 —
- 37 —
- 38 —
- 39 —
- 40 —
- 41 —
- 42 —
- 43 —
- 44 —
- 45 —
- 46 —
- 47 —
- 48 —
- 49 —

CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
 PRODUCTION PURGE

2309-4917 A






IFC BUS

- 86 —
- 87 —
- 88 —
- 89 —
- 90 —
- 91 —
- 92 —
- 93 —
- 94 —
- 95 —
- 96 —
- 97 —
- 98 —
- 99 —
- 100 —
- 101 —
- 102 —
- 103 —


CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
AFTERMARKET PURGE

2309-4918 A




- 61 —
- 62 —
- 63 —
- 64 —
- 65 —
- 66 —
- 67 —
- 68 —
- 69 —
- 70 —
- 71 —
- 72 —
- 73 —
- 74 —
- 75 —
- 76 —
- 77 —
- 78 —
- 79 —
- 80 —
- 81 —
- 82 —
- 83 —
- 84 —
- 85 —
- 86 —
- 87 —


- 87 —
- 88 —
- 89 —
- 90 —
- 91 —
- 92 —
- 93 —
- 94 —
- 95 —
- 96 —
- 97 —
- 98 —
- 99 —
- 100 —
- 101 —
- 102 —
- 103 —
- 104 —
- 105 —
- 106 —



CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
UNIT CONTROLS SCHEMATIC

2309-4919 A






- 140 —
- 141 —
- 142 —
- 143 —
- 144 —
- 145 —
- 146 —
- 147 —
- 148 —
- 149 —
- 150 —
- 151 —
- 152 —
- 153 —
- 154 —
- 155 —
- 156 —
- 157 —
- 158 —
- 159 —
- 160 —
- 161 —
- 162 —
- 163 —
- 164 —
- 165 —
- 166 —
- 167 —
- 168 —
- 169 —
- 170 —
- 171 —
- 172 —
- 173 —

CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
SYSTEM CONTROLS SCHEMATIC

2309-4920 A




- 181- 4B1 PRESS. SWITCH 4-200MA
- 182- 4B2 PRESS. SWITCH 4-200MA
- 183- EVAP. DIFFERENTIAL WATER PRESS.
- 184- 4B13 EXTERNAL FREE COOLING SWITCH
- 185- 4B13 SPLICE 4B12 118A
- 186- 120A 120B 119A
- 187- FC ACTUATORS CLOSED
- 188- 5S8
- 189- 120A 120B 118A 119A
- 190- 120A 120B 118A 119A
- 191- 120A 120B 118A 119A
- 192- 120A 120B 118A 119A
- 193- 120A 120B 118A 119A
- 194- 120A 120B 118A 119A
- 195- 120A 120B 118A 119A
- 196- 120A 120B 118A 119A
- 197- 120A 120B 118A 119A
- 198- 120A 120B 118A 119A



CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG  
OPTIONS SCHEMATIC

2309-4921 A



IPC BUS

# HERMETIC CENTRIFUGAL LIQUID CHILLER

# 2309-4922 B

CENTRAVAC®

CH 530 SCHEMATIC WIRING CVHE, CVHF, CVHG

LEGEND

DEVICE LOCATION PREFIX CODE

- 1= MAIN PANEL MOUNTED
- 2= STARTER PANEL MOUNTED
- 3= PURGE MOUNTED
- 4= FRAME MOUNTED DEVICE
- 5= PROVIDED BY OTHERS

DASHED LINES INDICATE WIRING BY OTHERS

**Note:** This legend applies to unit mounted Wye-Delta Starter.

DEVICE DESIGNATION	DESCRIPTION	LINE NUMBER
1A1	POWER SUPPLY #1	
1A2	POWER SUPPLY #2	PAGE 3
1A3	OIL TANK HEATER CONTROL	
1A4	CONDENSER HIGH PRESSURE CUT-OUT SWITCH	
1A5	CONDENSER, EVAPORATOR WATER PUMP RELAYS	
1A6	CONDENSER, EVAPORATOR WATER FLOW SWITCH	
1A7	OIL/REFRIGERANT PUMP MOTOR CONTROL	
1A8	UNIT OPERATING STATUS	
1A9	UNIT OPERATING STATUS	
1A10	ICE BUILDING RELAY	
1A11	FREE COOLING CONTROL RELAYS	
1A12	HOT GAS BY-PASS CONTROL RELAYS	
1A13	EXT. AUTO/STOP & EMERGENCY STOP INPUT	
1A14	TRACER COMMUNICATIONS COMM 4	
1A15	%RLA & COND. REFR. PRESSURE OUTPUT	PAGE 5
1A16	EXT. CURRENT LIMIT & CHILLED WATER SETPOINTS	
1A17	EXT. BASE LOADING AND REFRIGERANT MONITOR	
1A18	EXTERNAL BASE LOADING & HOT WATER E/D	
1A19	EXTERNAL ICE MAKING COMMAND	
1A20	EXTERNAL FREE COOLING COMMAND	PAGE 4
1A21	WATER DIFFERENTIAL PRESSURE INPUT	
1A22	DYNA VIEW OPER. INTERFACE/ MAIN PROCESSOR	
1F1	CONTROL POWER FUSE	143
1F2	OIL PUMP FUSE	161
1Q1	CIRCUIT BREAKER - STARTER	21
1Q2	CIRCUIT BREAKER - PURGE	141
1Q3	CIRCUIT BREAKER - UNIT CONTROL	143
1Q4	CIRCUIT BREAKER - MOTOR CONTROL	145
1T1	CONTROL POWER TRANSFORMER	144
1X1	CONTROL PANEL TERM BLOCK	
2C1	POWER FACTOR CORRECTION CAPACITOR	12
2A1	STARTER MODULE	
2F1,2,3	PRIMARY STARTER FUSING	3,6,10
2F4	SECONDARY CONTROL POWER FUSE	16
2K1	START CONTACTOR	29
2K2	RUN CONTACTOR	32
2K3	SHORTING CONTACTOR	35
2K4	TRANSITION CONTACTOR	38
2K9	GROUND FAULT RELAY	17
2K11	INTERLOCKING RELAY	27
2Q1	CIRCUIT BREAKER - LINE VOLTAGE	1,5,9
2T1,2,3	CURRENT TRANSFORMERS	2,5,8
2T5	CONTROL POWER TRANSFORMER	12
2T6,7,8	POTENTIAL TRANSFORMER	18,20,22
2X1	CONTROL TERM. STRIP	
2X3	LINE TERMINAL BLOCK	
3A1	PURGE PUMPOUT & EXHAUST SOLENOIDS	
3A2	PURGE CONDENSING UNIT	
3A3	PURGE PUMPOUT, HEATER & REGEN SOLINOID	
3A4	PURGE LIQUID LEVEL SWITCH INPUT	
3A7	MOTOR WINDING TEMPERATURE	164
3HR1	PURGE CARBON TANK HEATER	82
3L1	PURGE EXHAUST SOLENOID	94
3L2	PURGE PUMPOUT SOLENOID	96
3L3	PURGE REGENERATION SOLENOID	79
3M5	PURGE CONDENSING UNIT	91
3M6	PURGE PUMP-OUT COMPRESSOR	85
3R1	PURGE REFRIGERANT COMPRESSOR SUCTION TEMP.	165
3R2	PURGE CARBON TANK TEMPERATURE SENSOR	75
3S1	CONDENSER HIGH PRESS SWITCH	19
3S9	PURGE LIQUID LEVEL SWITCH	77

DEVICE DESIGNATION	DESCRIPTION	LINE NUMBER
4B1	EVAPORATOR WATER DIFFERENTIAL PRESSURE	182
4B2	CONDENSER WATER DIFFERENTIAL PRESSURE	185
4B12	FREE COOLING DISCHARGE ACTUATOR CLOSED	191
4B13	FREE COOLING SUCTION ACTUATOR CLOSED	191
4C1	OIL/REFRIGERANT PUMP CAPACITOR	165
4HR1	OIL TANK HEATER	159
4K8	OIL/REFRIGERANT PUMP MOTOR CONTROL RELAY	166
4M1	COMPRESSOR MOTOR	5
4M2	INLET GUIDE VANE ACTUATOR FIRST STAGE	131
4M3	OIL/REFRIGERANT PUMP MOTOR	165
4M4	INLET GUIDE VANE ACTUATOR SECOND STAGE	137
4M5	HOT GAS BY-PASS ACTUATOR	210
4M12	FREE COOLING DISCHARGE ACTUATOR	214
4M13	FREE COOLING SUCTION ACTUATOR	217
4M1R2,3 & 4	MOTOR WINDING TEMPERATURE 1, 2 & 3	165
4R1	INBOARD BEARING TEMPERATURE SENSOR	146
4R2	OUTBOARD BEARING TEMPERATURE SENSOR	149
4R3	OIL PUMP DISCHARGE PRESSURE TRANSDUCER	153
4R4	OIL TANK PRESSURE TRANSDUCER	156
4R5	OIL TANK TEMPERATURE SENSOR	159
4R6	EVAPORATOR ENTERING WATER TEMPERATURE SENSOR	195
4R7	EVAPORATOR LEAVING WATER TEMPERATURE SENSOR	197
4R8	CONDENSER ENTERING WATER TEMPERATURE SENSOR	200
4R9	CONDENSER LEAVING WATER TEMPERATURE SENSOR	203
4R10	SATURATED EVAPORATOR REFRIGERANT TEMP. SENSOR	205
4R11	SATURATED CONDENSER REFRIGERANT TEMP. SENSOR	207
4R13	OUTDOOR AIR TEMPERATURE SENSOR	212
4R14	SECOND CONDENSER ENTERING WATER TEMP. SENSOR	215
4R15	SECOND CONDENSER LEAVING WATER TEMP. SENSOR	217
4R16	COMPRESSOR DISCHARGE REFRIGERANT TEMP. SENSOR	220
4R22	CONDENSER REFRIGERANT PRESSURE TRANSDUCER	222
4S1	HOT GAS BY-PASS VALVE CLOSED	148
5K1	EVAPORATOR WATER PUMP CONTACTOR	194
5K2	CONDENSER WATER PUMP CONTACTOR	197
5K9	FREE COOLING RELAY	221
5H1	LATCHING ALARM INDICATOR	269
5H2	NON-LATCHING ALARM INDICATOR	275
5H4	PURGE ALARM INDICATOR	256
5H6	COMPRESSOR RUNNING INDICATOR	266
5H7	LIMIT WARNING INDICATOR	272
5H8	ICE BUILDING INDICATOR	246
5H10	HEAD RELIEF REQUEST INDICATOR	259
5H11	MAXIMUM CAPACITY INDICATOR	262
5S1	EVAPORATOR WATER FLOW SWITCH	185
5S2	CONDENSER WATER FLOW SWITCH	186
5S3	EXTERNAL AUTO/ STOP	169
5S4	EXTERNAL EMERGENCY STOP	171
5S5	EXTERNAL BASE LOADING COMMAND	251
5S6	EXTERNAL HEAT PUMP CONTROL COMMAND	253
5S7	EXTERNAL ICE BUILDING COMMAND	246
5S8	EXTERNAL FREE COOLING COMMAND	189



### WARNING

HAZARDOUS VOLTAGE!

DISCONNECT ALL ELECTRIC POWER INCLUDING REMOTE DISCONNECTS BEFORE SERVICING.

FAILURE TO DISCONNECT POWER BEFORE SERVICING CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.



### AVERTISSEMENT

VOLTAGE HASARDEUX!

DECONNECTEZ TOUTES LES SOURCES ELECTRIQUES INCLUANT LES DISJONCTEURS SITUES A DISTANCE AVANT D'EFFECTUER L'ENTRETIEN.

FAUTE DE DECONNECTER LA SOURCE ELECTRIQUE AVANT D'EFFECTUER L'ENTRETIEN PEUT ENTRAÎNER DES BLESSURES CORPORELLES SEVERES OU LA MORT.



### CAUTION

USE COPPER CONDUCTORS ONLY!

UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS.

FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

#### NOTES:



1. DASHED LINES INDICATE RECOMMENDED FIELD WIRING BY OTHERS. CHECK SALES ORDER TO DETERMINE IF WIRING IS REQUIRED FOR SPECIFIC OPTIONS.
2. CAUTION - DO NOT ENERGIZE UNIT UNTIL CHECK-OUT AND START-UP PROCEDURES HAVE BEEN COMPLETED.

#### REQUIRED


3. ALL CUSTOMER CONTROL CIRCUIT WIRING MUST HAVE A MINIMUM RATING OF 150 VOLTS.
4. ALL FIELD WIRING MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC), STATE AND LOCAL REQUIREMENTS. OUTSIDE THE UNITED STATES, OTHER COUNTRIES APPLICABLE NATIONAL AND/OR LOCAL REQUIREMENTS SHALL APPLY.
5. EVAPORATOR AND CONDENSER FLOW SWITCHES ARE REQUIRED. THEY MUST BE INSTALLED AND WIRED TO THE TRANE PANEL BY THE INSTALLING CONTRACTOR. PURCHASE OF SWITCHES FROM TRANE IS OPTIONAL.

- 6 2 WIRES, 115 VAC CIRCUIT, SEPARATE POWER SUPPLY IS REQUIRED. MINIMUM CONTACT RATING AT 115 VAC - 2.88 INDUCTIVE 1/3 H.P.(.25 kW) AT 115 VAC OPTIONAL.
- 7 2 WIRES, 115 VAC CIRCUIT, SEPARATE POWER SUPPLY IS REQUIRED. CONTACTS ARE N.O. CONTACT RATING - 2.88 INDUCTIVE 1/3 H.P.(.25 kW) AT 115 VAC.
- 8 2 OR 3 WIRES(N.O. &/OR N.C.), 115 VAC CIRCUIT, SEPARATE 115 VAC POWER SUPPLY IS REQUIRED. CONTACTS ARE NO/NC RATINGS - 2.88 INDUCTIVE 1/3 H.P.(.25 kW) AT 115 VAC.
- 9 2-10V OR 4-20ma INPUT
- 10 2-10V OR 4-20ma OUTPUT
- 11 CUSTOMER SUPPLIED SILVER CONTACTS MUST BE COMPATIBLE WITH DRY CIRCUIT 24 VDC, 12ma RESISTIVE LOAD.
- 12 SHIELDED PAIR. 30 VOLT OR LESS CIRCUIT. MAX LENGTH 1500 FT. BELDON TYPE 8760 RECOMMENDED.

THE UNIT CONTROL PANEL (CH.530) SUPPLIES A CONTACT OUTPUT TO CONTROL THE CUSTOMER SUPPLIED DEVICES SHOWN BELOW. MAXIMUM FUSE SIZE PER DEVICE - 15 AMPS.



LOW VOLTAGE (30V MAX)  
2 WIRES, NOT RUN WITH  
HIGHER VOLTAGE CIRCUITS.



FRONT ELEVATION

<p><b>⚠ WARNING</b> HAZARDOUS VOLTAGE! DISCONNECT ALL ELECTRIC POWER INCLUDING REMOTE DISCONNECTS BEFORE SERVICING. FAILURE TO DISCONNECT POWER BEFORE SERVICING CAN CAUSE SEVERE PERSONAL INJURY OR DEATH.</p>	<p><b>⚠ AVERTISSEMENT</b> VOLTAGE HASARDEUX! DECONNECTEZ TOUTES LES SOURCES ELECTRIQUES INCLUANT LES DISJONCTEURS SITUES A DISTANCE AVANT D'EFFECTUER L'ENTRETIEN. FAUTE DE DECONNECTER LA SOURCE ELECTRIQUE AVANT D'EFFECTUER L'ENTRETIEN PEUT ENTRAÎNER DES BLESSURES CORPORELLES SEVERES OU LA MORT.</p>	<p><b>⚠ CAUTION</b> USE COPPER CONDUCTORS ONLY! UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS. FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.</p>
---	---	--

**NOTES:**



1. DASHED LINES INDICATE RECOMMENDED FIELD WIRING BY OTHERS. CHECK SALES ORDER TO DETERMINE IF WIRING IS REQUIRED FOR SPECIFIC OPTIONS.
2. CAUTION - DO NOT ENERGIZE UNIT UNTIL CHECK-OUT AND START-UP PROCEDURES HAVE BEEN COMPLETED.

**REQUIRED**

3. ALL CUSTOMER CONTROL CIRCUIT WIRING MUST HAVE A MINIMUM RATING OF 150 VOLTS.
4. ALL FIELD WIRING MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC), STATE AND LOCAL REQUIREMENTS. OUTSIDE THE UNITED STATES, OTHER COUNTRIES APPLICABLE NATIONAL AND/OR LOCAL REQUIREMENTS SHALL APPLY.
5. EVAPORATOR AND CONDENSER FLOW SWITCHES ARE REQUIRED. THEY MUST BE INSTALLED AND WIRED TO THE TRANE PANEL BY THE INSTALLING CONTRACTOR. PURCHASE OF SWITCHES FROM TRANE IS OPTIONAL.

- |    |   |
|----|---|
| 6  | 2 WIRES, 115 VAC CIRCUIT, SEPARATE POWER SUPPLY IS REQUIRED. MINIMUM CONTACT RATING AT 115 VAC - 2.88 INDUCTIVE 1/3 H.P. (.25 kW) AT 115 VAC OPTIONAL.              |
| 7  | 2 WIRES, 115 VAC CIRCUIT, SEPARATE POWER SUPPLY IS REQUIRED. CONTACTS ARE N.O. CONTACT RATING - 2.88 INDUCTIVE 1/3 H.P. (.25 kW) AT 115 VAC.                        |
| 8  | 2 OR 3 WIRES(N.O. &/OR N.C.), 115 VAC CIRCUIT, SEPARATE 115 VAC POWER SUPPLY IS REQUIRED. CONTACTS ARE NO/NC RATINGS - 2.88 INDUCTIVE 1/3 H.P. (.25 kW) AT 115 VAC. |
| 9  | 2-10V OR 4-20ma INPUT   |
| 10 | 2-10V OR 4-20ma OUTPUT  |
| 11 | CUSTOMER SUPPLIED SILVER CONTACTS MUST BE COMPATIBLE WITH DRY CIRCUIT 24 VDC, 12ma RESISTIVE LOAD.  |
| 12 | SHIELDED PAIR, 30 VOLT OR LESS CIRCUIT. MAX LENGTH 1500 FT. BELDON TYPE 8760 RECOMMENDED.   |

THE UNIT CONTROL PANEL (CH.530) SUPPLIES A CONTACT OUTPUT TO CONTROL THE CUSTOMER SUPPLIED DEVICES SHOWN BELOW. MAXIMUM FUSE SIZE PER DEVICE - 15 AMPS.




LOW VOLTAGE (30V MAX)  
2 WIRES, NOT RUN WITH HIGHER VOLTAGE CIRCUITS.

CONTROL VOLTAGE  
115 VAC - 7 WIRES  
2 - #8 AWG 600V  
4 - #16 AWG 600V  
1 - #8 GRN FOR GROUND

COPPER WIRE ONLY  
SIZED PER N.E.C. BASED ON NAMEPLATE RATING.

LINE VOLTAGE  
REMOTE STARTER (SEE NAMEPLATE)

LINE VOLTAGE TO MOTOR









CONNECTION DIAGRAM  
FIELD CONNECTION - TRANE STARTER  
CH 530

2309-4935 A






**NOTES:**

1. DASHED LINES INDICATE FIELD WIRING BY OTHERS. CHECK SALES ORDER TO DETERMINE WHICH OPTIONS ARE SPECIFIED.
2. DO NOT ROUTE LOW VOLTAGE (30V MAX) WITH CONTROL VOLTAGE (115V) AND DO NOT POWER UNIT UNTIL CHECK-OUT AND START-UP PROCEDURES HAVE BEEN COMPLETED.
3. EVAPORATOR AND CONDENSER FLOW SWITCHES ARE REQUIRED. THEY CONTAIN DPDT CONTACTS. THE SEPERATE FLOW SWITCHES ARE RUN IN SERIES WITH SEPERATE AUX CONTACTS FOR THE CONDENSER PUMP AND SEPERATE AUX CONTACTS FOR THE EVAPORATOR PUMP. THEY MUST BE INSTALLED AND WIRED TO THE APPROPRIATE TRANE PANEL BY THE INSTALLING CONTRACTOR. PURCHASE OF SWITCHES FROM THE TRANE CO. IS OPTIONAL.





CONNECTION DIAGRAM  
FIELD CONNECTION  
CUSTOMER SUPPLIED STARTER  
CVHE,CVHF,CVHG

2309-4936 A












CONNECTION DIAGRAM  
 UNIT WIRING OPTIONAL  
 CH 530  
 CVHE,CVHF,CVHG

2309-4938 A

UNIT CONTROL PANEL






**NOTES;**


1. WATER TEMP. SENSORS MAY BE CONNECTED TO 4-WIRE COMMUNICATON LINK CABLE WB2 FOR RIGHT HAND END OR WB3 FOR LEFT HAND END DEPENDING ON WATER BOX PASS ARRANGEMENT.
2. WIRING SHOWN IS FOR UNIT MOUNTED STARTER, IF REMOTE STARTER IS USED SEE DRG. 2309-4935 OR IF CUSTOMER SUPPLIED STARTER SEE DRG. 2309-4936.



PURGE PUMPOUT COMPRESSOR  
(PANEL ASSEMBLY)




EXHAUST SOLENOID  
(PANEL ASSEMBLY)




COMPRESSOR SUCTION TEMPERATURE SENSOR

TEMPERATURE SENSORS  
(UNIT ASSEMBLY)




CARBON TANK TEMP SENSOR




COMPRESSOR MOTOR WINDING  
TEMPERATURE SENSORS

COND. HIGH PRESS. CONTROL  
(INSIDE PURGE CONTROL PANEL)



REGENERATION SOLENOID  
(PANEL ASSEMBLY)



CARBON TANK HEATER  
(UNIT ASSEMBLY)



CONDENSING UNIT  
(UNIT ASSEMBLY)



COMPRESSOR MOTOR WINDING  
TEMPERATURE SENSORS

WIRE NO. 14A & 2AA FROM  
UNIT CONTROL PANEL TO 3X1  
& WIRE NO. 3A, 4A & 7A FROM  
UNIT CONTROL PANEL TO 3S1







**TRANE®**

**Trane**  
**An American Standard Company**  
**[www.trane.com](http://www.trane.com)**

For more information contact  
your local district office or  
e-mail us at [comfort@trane.com](mailto:comfort@trane.com)

---

Literature Order Number	CVHE-SVN03A-EN
File Number	SV-RF-CTV-CVHE-SVN03A-EN-1001
Supersedes	New
Stocking Location	La Crosse

---

*Since Trane has a policy of continuous product and product data improvement, it reserves the right to change design and specifications without notice.*

*Only qualified technicians should perform the installation and servicing of equipment referred to in this publication.*