

TOSHIBA

T300MVi

MEDIUM VOLTAGE 

ADJUSTABLE SPEED MOTOR DRIVE

Troubleshooting Manual

June, 2007

TOSHIBA INTERNATIONAL CORPORATION



Document Number: IF08CZ02
REV. 0


Contents


1	Usage Notes	3
2	Reading this manual	5
3	Fault Signal Explanation	6
3.1	Fault Signal A~	6
3.2	Fault Signal B~	8
3.3	Fault Signal C~	9
3.4	Fault Signal D~	13
3.5	Fault Signal E~	14
3.6	Fault Signal F~	15
3.7	Fault Signal G~	16
3.8	Fault Signal I~	17
3.9	Fault Signal M~	18
3.10	Fault Signal N~	20
3.11	Fault Signal O~	21
3.12	Fault Signal P~	24
3.13	Fault Signal R~	27
3.14	Fault Signal S~	28
3.15	Fault Signal T~	32
3.16	Fault Signal U~	34
3.17	Fault Signal V~	36
3.18	Fault Signal X~	37

1 Usage Notes

This equipment includes high-voltage components. To prevent electric shock, burns, or other injuries when using this equipment, and to maintain its performance, be sure to read this manual before using this equipment. Also, observe all warning labels attached to the equipment.

The  and  marks have the following meanings:


: Electric shock warning


: Warning for safe work



■ Danger (Red Label)

Failure to avoid locations or actions marked in this manner may lead to serious injury or death.

[Warning Label Examples]







	DANGER
Primary circuit voltage is supplied.	

 DANGER	
	Hazardous voltage can result in electric shock. Make sure that there is no electrical charge before inspection or maintenance.

■ Warning (Orange Label)

Failure to avoid locations or actions marked in this manner may lead to injury, albeit of a somewhat lesser severity. Failure to follow these directions may also lead to property loss, such as damage to the equipment or components, or to fires.


 WARNING	
	Hazardous voltage can result in electric shock. Do not open the door while the power is on. Turn off the power supply to the equipment before inspection or maintenance.

 WARNING	
	Hazardous voltage can result in electric shock. Do not open the door while the power is on. Opening the door during power receiving will trip the circuit breaker.

■ Advice (Green Label)

These labels provide advice that can assure safe operation, can prevent errors and performance degradation in the equipment, and can be useful in preventing breakdowns.

[Warning Label Examples]

	<p>NOTICE When operating or adjusting the equipment and during maintenance/inspections, be sure to observe the precautions noted in the User's Manual.</p>
---	---

■ Others (White Labels)

These labels present items related to maintaining the performance of the equipment.

2 Reading this manual

Content (cause):

They are the content of failure and the cause of presumed.

Action:

It is the action for restoring failure.

Parameters:

They are the parameters relevant to a failure detection.

Refer to "Parameter Setting Manual" about the details of a parameter.

3 Fault Signal Explanation

3.1 Fault Signal A~

AC_MCCB

AC input circuit breaker open

AC MCCB open

Content (cause):

The input AC circuit breaker of the equipment (AC_MCCB) is open. Turns off UVA signal and stops.

Action:

If no interface with the auxiliary contact of the input AC circuit breaker is provided for this signal, mask it.

Check the wiring of the answerback auxiliary contact of the input AC circuit breaker.

Check the input AC circuit breaker for any abnormality.

Parameters: MSK_UVA1, MSK_ACT1

ACSW_C

AC contactor close

AC SWitch is Closing

Content (cause):

The contactor on the load side is closed although it is not turned on.

Action:

Check the contactor (a point of contact and a conduction).

Parameters: MSK_SIL1, MSK_ACIL1

ACSW_F

AC contactor fault
AC SWitch Failure

Content (cause):

The contactor on the load side is open during operation. Turns off UV signal and stops.

Action:

Check the contactor on the load side for any abnormality (a point of contact and a conduction).

Parameters: MSK_UV1, MSK_HFD1

ACSW_T

AC contactor open timer
AC SWitch open Timer

Content (cause):

The contactor on the load side is open. READY signal is not turned on.

Action:

It is a standard circuit that the contactor on the load side is turned on with the establishment of a UV signal.

If this signal is detected even if UV signal is turned on, check the contactor (a point of contact and a conduction).

Parameters: MSK_READY1

AIN_FAULT

General analog input signal lost fault
General Analog INput signal lost FAULT

Content (cause):

Current signal fell lower than 4mA when using 4-20mA current type general analog input. UV signal is not turned on.

Action:

Check the condition of signal cable and signal source.

Signal lost detection is not available when using voltage type general analog input. Thus set this fault bit to be not used.

Parameters: MSK_UV2, MSK_HFD2, MSK_LFD1

3.2 Fault Signal B~

B_HLTY

Break healthy detection

Break HeaLThY detection

Content (cause):

A brake healthy signal.

Action:

Check the brake circuit.

Parameters: MSK_UV2, MSK_HFD2

BLA

AC circuit breaker trip

BLocking signal - Auxiliary

Content (cause):

An external BLA off signal (AC circuit breaker off) is detected. It turns off UVA signal and then stops.

Action:

In the case of the inverter, mask it.

Check the external BLA signal.

Parameters: MSK_UVA3

BLR

Electrical critical fault

BLocking Relay

Content (cause):

This is a secondary display caused by the BLR condition being off.

Action:

Refer to the display of the primary cause of BLR being off.

Parameters: MSK_UVA1, MSK_ACT1

BLR_CPSF

Electrical critical fault except power supply failure

BLocking Relay except Control Power Supply Failure

Content (cause):

This is a secondary display caused by the BLR except power supply failure condition being off.

Action:

Refer to the display of the primary cause of BLR except power supply failure being off.

Parameters: MSK_UVA1, MSK_ACT1

BR_F

Electromagnetic brake energizing circuit fault

BRake Failure

Content (cause):

A brake operation circuit fault. This indicates a situation in which no answerback (operation confirmation signal) is returned although brake releasing command "BR" is output. Turns off READY signal and stops.

Action:

In the case of a built-in type brake, the contactor of the energizing circuit may be failing. Check the contactor.

In the case of an air brake, the microswitch of the air valve may be failing.

Check the operation of the electromagnetic valve and microswitch.

In the case of an electromagnetic brake, an error (current drop) may be detected in the energizing unit.

Check whether the LED "LF" of the energizing unit is on. If it is off, check the input voltage and output current.

Parameters: MSK_READY2, MSK_HFD2

3.3 Fault Signal C~

C_FN

Equipment ventilating fan stopped

Cooling FaN

Content (cause):

An equipment ventilating fan error has been detected.

This detection is made by an auxiliary contact of the fan MCCB.

If continued the operation further, "C_FN_T" activates and the breaker trips.

Action:

Check the fan MCCB status.

Check the rotation condition of the fan. (Abnormal sound, entrapping of foreign matter, burning of bearing, etc.)

Check the fan motor.

Parameters: MSK_STPRQ1, MSK_LFD1

C_FN_B

Equipment ventilating fan stopped B bank

Cooling FaN B bank

Content (cause):

An equipment ventilating fan alarm on bank B is detected.

This detection is made by an auxiliary contact of the fan MCCB.

If continued the operation further, "C_FN_B_T" activates and the breaker trips.

Action:

Check the fan MCCB status.

Check the rotation condition of the fan. (Abnormal sound, entrapping of foreign matter, burning of bearing, etc.)

Check the fan motor.

Systems: Twin drive

Parameters: MSK_STPRQ1, MSK_LFD1

C_FN_T

Equipment ventilating fan stop timer

Cooling FaN Timer

Content (cause):

Abnormal status of the equipment ventilating fan continued for the length of time set with the timer.

Turns off UVA signal and stops.

This detection is made by an auxiliary contact of the fan MCCB.

Action:

Check the fan MCCB status.

Check the rotation condition of the fan. Abnormal sound, entrapping of foreign matter, burning of bearing, etc.

Check the fan motor.

Parameters: MSK_UVA1, TIME_CFAN

C_FN_T_B

Equipment ventilating fan timer stop timer B bank

Cooling FaN Timer B bank

Content (cause):

Abnormal status of the equipment ventilating fan of bank B continued for the length of time set with the timer.

Turns off UVA signal and stops.

This detection is made by an auxiliary contact of the fan MCCB.

Action:

Check the fan MCCB status.

Check the rotation condition of the fan. Abnormal sound, entrapping of foreign matter, burning of bearing, etc.

Check the fan motor.

Systems: Twin drive

Parameters: MSK_UVA2, TIME_CFAN

C_IL

Closing interlock

Closing InterLock

Content (cause):

A secondary display caused by a UV starting interlock being off.

If this signal is not established, the UV signal cannot be turned on.

Action:

Refer to the display of the primary cause for the starting interlock (SIL) or UV starting interlock being off.

Parameters: MSK_UV1

CHG_START

System change in progress

system CHanGing START

Content (cause):

Shows that the motor changeover control is in progress.

While the changeover control is in progress, READY signal is turned off and operating becomes impossible.

Under normal conditions, after the changeover operation is completed, the system will automatically return to the previous status.

Action:

Check the wiring of the motor changeover circuit (2S and 3S signals).

Parameters: MSK_READY2, FLG_CHGSYS

CL_T

Current limit timer

Current Limit Timer

Content (cause):

It has been detected that operation with a current limit has continued for the length of time set with the timer.

Turns off UVA signal and stops.

Action:

Check the operation status and load status.

Check whether there is a contributing factor to cause an overload on the machine side such as a machine locked.

Check the output kW of the drive.

Parameters: MSK_UVA1, TIME_CL

CL_TA

Current limit timer alarm

Current Limit Timer Alarm

Content (cause):

An operation under the current limited condition continued for up to 80% of the time set with the current limit timer (CL_T). Stop request (STPRQ) is output.

If continued the operation further, "CL_T" activates and the breaker trips.

Action:

Check the operation status.

Check whether there is any error causing stall on the machine side.

Parameters: MSK_STPRQ1, TIME_CL

CPSF

Control power source failure
Control Power Source Failure

Content (cause):

The control power supply voltage has dropped. Turns off BLR signal and stops

Action:

Check the voltage of the control power supply.

Check the fuse of the GDM board.

Check whether an instantaneous interruption accident, etc. occurred.

Parameters: MSK_BLR6, CP_PSF

CPT_FAIL

Capture failure

CaPTure FAIL

Content (cause):

Utility synchronization capture failed. Turns off the UVA signal and stops, or turns off the LFD signal and indicates ALARM.

Action:

Check that the line voltage detection circuit of the inverter output is connected correctly.

Check the parameter (LVL_IPLL_DLTQ) of the phase synchronization criteria value.

Check the utility power supply voltage for distortion or frequency variations.

Parameters: MSK_UVA3, MSK_LFD2, LVL_IPLL_DLTQ

CPU_A

Slave CPU A failure

CPU slave A failure

Content (cause):

The watchdog failure has occurred in the slave CPU-A of the CTR board.

Turns off BLR signal and stops

This error may also occur when the 5 V power supply is abnormal.

Action:

For restarting the CPU, carry out a power supply initialize (by turning off the control power supply and turning it on again).

If recovery is not possible even with the power supply initializing or this error recurs repeatedly, replace the CTR board.

Parameters: MSK_BLR1

CPU_M

Master CPU failure

CPU Master failure

Content (cause):

The watchdog failure has occurred in the main CPU of the CTR board.

Turns off BLR signal and stops

This error may also occur when the 5 V power supply is abnormal.

Action:

For restarting the CPU, carry out a power supply initialize (by turning off the control power supply and turning it on again).

If recovery is not possible even with the power supply initializing or this error recurs repeatedly, replace the CTR board.

Parameters: MSK_BLR1

CUR_DIFF

Current differential detection

CURrent DIFFerential detection

Content (cause):

The current unbalance between bank A and bank B reached 50% or more of the rating.

Action:

Check whether the main circuit DC bus and output contactor, etc. of either bank A or bank B are open.

Check the wiring and format of the current detector and wiring of the cables connected to the CTR.

Parameters: MSK_LFD1

CURU

Current failure of U-phase

CURrent failure of U-phase

Content (cause):

U-phase current could not be detected. Turns off BLR signal and stops

Action:

In the case of the single configuration, check the wiring of the U-phase current detector and wiring of the main circuit.

In the case of the twin configuration, check the wiring of the U-phase current detector of bank A and wiring of the main circuit.

Check the wiring of the cables connected to the CTR board.

Parameters: MSK_BLR1, CP_CURCHK

CURW

Current failure of W-phase

CURrent failure of W-phase

Content (cause):

W-phase current could not be detected. Turns off BLR signal and stops

Action:

In the case of the single configuration, check the wiring of the W-phase current detector and wiring of the main circuit.

In the case of the twin configuration, check the wiring of the W-phase current detector of bank A and wiring of the main circuit.

Check the wiring of the cables connected to the CTR board.

Parameters: MSK_BLR1, CP_CURCHK

3.4 Fault Signal D~

DS

Door open

Door Switch open

Content (cause):

The door switch on the front panel of the inverter shows “Door switch open” status.

Action:

Close the front door.

Check to make sure a micro switch on the upper side of the door is not damaged or something.

Parameters: MSK_ACT1

DS_T

Door open timer

Door Switch open Timer

Content (cause):

A door switch open condition continued for the length of time set with the timer.

Turns off BLR signal and stops.

Action:

Close the front door.

Check to make sure a micro switch on the upper side of the door is not damaged or something.

Parameters: MSK_BLR5, TIME_DS

3.5 Fault Signal E~**ENCODER_F**

Speed Encoder Fail Detect

ENCODER Fail

Content (cause):

The abnormalities of a speed detection encoder have been detected. Turns off BLR signal and stops.

Action:

Check whether rolling material, etc. is caught inside.

Check the wiring and the coupling of the speed sensor for any abnormality.

Parameters: MSK_BLR3

3.6 Fault Signal F~**FUSE_XP, FUSE_XN (X : U, V, W)**

IGBT fuse blown

FUSE

Content (cause):

Main circuit protection fuse is blown. Turns off BLR signal and stops.

The IGBT device may have been damaged.

Action:

Check the indicator of each fuse and replace the blown fuse.

Check the device and if the device is damaged, replace the damaged power module.

Parameters: MSK_BLR2

3.7 Fault Signal G~

GR_A

Ground detection alarm

GRound detection Alarm

Content (cause):

It has been detected that a ground current is upper than ground detection alarm level.

Action:

Check whether the main circuit cable etc. has Insulated degradation.

Parameters: MSK_LFD1, MSK_STPRQ1, CP_GDI_A

GR_T

Ground detection timer

GRound detection Timer

Content (cause):

Abnormal current is detected in the grounding circuit where the main circuit is grounded through a high value resistance.

And it has been detected for the length of time set with the timer.

Turns off UVA signal and stops.

Some IGBT devices may have been damaged.

Action:

Check whether the main circuit has a ground fault.

Check the devices and if some devices are damaged, replace the IGBT unit.

Parameters: MSK_UVA3, MSK_HFD2, MSK_LFD1, CP_GDI, TIME_GR

3.8 Fault Signal I~**IL**

External interlock

InterLock

Content (cause):

An interlock signal from outside (trunk line) is in “operation prohibition” status.

Turns off UV signal and stops.

Action:

Check the condition on the master cubicle side.

Parameters: MSK_UV1

3.9 Fault Signal M~

M_FN

Motor cooling fan stopped

Motor FaN

Content (cause):

The motor cooling fan stopped. If continued the operation further, "M_FN_T" activates.

Action:

Start the motor cooling fan.

Parameters: MSK_SIL1, MSK_STPRQ1, MSK_LFD1

M_FN_T

Motor cooling fan stop timer

Motor FaN Timer

Content (cause):

The condition of motor cooling fan being stopped have continued for the length of time set with the timer.

Turns off READY signal and stops.

Action:

Start the motor cooling fan.

Parameters: MSK_READY2, MSK_HFD2, TIME_MFAN

M_OH

Motor overheat

Motor OverHeat

Content (cause):

The motor temperature detection circuit has detected an overheat.

Action:

Check the cooling situation of the motor.

Parameters: MSK_UV2, MSK_HFD2, MSK_STPRQ1, MSK_LFD1

M_OH_A

Motor overheat alarm

Motor OverHeat Alarm

Content (cause):

An overheat alarm is detected by the motor temperature detection circuit.

If the temperature further rises, "M_OH" is activated.

Action:

Check the cooling situation of the motor.

Parameters: MSK_STPRQ1, MSK_LFD1

MOT_V_IL

Motor voltage start interlock

MOTor Voltage start InterLock

Content (cause):

Motor residual voltage is remaining over protection level (CP_MOT_V_IL).

When the motor is running, drive doesn't detect it.

Action:

Wait until motor residual voltage goes down under CP_MOT_V_IL.

Check the Voltage detection circuit (Cell board, wire and connection).

Parameters: CP_MOT_V_IL, MSK_READY1

MPSF

Main power source failure

Main Power Source Failure

Content (cause):

A main power supply loss has been detected during operation. Turns off BLR signal and stops.

Action:

Check the wiring of the main circuit and the current detector.

Parameters: MSK_BLR6

MPSF_MV

Main power source failure

Main Power Source Failure MV

Content (cause):

An AC main power supply loss has been detected during operation. Turns off BLR signal and stops.

Action:

Check the wiring of the main circuit, the input voltage detector and the fuse.

Parameters: MSK_BLR6

MTMP_S

Motor temperature detector fault

Motor TeMPerature Stop request

Content (cause):

An error is found in the motor temperature detector.

Action:

Check the motor temperature and motor temperature detector.

Parameters: MSK_STPRQ1, MSK_LFD1

3.10 Fault Signal N~**N. U.**

Not used

Not Used

Action:

Mask the signal.

Parameters: MSK_BLF1~3, MSK_BLR2~6, MSK_UVA1~4, MSK_UV1, 2, MSK_SIL1, 2, MSK_READY1, 2, MSK_HFD1, 2, MSK_STPRQ1, MSK_LFD1, MSK_ACIL1, MSK_ACT1

N_IM

Number of IM motors error

Number of Induction Motors failure

Content (cause):

In a multiple sensor-less units driving system, the number of motors driven became the number equal to or less than the low limit level. Turns off UVA signal and stops.

Action:

Check the NFB installed in each motor.

Check the detection circuit to count the number of motor units.

Parameters: MSK_UVA4, CP_N_IM_LL

NO_LOAD

Output side open

output No LOAD detection

Content (cause):

An open load is detected. Turns off UVA signal and stops.

This signal is generated when the feedback current becomes one eighth or less of the excitation current.

The load circuit may be left open.

Action:

The IGBT circuit, gate circuit or the current detection circuit may have a problem.

Parameters: MSK_UVA3

3.11 Fault Signal O~**OCA**

AC overcurrent

OverCurrent Ac

Content (cause):

The AC over current detection circuit (hardware) activated. Turns off BLR signal and stops

Action:

Check whether there is any current hunching during operation.

In the case of an inverter, check to see there are not ground of a motor line and disconnection of a speed sensor.

Parameters: MSK_BLR1

OCD_XA1, OCD_XA4, OCD_XB1, OCD_XB4 (X : U, V, W)

Device short-circuit protection

OverCurrent Device

Content (cause):

The short-circuit protection circuit of the main circuit device activated. Turns off BLR signal and stops.

The subscript of "A" or "B" means side of power module (See instruction manual).

And number shows the position of damaged device. "1" means device #1 or #2 may have damaged, and "4" means device #3 or #4 may have damaged.

Action:

Check the main circuit device and if the device is damaged, replace the damaged power module.

Parameters: MSK_BLR4

OH

Equipment overheat

OverHeat

Content (cause):

An overheat condition of the inverter stack is detected. Outputs a stop request (STPRQ).

If continued the operation further, "OH_T" activates and the inverter trips.

Action:

Check the operation of the ventilating fan, the filter for any clogging and the temperature of the electric room.

Parameters: MSK_STPRQ1

OH_T_U, OH_T_V, OH_T_W

Equipment overheat timer

OverHeat Timer

Content (cause):

An overheat condition of the equipment continued for the length of time set with the timer.

Turns off BLR signal and stops.

Action:

Check the operation situation.

If there is no sign of overload, check the operation of the ventilating fan, the filter for any clogging and the temperature of the electric room.

Parameters: MSK_BLR1, TIME_OH

OH_TR

Overheat transformer

OverHeat TRansformer

Content (cause):

An overheat condition of the transformer occurred.

Turns off BLR signal and stops.

Action:

If there is no sign of overload, check the operation of the ventilating fan, the filter for any clogging and the temperature of the electric room.

Parameters: MSK_BLR2

OL_A

Equipment overload alarm

OverLoad Alarm

Content (cause):

The AC current RMS has exceeded the set value for 5 minutes. Outputs a stop request (STPRQ).

Action:

Check the load situation.

Parameters: MSK_STPRQ1, CP_RMS_A

OL20

Overload (20 minutes) RMS

OverLoad 20 minutes

Content (cause):

The output current RMS has exceeded the set value for 20 minutes. Turns off UVA signal and stops.

Action:

Check the load situation.

Parameters: MSK_UVA1, CP_RMS_20

OL5

Overload (5 minutes) RMS

OverLoad 5 minutes

Content (cause):

The AC current RMS has exceeded the set value for 5 minutes. Turns off UVA signal and stops.

Action:

Check the load situation.

Parameters: MSK_UVA1, CP_RMS_5

OSS

Overspeed

OverSpeed Software

Content (cause):

An overspeed of the motor has been detected. Turns off BLR signal and stops.

Action:

Check to see there is not disconnection of a speed sensor.

Check the amount of overshoot of speed control.

Check whether there is any influence of the machine connected, material, etc.

Parameters: MSK_BLR3, CP_OSP

OSS_FO

Output frequency exceeded

OverSpeed Software FO (FO: frequency)

Content (cause):

Excessive output frequency has been detected. Turns off BLR signal and stops.

Action:

Check the amount of overshoot of speed control.

Check whether there is any influence of the machine connected, material, etc.

Parameters: MSK_BLR3, CS_MOTOR_FREQ

OV_XP, OV_XN (X : U, V, W)

DC overvoltage

OverVoltage Dc

Content (cause):

Power module DC overvoltage detection is activated. Turns off BLR signal and stops.

The subscript of "P" or "N" means which side of DC bus on power module (See instruction manual). Action:

Check whether a voltage variation or a more sudden deceleration operation than normal was not made.

Parameters: MSK_BLR6, CP_OV

3.12 Fault Signal P~**P_SW**

Panel interlock switch on

Panel SWitch

Content (cause):

The interlock switch on the cubicle is in "Operation prohibited" (lamp lit) status.

Turns off UV signal and stops

Action:

Press the switch to turn the interlock switch to "Operation permitted" (lamp unlit) status.

Parameters: MSK_UV1, MSK_HFD1

PARA_ERR

Set parameter check error

PARAMeter check ERRor

Content (cause):

This is a checksum error of parameter setting value. Turns off UVA signal.

Action:

Carry out a power supply initialize (by turning off the control power supply and turning it on again) to make sure the error.

Reload the adjustment record data.

Parameters: MSK_UVA3

PHASE_ERR

Phase rotation error

PHASE ERRor

Content (cause):

This is a PLL power supply phase sequence error. Turns off UVA signal and stops.

Action:

Check the PDM board for input fuse blowing.

Check whether the PLL input phase sequence matches the main circuit phase sequence.

Parameters: MSK_UVA3

PLD_ERR

PLD error

PLD ERRor

Content (cause):

The PLD(Programmable Logic Device) error of the CTR board has been detected.

Turns off BLR signal and stops.

Action:

Replace the CTR board.

Parameters: MSK_BLR5

PLL

Power supply synchronization PLL error

Phase Lock Loop error

Content (cause):

A power supply synchronization PLL error has been detected.

Turns off BLR signal and stops

Action:

Check the PDM board for input fuse blowing.

Check whether the PLL input phase sequence matches the main circuit phase sequence.

Check whether there is any PLL power failure.

Parameters: MSK_BLR6

PLLPSF

PLL power supply failure

Phase Lock Loop Power Source Failure

Content (cause):

A power supply synchronization PLL power loss has been detected. Turns off BLR signal and stops

Action:

Check the PDM board for input fuse blowing.

Check whether there is any open phase or other trouble in the PLL power source.

Check whether there is any PLL power failure.

Parameters: MSK_BLR6

PP7 CODE ERR

SRAM for CPU A(PP7) check sum error

PP7 CODE_ERROR

Content (cause):

A check sum error of SRAM, that is for CPU A (PP7) code memory, has been detected. Turns off UV signal and stops, or indicates alarm without stop.

Action:

For restarting the CPU, carry out a power supply initialize (by turning off the control power supply and turning it on again).

If recovery is not possible even with the power supply initializing or this error recurs repeatedly, replace the CTR board.

Parameters: MSK_UV2, MSK_HFD2, MSK_LFD2, TIME_CODE_ERR

PRE_CTT

Pre-charge contactor open

PRE-charge CTT open

Content (cause):

The contactor of the pre-charge circuit is open. In case of UVS off or no DC power, it would not be close.

Turns off UV or HFD signal and stops

Action:

Check the UVS switch status.

Check the main power supply and main contactor status.

Parameters: MSK_UV2, MSK_HFD2

PRE_CTT_F

Pre-charge contactor failure

PRE-charge CTT Failure

Content (cause):

An error is detected in the contactor of the pre-charge circuit.

Action:

Check the fuse and contactor of the reserved charging circuit.

Check the power supply voltage of the reserved charging circuit.

There is a possibility of DC voltage detection circuit error. Check the GDM board.

Parameters: MSK_STPRQ1, MSK_LFD1

3.13 Fault Signal R~**REC_F**

Rectifier failure

RECTifier Failure

Content (cause):

It detected that it doesn't establish the DC voltage in case of the main AC input is on.

Action:

Check the rectifier and input AC fuse.

Check the wiring the AC input for equipment.

Parameters: MSK_BLR4

RETRY

In retry operation

RETRY operation

Content (cause):

Operation is in retry mode due to some fault set in RETRY_MSK.

Drive will retry after interval time for attempt times.

When drive success to run for 5 minutes or start command off or fault reset, this alarm will be off.

Action:

Wait until drive restart.

Start command off or fault reset will clear the retry operation.

Parameters: MSK_LFD2, RTRY_INTVL, RTRY_MSK, RTRY_MAX

REV_ROT_F

Reverse rotate failure

REVerse ROTate Failure

Content (cause):

It detected that the motor was rotating to an opposite direction to the speed reference.

Action:

Check the wiring of the motor.

Check the wiring and the coupling of the speed sensor for any abnormality.

Parameters: MSK_BLR3, [CP_REV_ROT](#)**ROTATE_FAIL**

Motor rotate failure

motor ~~ROTATE_FAIL~~[ureROTate Failure](#)

Content (cause):

The motor stall has been detected.

Action:

Check whether rolling material, etc. is caught inside.

Check the wiring and the coupling of the speed sensor for any abnormality.

Parameters: MSK_BLR3, [CP_ROT_F_DIFF](#), [CP_ROT_F_EN](#), [TIME_ROT_F](#)

3.14 Fault Signal S~**SL_CHG**

Automatic sensorless mode change

automatic SensorLess mode CHanGe

Content (cause):

In case of using automatic sensorless mode change function, a failure of speed sensor has been detected and then the inverter has been changed to sensorless mode automatically.

Action:

Check the speed sensor and then cycle the control power supply.

Turn off the automatic sensorless mode change function to trip the equipment after the failure of speed sensor is detected.

Parameters: MSK_LFD2, FLG_DIFF_PG, FLG_SP_ERR_SL, TIME_SP_ERR_SL

SOFT_STL

Soft stall

SOFT STaLI

Content (cause):

Operation is in soft stall mode due to overload or high temperature.

(Soft stall mode decelerates the motor speed to protect the equipment against overload)

Action:

Check the load and whether circumference temperature is not over 40 degrees C.

Parameters: MSK_LFD1

SP_ERR

Speed detection error

SPeed sensor ERRor

Content (cause):

A speed feedback error has been detected. Turns off BLR signal and stops

Action:

Check whether rolling material, etc. is caught inside.

Check the wiring and the coupling of the speed sensor for any abnormality.

Parameters: MSK_BLR3

SP_ERR2

Speed detection error 2

SPeed sensor ERRor 2

Content (cause):

A speed feedback error has been detected. Turns off BLR signal and stops

Action:

Check whether rolling material, etc. is caught inside.

Check the wiring and the coupling of the speed sensor for any abnormality.

Parameters: MSK_BLR3

SP_LOST

Speed reference lost

SPEED reference LOST

Content (cause):

Detects the speed reference lost.

According to a mask setting, it becomes one of the following of operation.

- (1) Turns off UV signal and free run stop
- (2) Turns off HFD signal and free run stop
- (3) Turns off READY signal and slowdown stop

Action:

Check the connection and level of speed reference signal.

Parameters: MSK_UV1, MSK_HFD1, MSK_READY1

SP_LST_A

Speed reference lost alarm

SPEED reference LoST Alarm

Content (cause):

Detects the speed reference lost.

Action:

Check the connection and level of speed reference signal.

If detecting this signal is not required, mask the signal.

Parameters: MSK_LFD1, MSK_STPRQ1

SP_SIL

Zero speed starting interlock

SPEED Start InterLock

Content (cause):

Because the motor is running, a startup interlock condition cannot be made.

Action:

Check whether the motor has stopped and operate the equipment again.

Starting the motor while it is still running is required, mask the signal.

Parameters: MSK_SIL1, MA_ZERO_SP

SPA1

Spare 1

SPARE 1

Content (cause):

A spare signal (spare 1) has been detected.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_UV2, MSK_READY2, MSK_HFD2, MSK_SIL1, MSK_STPRQ1, MSK_LFD2

SPA1_T

Spare 1 timer

SPARE 1 Timer

Content (cause):

A spare signal (spare 1) error continued for the length of time set with the timer.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_LFD2, TIME_SPA1

SPA2

Spare 2

SPARe 2

Content (cause):

A spare signal (spare 2) has been detected.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_UV2, MSK_READY2, MSK_HFD2, MSK_SIL1, MSK_LFD2

SPA2_T

Spare 2 timer

SPARe 2 Timer

Content (cause):

A spare signal (spare 1) error continued for the length of time set with the timer.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_LFD2, TIME_SPA2

SPA3

Spare 3

SPARe 3

Content (cause):

A spare signal (spare 3) has been detected.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_LFD2

SPA3_T

Spare 3 timer

SPARe 3 Timer

Content (cause):

A spare signal (spare 3) error continued for the length of time set with the timer.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_LFD2, TIME_SPA3

SPA4

Spare 4

SPARe 4

Content (cause):

A spare signal (spare 4) has been detected.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_LFD2

SPA4_T

Spare 4 timer

SPAre 4 Timer

Content (cause):

A spare signal (spare 4) error continued for the length of time set with the timer.

Action:

Check the spare signal and mask data.

Parameters: MSK_BLR5, MSK_UVA4, MSK_LFD2, TIME_SPA4

STALL

Low frequency overload

STALL detection

Content (cause):

A large load was charged when the output frequency of the inverter was small.

Turns off UVA signal and stops.

Action:

Check the load status.

Parameters: MSK_UVA3

STCMD

Driving signal starting interlock

STart CoMmanD

Content (cause):

The start command is entered before the UV signal is satisfied.

The starting interlock condition is not satisfied.

Action:

Turn off the driving signal on the master side.

Parameters: MSK_SIL1

STPRQ

Intermediate fault (stop request)

SToP ReQuest

Content (cause):

The secondary display of the line stop request (STPRQ) sequence processing. Turns off LFD signal.

Action:

See the primary factor of STPRQ signal off.

Parameters: MSK_LFD1

SYS_ERR

System configuration error

SYStem ERRor

Content (cause):

A system configuration setting error has been detected. Turns off UVA signal.

The DIP switch of the CTR board and the setup of a system configuration (SYSTEM) are not correct.

Action:

Check whether the adjustment record data of other devices is loaded or not such as by mistaking the output voltage type (4kV, 2kV).

Parameters: MSK_UVA3, SYSTEM

3.15 Fault Signal T~

TL_F1

Transmission failure 1 – Own station failure

TosLine Failure 1

Content (cause):

The watchdog failure has occurred in the CPU of the transmission board.

Depending on the sequence mask setting, this signal interlocks on UVA signal or READY signal.

Carry out a power supply initialize (by turning off the control power supply and turning it on again) to make sure the failure.

Replace the transmission board.

Parameters: MSK_UVA4, MSK_READY1, [MSK_HFD2](#), [MSK_LFD2](#)

TL_F2

Transmission failure 2 – Initialization and Online failures

TosLine Failure 2

Content (cause):

Serial transmission in the own station is off line.

The condition is not established during initializing.

An error has occurred on the transmitting side of the optical fiber cable during operation.

Depending on the sequence mask setting, this signal interlocks on UVA signal or READY signal.

Check the optical fiber cable.

Replace the transmission board.

Parameters: MSK_UVA4, MSK_READY1, [MSK_HFD2](#), [MSK_LFD2](#)

TL_F3

Transmission failure 3 – Trunk line failure

TosLine Failure 3

Content (cause):

A serial transmission error in the master station.

Depending on the sequence mask setting, this signal interlocks on UVA signal or READY signal.

Check the transmission board on the master station.

Check the optical fiber cable.

Also check the situation of other inverters connected to the same master station.

Replace the transmission board.

Parameters: MSK_UV2, MSK_READY1, MSK_HFD2, [MSK_LFD2](#)

TL_F4

Transmission failure 4 – Drive-to-drive failure

TosLine Failure 4

Content (cause):

An error of data transmission between drives. This is detected when the other party is not online.

Depending on the sequence mask setting, this signal interlocks on UVA signal or READY signal.

Check the error message of inverter on the other party.

Check the optical fiber cable.

Replace the transmission board.

Parameters: MSK_UV2, MSK_READY1, MSK_HFD2

TUNE_IL

Auto-tuning interlock

automatic TUNE IneterLock

Content (cause):

The interruption or cancel switch was turned on during an auto-tuning operation.

Turns off UV signal and stops

Action:

Returns to normal when the auto-tuning operation is ended.

Parameters: MSK_UV2, MSK_HFD2

3.16 Fault Signal U~ **UL_A**

Low current detection alarm

Under Load detection alarm

Content (cause):

The load current is below the protection level. Indicates alarm.

Action:

Check the load condition.

Parameters: CP_UL_H, CP_UL_L, TIME_UL, MSK_LFD2

UL_T

Low current detection timer

Under Load detection timer

Content (cause):

The load current is below the protection level. Turns off UVA signal and stops.

Action:

Check the load condition. After check, it needs fault reset.

Parameters: CP_UL_H, CP_UL_L, TIME_UL, MSK_UVA1

UV

Electrical condition

Under Voltage

Content (cause):

The secondary display of sequence processing. Turns off ACIL signal.

Action:

Refer to the primary cause of UV off.

Parameters: MSK_ACIL1

UV_MPSF

Electrical condition

Under Voltage Main Power Source Failure

Content (cause):

An AC main power supply loss has been detected during operation.

Action:

Check the wiring of the main circuit, the input voltage detector and the fuse.

Parameters: MSK_UV1

UV_READY

External electrical ready condition

Under Voltage READY

Content (cause):

The secondary display of sequence processing. Turns off READY signal.

Action:

Refer to the primary cause of UV off.

Parameters: MSK_READY1

UV_SIL

DC voltage drop starting interlock

Under Voltage Start InterLock

Content (cause):

DC main power supply is equal to or less than the setting level.

Startup interlock condition cannot be made.

Action:

Check the AC input voltage and circuit.

Parameters: MSK_SIL1, CP_UV_SIL

UVA

Electrical condition ready condition

Under Voltage Auxiliary

Content (cause):

A secondary display of sequence processing.

Action:

Refer to the primary cause of UVA off.

Parameters: MSK_UV1, MSK_HFD1

UVA_EX

External equipment electrical condition ready condition

Under Voltage Auxiliary EXternal interlock

Content (cause):

An external electrical condition signal. Turns off UV signal and stops

Action:

Refer to the primary cause of UVA off of the inverter of the opposite station.

Parameters: MSK_UV1, MSK_HFD1

UVA_SIL

AC main voltage drop

Under Voltage Auxiliary Starting InterLock

Content (cause):

An AC main power supply loss has been detected. Turns off UVA signal and stops.

Action:

Check whether the operation procedure is correct or not.

Check the input AC circuit breaker for any abnormality.

Parameters: MSK_SIL1

UVD

DC voltage drop

Under Voltage of Dc

Content (cause):

Power supply voltage drop is detected in the DC main circuit. Turns off UVA signal and stops.

Action:

Check the AC input voltage and circuit.

Parameters: MSK_UVA1, CP_UVD

UVS

External safety switch

Under Voltage Safety interlock

Content (cause):

The operation interlock switch input from outside (the master cubicle) is off. Turns off UV signal and stops.

Action:

Check the condition on the master cubicle side.

Parameters: MSK_UV1

3.17 Fault Signal V~**VAC_PH_LOSS**

Input voltage phase loss detection

Voltage AC PHase LOSS

Content (cause):

Input AC voltage phase loss has detected. Turns off UVA signal and stop.

Action:

Check whether power-supply voltage balances.

Parameters: MSK_UVA2

VINV_PH_LOSS

Output Current phase loss detection

Voltage INVerter PHase LOSS

Content (cause):

Output AC current phase loss has detected. Turns off UVA signal and stop.

Action:

Check whether the load current balances.

Check the current detector for any abnormality.

Parameters: MSK_UVA2

3.18 Fault Signal X~**XFR_FAIL**

Transfer failure

transFeR Fail

Content (cause):

Utility synchronization transfer failed.

Action:

Check that the power supply voltage detection circuit is connected correctly.

Check the parameter (LVL_XFR_DLTQ) of the phase synchronization criteria value.

Check for any factor that causes excessive speed ripples in the load side.

Parameters: MSK_BLR5, MSK_LFD1, LVL_XFR_DLTQ