

	MEDIUM VOLTAGE SOLID STATE STARTER	
SERVICE	New Release	Form 160.00-M5 (706)

**MEDIUM VOLTAGE 4160V & 2300V, 60Hz & 3300V, 50Hz
SOLID STATE STARTERS for YK and YT CHILLER APPLICATIONS**

CURRENT-GUARD® STARTER



IMPORTANT!

READ BEFORE PROCEEDING!

GENERAL SAFETY GUIDELINES

This equipment is a relatively complicated apparatus. During installation, operation, maintenance or service, individuals may be exposed to certain components or conditions including, but not limited to: refrigerants, oils, materials under pressure, rotating components, and both high and low voltage. Each of these items has the potential, if misused or handled improperly, to cause bodily injury or death. It is the obligation and responsibility of operating/service personnel to identify and recognize these inherent hazards, protect themselves, and proceed safely in completing their tasks. Failure to comply with any of these requirements could result in serious damage to the equipment and the property in

which it is situated, as well as severe personal injury or death to themselves and people at the site.

This document is intended for use by owner-authorized operating/service personnel. It is expected that this individual possesses independent training that will enable them to perform their assigned tasks properly and safely. It is essential that, prior to performing any task on this equipment, this individual shall have read and understood this document and any referenced materials. This individual shall also be familiar with and comply with all applicable governmental standards and regulations pertaining to the task in question.

SAFETY SYMBOLS

The following symbols are used in this document to alert the reader to areas of potential hazard:




DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



CAUTION identifies a hazard which could lead to damage to the machine, damage to other equipment and/or environmental pollution. Usually an instruction will be given, together with a brief explanation.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



NOTE is used to highlight additional information which may be helpful to you.



External wiring, unless specified as an optional connection in the manufacturer's product line, is NOT to be connected inside the equipment cabinet. Devices such as relays, switches, transducers and controls may NOT be installed inside the unit. NO external wiring is allowed to be run through the unit. All wiring must be in accordance with YORK's published specifications and must be performed ONLY by qualified YORK personnel. YORK will not be responsible for damages/problems resulting from improper connections to the controls or application of improper control signals. Failure to follow this will void the manufacturer's warranty and cause serious damage to property or injury to persons.

DANGER
HIGH VOLTAGE

HAZARD OF ELECTRICAL SHOCK

LINE VOLTAGE PRESENT ON COMPONENTS AND TERMINALS IN THIS ENCLOSURE. MORE THAN ONE DISCONNECT SWITCH MAY BE REQUIRED TO DE-ENERGIZE THE EQUIPMENT FOR SERVICING. NOTE - LINE SIDE OF UNIT DISCONNECTS ARE LIVE UNLESS INCOMING SUPPLY VOLTAGE IS INTERRUPTED.

DANGER

HIGH VOLTAGE - KEEP OUT

DO NOT REMOVE COVERS, OPEN DOORS OR WORK ON THIS EQUIPMENT - UNLESS YOU COMPLY WITH ALL OF THE FOLLOWING:

1. Electric voltage & power has been turned off.
2. You are qualified & knowledgeable of this equipment.

CUT OFF POWER - LOCK OUT - TAG - PROPERLY GROUND ALL CIRCUITS BEFORE WORKING ON THIS EQUIPMENT. USE PROPER SAFETY PRECAUTIONS.

TABLE OF CONTENTS

GENERAL SAFETY GUIDELINES	2
SAFETY SYMBOLS	2
MVSSS VOLTAGE REQUIREMENTS	5
UNIT MODEL NOMENCLATURE	6
MVSSS OVERVIEW	7
SECTION 1 – THEORY OF OPERATION	8
SECTION 2 – SYSTEM ARCHITECTURE	12
GENERAL	12
POWER FUSES	12
CONTROL POWER TRANSFORMER	12
3-PHASE VOLTAGE DIVIDER	13
CONTACTORS	13
SCR POWER STACK ASSEMBLIES	14
SECTION 3 – CONTROLLER BOARD	15
GENERAL	15
CONNECTIONS	15
SECTION 4 – FIBER OPTIC TRANSMITTER BOARD	18
SECTION 5 – GATE DRIVER BOARDS	19
SECTION 6 – SCR HEATSINK ASSEMBLY	20
SECTION 7 – VOLTAGE DIVIDER BOARD	21
SECTION 8 – INSTALLATION	22
INSPECTION	22
GENERAL	22
SAFETY PRECAUTIONS	22
STARTER LOCATION	22
ELECTRICAL CONNECTION	22
CONTROL WIRING	23
POWER WIRING	23
SECTION 9 – STARTER FAULTS	26
DETAILED EXPLANATION OF MV-SSS FAULTS	28
SECTION 10 – TROUBLESHOOTING	30
INITIAL INSPECTION	30
BUILT-IN-SELF TEST (BIST)	31
SCR TESTING AND REPLACEMENT	32
TESTING THE STARTER ON LOW VOLTAGE	33

LIST OF TABLES

TABLE 1 – CT RATIOS	16
TABLE 2 – FAULT MESSAGES	26
TABLE 3 – GENERAL TROUBLESHOOTING	34

LIST OF FIGURES

FIG. 1 – FRONT VIEW, EXTERIOR	7
FIG. 2 – BASIC BLOCK DIAGRAM	9
FIG. 3 – MOTOR LEAD	10
FIG. 4 – R -TYPE FUSES	10
FIG. 5 – LOW VOLTAGE COMPARTMENT	11
FIG. 6 – MEDIUM VOLTAGE COMPARTMENT	11
FIG. 7 – LEXAN VIEWING WINDOW	12
FIG. 8 – CONTROL POWER TRANSFORMER	13
FIG. 9 – 3-PHASE VOLTAGE DIVIDER.....	13
FIG. 10 – IN-LINE / BYPASS CONTACTORS	13
FIG. 11 – SCR POWER STACK ASSEMBLY	14
FIG. 12 – CONTROLLER BOARD.....	14
FIG. 13 – OUTGOING TERMINATION BUS.....	14
FIG. 14 – CONTROLLER BOARD.....	15
FIG. 15 – FIBER OPTIC TRANSMITTER BOARD	18
FIG. 16 – GATE DRIVER BOARD	19
FIG. 17 – SCR HEATSINK POWER STACK CURRENT FLOW.....	20
FIG. 18 – DIVIDER / CONTROLLER RESISTORS	21
FIG. 19 – MODUS CONNECTION.....	23
FIG. 20 – INCOMING POWER LANDING PAD	23
FIG. 21 – OIL PUMP WIRING.....	23
FIG. 22 – 36" CABINET ELECTRICAL CONNECTIONS / UNIT CLEARANCES	24
FIG. 23 – 72" CABINET ELECTRICAL CONNECTIONS / UNIT CLEARANCES	25
FIG. 24 – CONTROLLER BOARD FAULT MESSAGE	26

MV-SSS REQUIREMENTS

Nominal Rated Voltage-	4160	3300	2300
Maximum Continuous Voltage-	4576	3630	2530
Minnimum Continuous Voltage-	3744	2970	2070
Maximum Voltage Dip-	10%	10%	10%
Absolute Minimum Voltage-	3536	2805	1955
Frequency-	60Hz +/-2Hz	50Hz +/-2Hz	60Hz +/-2Hz
Frequency Rate of Change-	10Hz / sec.	10Hz / sec.	10Hz / sec.
Max. Phase Unbalance-	3%	3%	3%
Interrupting Capacity-	50KA	50KA	50KA

% THD - Output THD does NOT exceed input THD once start sequence is started.

Overload - 105% Full Load RMS current for 40 seconds.

Anti-recycle Time - Minimum 20 minutes between starts.

Efficiency - 99.5% at rated input voltage and load.


Code Approval - CSA, UL, and CE.

Environmental - 32°F to 104°F (0°C to 40°C), max. 95% humidity, non-condensing, 5000' (1524m) altitude.

Enclosure - NEMA 1, IP20, IEC-529.

UNIT MODEL NUMBER NOMENCLATURE

MVSSS 0 8 5 3 R T 0 4 2 . 8 0



36" CABINET								
UNIT MODEL REFERENCE CHART								
MODEL #	MAX. FLA	MAX. LRA	45% LRA	CT 1, 2, 3	FU 1, 2, 3	POWER STACK ASSEMBLY P/N		
						2300 VAC	3300 VAC	4160 VAC
MVSSS0853R_042-V	42	1896	853	864:1	3R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_050-V	50	1896	853	864:1	4R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_065-V	65	1896	853	864:1	6R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_095-V	95	1896	853	864:1	9R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_105-V	105	1896	853	864:1	9R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_140-V	140	1896	853	864:1	12R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_190-V	190	1896	853	864:1	12R	031-02578-000	031-02578-000	031-02580-000
MVSSS0853R_280-V	280	1896	853	2640:1	18R	031-02581-000	031-02581-000	031-02583-000
MVSSS0853R_310-V	310	1896	853	2640:1	24R	031-02581-000	031-02581-000	031-02583-000
MVSSS0853R_360-V	360	1896	853	2640:1	24R	031-02581-000	031-02581-000	031-02583-000
MVSSS1708R_360-V	360	3796	1708	2640:1	24R	031-02581-000	031-02581-000	031-02583-000

72" CABINET								
UNIT MODEL REFERENCE CHART								
MODEL #	MAX. FLA	MAX. LRA	45% LRA	CT 1, 2, 3	FU 1, 2, 3	POWER STACK ASSEMBLY P/N		
						2300 VAC	3300 VAC	4160 VAC
MVSSS1708R_550-V	550	3796	1708	2640:1	38R	031-02581-000	031-02581-000	031-02583-000



FIG. 1 – MEDIUM VOLTAGE SOLID STATE STARTER – FRONT VIEW, EXTERIOR

LD11477

MEDIUM VOLTAGE SOLID STATE STARTER OVERVIEW



Safety is Number One! Voltages present within this starter enclosure may be lethal! Only “qualified” individuals are permitted to service this product!

This instruction describes the operation, start-up, and troubleshooting of the YORK Medium Voltage Solid State Starter (MV-SSS). Qualification in this case requires that the individual hold a certificate, proving satisfactory completion of formal training on proper procedures and safety requirements for working on equipment in the medium voltage (600 VAC to 7500 VAC) class. The qualified individual furthermore is to be knowledgeable of, and adhere to, all safe work practices as required by NEC, OSHA, and NFPA 70E. Because available fault current is determined largely due to sizing of the upstream transformers, wiring, and protective devices - available fault current and arc-flash hazard levels must be determined by personnel responsible for the electrical systems

within the facility where this product is installed. Proper personal protective equipment (PPE) is to be utilized where and when required. This entire publication is to be read thoroughly before servicing this product. Proper lock-out and tag-out procedures are mandatory!



Under no circumstances should any live testing be performed with the main cabinet doors open, exposing medium voltage components! Only the low-voltage access door is permitted to be open during live testing or operation of the unit. The energized safe approach distance for this product is to be determined per NFPA 70E. Non-qualified personnel are not to be present within this boundary during energizing, de-energizing, or energized testing (even with cabinet doors closed) on this starter!

SECTION 1 – THEORY OF OPERATION

General

The Medium Voltage Solid State Starter (MV-SSS), provides a soft continuous current to the chiller motor during motor starting, limiting the inrush of current to a programmed starting value, by reducing the voltage to the motor during startup. This reduced voltage is accomplished when the silicon controlled rectifiers (SCRs) are turned on in a phased back mode during motor acceleration.

The controller board provides turn-on, or “firing”, pulses to the fiber optic transmitter board, which in turn provides firing signals to the SCR power stack assemblies in each phase. Each power stack assembly contains six SCR devices and a gate driver board mounted to the SCR heatsink. Initially during motor starting these firing signals are delayed such that only a portion of the applied AC mains voltage waveform is conducted to the motor. As the motor accelerates and the inrush of current begins to drop, the SCR devices are fired with less delay time so that more of the AC mains voltage is conducted.


Once the motor is up to full speed, there is no longer any delay applied to the firing signals. The SCR devices are turned on fully, and the full applied voltage is conducted to the motor. At this point a bypass contactor is engaged to connect the motor leads directly to the incoming mains voltage so that current no longer passes through the SCR devices.

The SCR power stack assemblies control motor voltage in a manner similar to YORK’s low-voltage air-cooled and liquid-cooled solid-state starters, the higher voltage level requires that multiple SCR devices be connected together in series to withstand the voltage. Compared to YORK low-voltage starters which contain 2 SCR devices per phase, the medium voltage starter contains 6 SCRs in each phase at 4160 volts. Therefore, each SCR pair handles just under 1400 volts. This is the maximum safe rating for such SCR devices. Within each phase, three SCRs are fired simultaneously to handle the positive half of the AC waveform, and three more SCRs are fired simultaneously to handle the negative half of the AC waveform.

The gate driver board, which is attached to the SCR power stack assembly, receives firing signals for each of the 6 SCRs from the fiber optic transmitter board. The gate driver board also monitors any fault condition at the SCR power stack, and sends a “status OK” signal back to the fiber optic transmitter board. These fiber optic connections serve to isolate the voltages between phases and provide immunity to electrical noise in the environment.

The fiber optic transmitter board serves only to convert signals between electrical logic and optical logic. With 6 SCR devices per phase, there are 18 firing signals coming from the controller board which are converted to 18 optical signals, or 6 signals to each phase. Also, each of the three gate driver boards sends an optical signal back to the fiber optic transmitter board where these signals are combined into one “fault” signal that is passed from the fiber optic board, back to the controller board.


The controller board’s main function is to provide the firing signals to the SCRs and to control the in-line contactor and SCR bypass contactor. The controller board also monitors the incoming mains voltage and current to the motor. Decisions about safety and cycling shutdowns are made by logic circuits within the controller board, and all starter parameters, status information, and fault information is communicated back to the YORK OptiView panel through the controller board. This information is passed to the OptiView panel via a Modbus data connection between the OptiView panel and this controller board. In addition, there is a hard-wired start command supplied to the controller board from the OptiView panel, and a hard-wired motor controller shutdown command sent back to the OptiView panel from the controller board.



LD11745

FIG. 2 – BASIC BLOCK DIAGRAM

SECTION 2 – SYSTEM ARCHITECTURE




LD11615

FIG. 3 – MOTOR LEAD




LD11616

FIG. 4 – R -TYPE FUSES



LD11613

FIG. 5 – LOW VOLTAGE COMPARTMENT



LD11614

FIG. 6 – MEDIUM VOLTAGE COMPARTMENT

GENERAL

The YORK MV-SSS is a floor-standing, air-cooled, self-contained motor starter for 2300, 3300, and 4160 volt 3-phase applications. The cabinet is NEMA 1 rated, and designed for temperatures from 32°F to 104°F (0°C to 40°C), with relative humidity of 20% to 95%, non-condensing. If the MV-SSS is to be applied at greater than 5000' it will need to be de-rated. It is designed to interface to the YORK OptiView control panel. All setup parameters are entered through the OptiView panel, and all data and fault information from the starter are communicated back to the OptiView panel for display and access through history screens.

All components of the medium voltage solid state starter are contained within a standard 36" or 72" wide enclosures (see FIG. 1). This offers a definite advantage over other medium voltage electro-mechanical reduced voltage starters, which typically are in much larger enclosures.

Incoming power connections are made inside the top section of the enclosure to a three-phase load-break rated isolation switch. Main power supply wiring may enter at the top of the cabinet, adjacent to this switch – or may be brought into the cabinet from the floor. Conduit entrance plates are provided at the top and the bottom of the cabinet. There is also a wire path provided along the left cabinet wall for optional bottom-entry wiring. Tie-straps are provided to secure the wires if this option is chosen.

The main incoming power isolation switch is rated to open under load, the number of operations under load is very limited.



Do NOT open this switch as a normal means of shutting down the system.

When the switch is open, all three contact blades should be resting against a grounded metal bracket which assures the load-side circuits are de-energized and discharged. Visual confirmation of an open switch can be made by viewing the contact blades through a Lexan viewing window in the front of the upper cabinet portion of the enclosure (see FIG. 7).



Before opening the cabinet of the MV-SSS, standard lock-out/tag-out procedures must be followed, and visual confirmation of an open incoming power switch must be made through the viewing window!




LD11742

FIG. 7 – LEXAN VIEWING WINDOW

POWER FUSES

From the load side of the incoming power isolation switch, power is routed to the three R-type medium-voltage motor-starting power fuses inside the starter (see FIG. 4). These supplied fuses are pre-selected to match the size of motor being applied.



Upstream customer fuses should be sized such that the starter's internal fuses should open first. Most often upstream fuses will be E-type fuses which have a different time/current characteristic compared to R-type fuses.

The time/current characteristics of the upstream fuses must be selected to handle the motor inrush permitted by the R-type fuses. The load side of the MV-SSS motor starting fuses supplies power to the 120 VAC control power transformer (T1), the optional 3-phase oil pump transformer (if supplied), the 3-phase voltage divider network, and to the in-line and bypass contactors.

CONTROL TRANSFORMER

The 120 VAC control transformer (T1) is located on the floor of the starter cabinet. It supplies power to the control circuits of the MV-SSS as well as 120 VAC to the OptiView control panel on the chiller. When the three-phase oil pump transformer option is selected, there will be an additional set of primary and secondary fuses for line and load sides of this transformer.



LD11743

FIG. 8 – CONTROL TRANSFORMER

3-PHASE VOLTAGE DIVIDER NETWORK

The 3-phase voltage divider network is a series of resistors mounted under the glassic panel that separates the upper and lower sections of the starter cabinet. This series of resistors drops the voltage down to approximately 0.4 VAC to supply a 3-phase representation of line voltage to the MV-SSS controller board.



LD11744

FIG. 9 – 3-PHASE VOLTAGE DIVIDER

CONTACTORS

The in-line and bypass contactors are located directly below the 3 large R-type fuses within the incoming power compartment for the 36" cabinet. The in-line and bypass contactors are located in the starter section of the 72" cabinet. These contactors are vacuum bottle type assemblies, designed to open under load in less than 4 line-cycles. The power from the R-type fuses is supplied to the line side of both vacuum bottle assemblies. The in-line vacuum bottles are engaged initially during motor starting, to supply power to the three SCR assemblies that control the ramping up of voltage to the motor.

Once the motor is up to speed, the bypass contactor closes to connect the motor directly across the incoming line. The in-line contactor can then be dropped out and the SCRs devices turned off. The motor continues to run until the bypass contactor is dropped out.

IN-LINE
CONTACTORBYPASS
CONTACTOR

LD11748

FIG. 10 – IN-LINE / BYPASS CONTACTORS

SCR POWER STACK ASSEMBLIES

Wires pass from the load side of the in-line contactor to each of the three phase SCR power stack assemblies. Each stack contains 6 SCR devices, with 3 pairs in series to handle the rated voltage. Each SCR power stack also contains a gate driver board which is powered by 28 VAC and in-turn develops isolated supplies to power the gate of each SCR on the stack assembly. Each individual gate supply on this gate driver board is further isolated by fiber optics which transmit the firing commands from the controller board to the individual SCRs.

The load side of the bypass contactor and the load side of the SCR power stack assemblies are tied together at the output bus connections located along the lower left wall of the starter enclosure. Three copper buses are mounted to glastic standoffs to serve as a point for termination of wiring to the motor. These buses and standoffs are oriented to accept wiring entering the starter cabinet from the top of the enclosure. However, bottom entry is possible. It requires that the mounting of the three buses and standoffs to be rotated 180 degrees and re-bolted to the cabinet structure. For details of motor lead landing pads see the following FIG. below.




FIG. 11 – SCR POWER STACK ASSEMBLIES

LD11614




FIG. 12 – CONTROLLER BOARD

LD11746



36" CABINET MOTOR LEAD LANDING PAD



72" CABINET MOTOR LEAD LANDING PAD

LD12114

FIG. 13 – OUTGOING TERMINATION BUS

SECTION 3 – CONTROLLER BOARD

GENERAL

The controller board (031-02574-000) is a generic controller board designed for use in various models of high-voltage and low-voltage solid-state starters. There are several connectors along the edge of this board that we do not use in our application. In particular, there are no wires connected to TB0, TB4, TB5, TB6, TB7, TB8, or TB9. The following FIG. depicts the Controller Board (see FIG. 5 for location).




FIG. 14 – CONTROLLER BOARD

LD11747

CONNECTIONS

If we begin with TB1, and address each connection in numeric order, the connections are as follows:

TB1, G, N, and L – (G)round, (N)eutral, and (L)ine connections for 120 Control Power to the controller board.

TB1, RC1 to NO1 – This is a dry contact on the controller board that closes to maintain a circuit between wires #16 and #53 to the YORK OptiView panel.

TB1, RC2 to NO2 – This is a dry contact on the controller board that closes to energize the in-line contactor in the MV-SSS.

TB1, RC3 to NO3 – This is a dry contact on the controller board that closes to energize the bypass contactor in the MV-SSS.

TB2, Start – This input accepts the 120 VAC #24 start signal from the OptiView panel.

TB2, DI1 – This 120 VAC digital input monitors the status of the auxiliary contact on the bypass vacuum contactor to verify the bypass contactor is engaged.

TB2, S/DI1 COM – This ties to control power neutral.

TB2, DI2 – This 120 VAC digital input monitors the status of the auxiliary contact on the in-line vacuum contactor to verify the in-line contactor is engaged.

TB2, DI3 – This 120 VAC digital input monitors the status of the micro-switch interlock contact on the main power isolation switch to verify the main power isolation switch is open/closed.

TB2, DI2/3 COM – This ties to control power neutral.

TB2, SA-, SA+, SCOM, SHLD – Modbus connection to the OptiView panel (see FIG. 19).


- OptiView Panel J13 (COM2) minus (-) terminal connects to MV-SSS "SA".
- OptiView Panel J13 (COM2) signal ground (GND) terminal connects to MV-SSS "Scom".
- OptiView Panel J13 (COM2) plus (+) terminal connects to MV-SSS "SB+".

The shield connects to the OptiView enclosure and is not connected in the MV-SSS. Note that there is an MV-SSS "Shld" terminal, NOT used in our application. Therefore only the panel end of this shield, or drain wire, is truly electrically connected. This conforms to the requirement of the shield being electrically connected only at one end.

TB2, MA-, MA+, MCOM, SHLD – Not used.

TB3 – Input Current Transformers (CTs). Left top and bottom are L1 (#60 & 61), middle top and bottom are L2 (#63 & 64), and right top and bottom are L3 (#64 & 65).

TB10 – Line Voltage from Voltage Divider – Three wires from the voltage divider circuit, with #14 being L1, #15 being L2, and #16 being L3. Each of these signals should measure 0.4 VAC to logic ground with 4160 volts applied to the starter.



This voltage is dependent on being plugged into the controller board!

If this connector is disconnected from the controller board, the controller board’s internal resistors are no longer in circuit to load the voltage, and the wires on the plug from the voltage divider will provide 120 VAC measured to ground with 4160 VAC applied to the starter. The voltage from wire to wire will be approximately 208 VAC.

TB11, AIN+ and AIN PWR – This is an input for the fault signal from the dry contact at TB2 on the fiber optic transmitter board.

TB11, AIN and SHLD – There should be a jumper wire going from AIN to the COM terminal on connector TB12. The SHLD connection is not used.

TB12, AOUT, COM, SHLD – There should be a jumper wire going to AIN on TB11. The other two connections, AOUT and SHLD are not used.

CONN2 – This is a 20 conductor ribbon wire that sends the gate firing signals to the fiber optic transmitter board.

There are also several jumpers and switches on this controller board, as follows:

- JP1** – CLOSED (Jumper installed)
- JP2** – OPEN (NO Jumper)
- JP3** – OPEN (NO Jumper)
- JD3** – OPEN (NO Jumper)
- SW6** – per the following table:




TABLE 1 – CT RATIOS

CT Ratio	Motor FLA	Switch 1	Switch 2
864:1	20A to 24A	Off	Off
864:1	25A to 70A	On	Off
864:1	71A to 180A	On	On
2640:1	40A to 80A	Off	Off
2640:1	81A to 200A	On	Off
2640:1	201A to 500A	On	On

PROGRAMMING THE CONTROLLER BOARD TO MATCH THE HP AND VOLTAGE OF THE STARTER

There is only one part number for the controller board (031-02574-000) for all sizes of MV-SSS. When a replacement controller board is installed in a starter, it is necessary to program the voltage, starter rating, and CT ratio into the replacement controller board. This is done with 120 VAC power applied to the controller board, using the LED display and pushbuttons along the lower edge of this board. Use the following procedure to select the proper settings:

After powering up the controller board, the display will most likely show a fault such as F82, which is due to the input power switch being open while in the “Test” mode. If the starter is powered up in the normal operating mode, you will most likely get a display of “Rdy”, indicating the starter is ready to run.

- Press “Param” on the Controller board – “P1” should show on the display.
- Press “Up” to get “P2” on the display.
- Press “Enter” – “OFF” should be on the display.
- If “ON” is displayed, refer to below
- Press “Enter” again – you should get a blinking cursor at the left most position.
- Press “Up” to get a zero in the first position.
- Press “Enter” to move to the 2nd position.
- Press “Up” 6X to get a “5” in the 2nd position.
- Press “Enter” to move to the 3rd position.
- Press “Up” 2X to get a “1” in the 3rd position.
- Press “Enter” to move to the 4th position.
- Press “Down” 1X to get a “9” in the 4th position.
- Press “Enter” – You should see “OFF” for a moment, followed by “P2” on the display.

Press “Up” 2X to scroll to “H1” on the display, and

press “Enter”.

Press “Up” or “Down” to select the proper max FLA for the starter frame size.

The available values are 42, 50, 65, 95, 105, 140, 190, 280, 310, 360 and 550.

Select the proper value for the size of starter, and press “Enter”

Press “Up” to scroll to “H2” on the display, and press “Enter”.

Press “Up” or “Down” to select the proper max inrush amps for the starter.

The only available values are 853 and 1708.

Select the proper value for the size of starter, and press “Enter”.

Press “Up” to scroll to “H3” on the display, and press “Enter”.

Press “Up” or “Down” to select the proper voltage rating for the starter.

The available values are 2300, 3300 and 4160.

Select the proper value for the size of starter, and press “Enter”.

Press “Up” to scroll to “H4” on the display, and press “Enter”.

Press “Up” or “Down” to select the correct output CT ratio for the starter.

The available values are 288, 864, 2640, 2880 and 5760.

Select the proper value for the size of starter, and press “Enter”.

Press “Up” to scroll to “H5” on the display, and press “Enter”.

Press “Up” or “Down” to select modbus address “10”, and press “Enter”.

Press “Up” to scroll to “H6” on the display, and press “Enter”.

Press “Up” or “Down” to select option “0”, and press “Enter”.

Press “Up” on the Controller board – “P1” should show on the display.

Press “Up” again to get “P2” on the display.

Press “Enter” – you should see “OFF” on the display.

Press “Enter” again and you should see a blinking cursor at the left most position.

Press “Up” to get a zero in the first position.

Press “Enter” to move to the 2nd position.

Press “Up” 6X to get a “5” in the 2nd position.

Press “Enter” to move to the 3rd position.

Press “Up” 2X to get a “1” in the 3rd position.

Press “Enter” to move to the 4th position.

Press “Down” 1X to get a “9” in the 4th position.

Press “Enter” – You should see “OFF” for a moment, followed by “P2” on the display.

Press “Up” several times and you should see the display alternate between P1, P2, and P3 only. Failure to display H1, H2, etc, proves that the board is again locked so that values cannot be accidentally changed. This completes programming of the MV-SSS controller board to match the starter voltage and frame size.

If “On” is displayed after pressing “Enter” from the “P2” display, use the following procedure to clear this condition:

Press “Enter” again – you should get a blinking cursor at the left most position.

Press “Up” to get a zero in the first position.

Press “Enter” to move to the 2nd position.

Press “Up” 5X to get a “4” in the 2nd position.

Press “Enter” to move to the 3rd position.

Press “Up” 2X to get a “1” in the 3rd position.

Press “Enter” to move to the 4th position.

Press “Up” 3X to get a “2” in the 4th position.

Press “Enter” – You should see “OFF” for a moment, followed by “P2” on the display.


Now go back to the point where you enter the password, “0519” to access programming of the board.

SECTION 4 – FIBER OPTIC TRANSMITTER BOARD


This board is located adjacent, and to the right of the controller board in the low voltage compartment of the MV-SSS (see FIG. 5). The purpose of this board is to convert electrical digital logic signals to optical digital logic signals. Optical isolation assures there will be no passing of electrical currents between phases, and assures immunity to electrical RFI/EMI noise in the surrounding environment.

Power to the board and digital logic signals are supplied via a 20 conductor ribbon wire connected to J3 on this board. When power is present on the board, the red “Power OK” LED1 is illuminated. Gate signals to the SCRs are transmitted from connectors FIB1 through FIB18. In addition, each gate driver board sends a fault status back to the fiber optic transmitter board on connectors FIB19, FIB20, and FIB21. If any one of these signals should indicate a fault at a gate driver, the fiber optic transmitter board extinguishes the green “Status” LED2 on the transmitter board. At this same time the board’s internal dry contacts across terminals 1 and 2 of TB2 transition, opening the circuit from AIN+ to AIN PWR back to the controller board at TB11. This causes an immediate shutdown of the starter.

The fiber optic transmitters are arranged that FIB 1 through FIB 6 go to the gate driver board on the L1 phase. FIB 7 through FIB 12 go to the L2 phase, and FIB 13 through FIB 18 go to the L3 phase (see the FIG. below).



J2, J4, and TB2 pins 3 through 6 are not used in the MV-SSS application.




LD11749

FIG. 15 – FIBER OPTIC TRANSMITTER BOARD


SECTION 5 – GATE DRIVER BOARDS

Each MV-SSS contains three identical gate driver boards, one for each phase. Each board is powered by 28 VAC which comes from a 300VA transformer, T2, located in the upper right corner of the low voltage compartment of the starter. T2 connects in a daisy-chain fashion to the J1 connectors on each gate driver board. The top left pin of each J1 connector is unused, and the top right pin of J1 goes to ground via a green ground wire. 28 VAC connects across the J1 lower two pins, with a white wire on the left and a red wire on the right (Refer to the FIG. below).

Gating signals are applied to this board from the fiber optic signals going to connectors SCRA through SCRF. These optical signals in turn cause gate voltages to be applied to the SCR devices at connectors J2, J4, J5, J6, J7, and J8 respectively.




J3 is not a gate signal, but connects to a Klaxon® thermal detector device on the heatsink.



There are also gate signal LEDs adjacent to each SCR gate connector.

None of these LEDs will be visible when running since we cannot operate the MV-SSS with the cabinet doors open. However the starter has a built in self test (BIST) mode that can be utilized with low voltage (only) applied to the MV-SSS. In the self test mode, gate signals are sent to all gate driver boards at a very slow rate so that illumination of the gate signal LEDs can be verified. This will be addressed in more detail in the troubleshooting section of this manual.



LD11750


FIG. 16 – GATE DRIVER BOARD

SECTION 6 – SCR HEATSINK POWER STACK ASSEMBLY




The SCR devices themselves are very similar to the SCR devices used in YORK low-voltage air-cooled and liquid-cooled solid-state starters. The MV-SSS heatsink assemblies or “stacks” are arranged somewhat like having three low voltage SCR heatsinks in series. There are a total of 6 SCRs in each stack, or phase. A gate driver board is attached to each heatsink to develop the gate to cathode potential needed to turn on the gate of each SCR device.

The gate signal is typically in the range of 0.7 to 3.0 VDC, with gate current in the range of 25 to 150 mA. The voltage across each SCR device is 1400 volts AC. These SCRs may be tested using a standard Gate/Hi-Pot tester such as in used on low voltage SCR products. Because it may be somewhat confusing to see how electrical current flows in such an assembly the FIG. below shows conventional current flow, alternating in both directions.

POSITIVE CURRENT FLOW B-D-F



NEGATIVE CURRENT FLOW E-C-A




LD11776

FIG. 17 – SCR HEATSINK POWER STACK CURRENT FLOW

SECTION 7 – VOLTAGE DIVIDER BOARD

The voltage divider board takes the incoming line voltage and drops it down to a lower voltage that can be supplied to the controller board for the purpose of monitoring the incoming line voltage and for detecting phase loss conditions, sags, etc.




If the wires from the divider board are unplugged from TB10 on the controller board, the controller board's internal resistors are no longer in the circuit and the voltage at the wires on this plug will increase to much more than the normal 0.4 VAC that is supplied to the controller board.

This is an excellent example of a case where we can use ohm's law and understand what is happening based on our knowledge of series and parallel resistors. Below is a diagram showing the resistors on the divider board and the resistors, which are internal to the controller board.

When the circuit is connected to TB10, we have three 866-ohm resistors, which are in parallel with the three 267K ohm resistors on the divider board. The combined resistance for each phase is $267,000 \times 866 / (267,000 + 866) = 863.2$ ohms. Therefore we essentially have three 5 megohm resistors connected in series with three 863.2-ohm resistors. The voltage drops as the ratio of these two values. On a phase to ground basis the incoming voltage for a 4160-volt starter is 2300 VAC nominal. Using the ratio of these two resistances, we determine the voltage at TB10 (connected) to be $863.2 / (5,000,000 + 863.2) \times 2300 = 0.397$ VAC. This is the voltage you will measure at TB10 from phase to ground with 4160 volts phase to phase applied at the input to the starter.

Now consider what happens if the cable is unplugged from the controller board. We have 2300 VAC across just two resistors in series. The voltage present at the junction of the two resistors is $267,000 / (5,000,000 + 267,000) \times 2300 = 116.6$ VAC. If you disconnect the plug from TB10 on the controller board, and measure the voltage from each wire of the plug to ground, you will see 116.6 VAC with 4160 volts phase to phase at the input to the starter.



LD11777

FIG. 18 – DIVIDER / CONTROLLER RESISTORS

SECTION 8 – INSTALLATION

INSPECTION

Remove any transit packing and inspect the unit to ensure that all components have been delivered and that no damage has occurred during transit. If any damage is evident, it should be noted on the carrier's freight bill and a claim entered. Any major damage must be reported to your local YORK representative.

General

Before installing the starter, ensure:

- The starter is the correct voltage and current rating for the motor being started.
- All of the installation safety precautions are followed.
- The correct power source is available.
- The installation site meets all environmental specifications for NEMA 1.
- The chiller being started is ready to be started.
- Any power factor correction capacitors (PFCCs) if installed, are located on the power source side of the starter and not on the motor side.
- Ensure that the starter is positioned so that the cabinet door has ample clearance, and all of the controls are accessible.



Failure to remove power factor correction or surge capacitors from the load side of the starter will result in serious damage to the starter which will NOT be covered by the starter's warranty. The capacitors must be powered from the line side of the starter. An auxiliary contact can be used to energize the capacitors after the motor has reached full speed.

SAFETY PRECAUTIONS

To ensure the safety of the individuals installing the starter, and the safe operation of the starter, observe the following guidelines:

- Ensure that the installation site meets all of the required environmental conditions.
- **LOCK-OUT/TAG-OUT ALL SOURCES OF POWER!**

- Follow all NEC (National Electrical Code) and/or C.S.A. (Canadian Standards Association) standards.
- Remove any foreign objects from the interior of the enclosure.
- Ensure that wiring is installed properly by a qualified electrician.
- Ensure that the individuals installing the starter have proper personal protective equipment (PPE).

STARTER LOCATION

The standard YORK MV-SSS is intended for indoor installations only. The cabinet is NEMA 1 rated. You should allow for 6" of clearance on either side of the starter and across the back of the starter enclosure. Ensure that the starter is positioned so that the cabinet door(s) has ample clearance, and all of the controls are accessible (36" minimum). There should be 24" of clearance above the starter cabinet (see FIG. 21 & 22). If the 3 phase Oil Pump Transformer option is selected please allow for an additional 24" of clearance above the Transformer.


The temperature range for operation is 32° F to 104° F (0°C to 40°C), with humidity not to exceed 95%, non-condensing. If the location is such that moisture could be permitted to condense on components inside the MV-SSS, it will be necessary to add cabinet heaters to keep the moisture out. Failure to prevent condensation inside the starter cabinet could result in serious electrical failure which is NOT covered by warranty. In cases where the application is greater than 5000' (1524m) above sea level, the starter will need to be de-rated. For additional details about de-rating the unit contact YORK marketing.

ELECTRICAL CONNECTION

The following connection recommendations are intended to ensure safe and satisfactory operation of the unit.




Failure to follow the recommendations could cause harm to persons, or damage to the unit, and may invalidate the warranty.



36" CABINET
BOTTOM ENTRY

36" CABINET
TOP ENTRY



FRONT INTERIOR VIEW

FRONT INTERIOR VIEW

LD12116

FIG. 22 – 36" CABINET ELECTRICAL CONNECTIONS / UNIT CLEARANCES





FIG. 23 – 72" CABINET ELECTRICAL CONNECTIONS / UNIT CLEARANCES

SECTION 9 – STARTER FAULTS

The Medium Voltage Solid State Starter (MV-SSS) controller board, in addition to generating firing pulses for the SCRs, also continually checks status of the three power stack assemblies, monitors for system parameters such as overcurrent and undervoltage, and communicates status and data back to the YORK OptiView panel for display and annunciation. Decisions about starter faults are made at the MV-SSS controller board. In the event of a problem, the MV-SSS controller opens the motor controller contacts which cause 120 VAC to drop out on wire #16 going back to the OptiView. At the same time, the controller board sends a fault message to the OptiView via the modbus connection.

There are many individual MV-SSS faults that can be detected. Some of these are combined together into a single generic OptiView panel message. The list below shows all the possible MV-SSS faults, and the associated OptiView panel message that is generated. The individual MV-SSS fault is also displayed on the controller board inside the low-voltage section of the MV-SSS cabinet (see FIG. 23). The MV-SSS controller board will display “F_XX”, where XX is a two-digit value representing the MV-SSS fault.



LD11907

FIG. 24 – CONTROLLER BOARD FAULT MESSAGE

TABLE 2 – FAULT MESSAGES

OPTIVIEW PANEL MESSAGE	MV-SSS CONTROLLER BOARD DISPLAY	MV-SSS FAULT DESCRIPTION
MV-SSS - 105% Overload	31	Overcurrent, motor current exceeded 105% FLA for 40 seconds.
MV-SSS - Contactor Fault	48	Bypass Contactor Fault, aux. contacts do NOT match contactor status.
	49	In-line Contactor Fault, aux. contacts do NOT match contactor status.
MV-SSS - Control Board	51	Current Sensor Offset, an abnormal current is detected at power up.
	52	Burden Switch was changed while the motor was running.
	94	Illegal Software State, program error detected on the controller board.
	95	Parameter Storage Loss, values in memory are invalid at power up.
	96	Illegal Instruction Trap, a program instruction error occurred on the controller board.
	97	Software Watchdog, the program has gotten off path and is NOT running properly.
	98	Spurious Interrupt, an interrupt has occurred that is NOT normally utilized by the program.
	99	Program Storage Fault, the checksum test failed at power up.

TABLE 2 – FAULT MESSAGES (CON'T)

OPTIVIEW PANEL MESSAGE	MV-SSS CONTROLLER BOARD DISPLAY	MV-SSS FAULT DESCRIPTION
MV-SSS - Disconnect Fault	46	Disconnect Open, feedback indicates the switch is opened while running.
MV-SSS - Failed SCR	40	An Open or Shorted SCR has been detected.
MV-SSS - Ground Fault	38	Ground Fault current exceeds 50% FLA for 3 seconds.
MV-SSS - Heatsink High Temperature - Running	71	Stack Overtemperature Running, the temperature exceeded 194°F (90°C) while running. A Klixon® device on one of the 3 stacks has opened its circuit.
MV-SSS - Heatsink High Temperature - Stopped	72	Stack Overtemperature Stopped, the temperature exceeded 194°F (90°C) while stopped. A Klixon® device on one of the 3 stacks has opened its circuit.
MV-SSS - High Supply Line Voltage	24	High Line L1 to L2, greater than 13.2% above rated for 20 seconds.
	25	High Line L2 to L3, greater than 13.2% above rated for 20 seconds.
	26	High Line L3 to L1, greater than 13.2% above rated for 20 seconds.
MV-SSS - High Instantaneous Current	30	A single sample of motor current was higher than the maximum amps for the starter.
	32	Current exceeded 115% of maximum programmed inrush for 1 second.
MV-SSS - Logic Board Power Supply	50	Control Power is Low, as determined at the Controller board.
MV-SSS - Low Supply Line Voltage	21	Low Line L1 to L2, less than 19% below rated for 20 seconds.
	22	Low Line L2 to L3, less than 19% below rated for 20 seconds.
	23	Low Line L3 to L1, less than 19% below rated for 20 seconds.
MV-SSS - Motor or Starter Current Imbalance	37	Current Imbalance, greater than 30% difference between phases for 45 seconds. This fault is inhibited for the first 45 seconds, and when motor current is below 80% FLA.
MV-SSS - Phase Loss	27	Phase Loss, a single phase dropped more than 30% below the rated value.
	28	No Line Voltage detected at Voltage Divider input to TB10.
MV-SSS - Phase Rotation	10	The incoming phase rotation is not ABC.
MV-SSS - Power Fault	34	Undercurrent, one of the phases has dropped below 10% FLA for 2 cycles.
	39	Motor Current dropped to below 25% FLA for 1/2 second while running.
MV-SSS - Run Signal	68	Run Interlock, both hard-wired and serial run commands were NOT present within 5 seconds.
MV-SSS - Serial Communications	82	Network Timeout, no modbus communications for more than 60 seconds.
(NOT reported on OptiView panel)	54	BIST Abnormal Exit - BIST was exited before completing all tests.

**DETAILED EXPLANATION OF MV-SSS
CONTROLLER BOARD DISPLAYS –**

10 – Phasing NOT ABC – The incoming phase rotation is sensed by the three signals derived from the voltage divider and applied to the Controller board at connector TB10.

21 - Low Supply Line L1 to L2 – The incoming line voltage has dropped below the threshold as detected at the signal applied to the Controller board at TB10. The threshold is as follows:

4160 Volt Starters – 3370 VAC
3300 Volt Starters – 2673 VAC
2300 Volt Starters – 1863 VAC

22 – Low Supply Line L2 to L3 – The same as above for L1 to L2.

23 – Low Supply Line L3 to L1 – The same as above for L1 to L2.

24 – High Supply Line L1 to L2 – The incoming line voltage has exceeded the threshold as detected at the signal applied to the Controller board at TB10. The threshold is as follows:

4160 Volt Starters – 4713 VAC
3300 Volt Starters – 3739 VAC
2300 Volt Starters – 2606 VAC

25 – High Supply Line L2 to L3 – The same as above for L1 to L2.

26 – High Supply Line L3 to L1 – The same as above for L1 to L2.

27 – Phase Loss – A single-cycle phase loss is detected on any individual phase as detected at TB10. To be detected, the line-to-line voltage must drop to below 30% of the nominal value. This fault only occurs when the motor is running, it is ignored when the motor is stopped.

28 – No Line Voltage – This fault occurs when the starter receives a command to start, but no line voltage is detected at TB10.

30 – Instantaneous Overcurrent – The starter has detected a single sample of motor current which is in excess of the starter's maximum rating.

31 – 105% Overcurrent – The motor current has exceeded 105% of full-load amps (FLA) for 40 seconds.

32 – High Short Term Current – The motor current has exceeded 115% of the programmed inrush current for 1 second.

34 – Undercurrent – One or more phases of motor current has dropped below 10% of FLA for 2 line-cycles. This fault is inhibited for the first 4 seconds of starting, and until all phase currents have reached 25% FLA.

38 – Ground Fault – The ground fault current has been determined to have exceeded 50% of motor FLA for 3 seconds. There is no device measuring current to ground. This is done by looking at all three motor currents, and calculating the instantaneous sum of all three. Recognize that at any given time, the current passing in the direction toward the motor must equal any currents coming back from the motor in the other phases. The net sum of all three instantaneous currents (with attention to polarity) is always zero. If at any time the sum is not zero, this would indicate that some current passing toward the load is not returning to the starter, but is leaking off to ground.

39 – No Current at Run – This fault occurs if the motor current is less than 25% FLA for ½ a second.

40 – Failed SCR – This fault indicates an open or shorted SCR has been detected. The controller board looks at line voltage and motor current, and determines if an SCR is open or shorted based on analysis of the voltage and current waveforms and knowing what SCR device should be turned on at any given time. The controller does not indicate which SCR was detected to have a problem. It is necessary to check the devices with an ohmmeter and/or gate/hi-pot tester.

46 – Disconnect Open – There is a micro-switch mounted on a cam attached to the main power disconnect or isolation switch. This micro-switch advises the controller board of the status of this isolation switch. If this switch provides indication that the main power disconnect was opened while the motor was running, this fault will be generated.

48 – Bypass Fault – The bypass vacuum contactor has an auxiliary switch mounted on it and wired back to the controller board at DI1. The controller board also controls the status of the bypass vacuum contactor through an output from R3 on this board. If this switch status does not match the status of R3, this fault is generated.

49 - In-line Fault – The in-line vacuum contactor has an auxiliary switch mounted on it and wired back to the controller board at DI2. The controller board also controls the status of the bypass vacuum contactor through an output from R2 on this board. If this switch status does not match the status of R2, this fault is generated.

50 – Control Power Low – This fault is generated when the 120 VAC control power drops below 90 VAC.

51 – Current Offset Sensor – The controller board performs a diagnostic at power up which checks the current feedback circuits on the controller board. If this test fails, this message is generated.

52 – Burden Switch Error – This fault occurs if the CT SW6 switch on the controller board is changed while the motor is running. Changing the switch while running can cause damage to the controller board.

54 – BIST Abnormal Exit – This fault occurs if the BIST routine is stopped before it is able to complete all of the BIST tests. This can be caused by the disconnect closing, line voltage being detected, or current being detected.

68 – Run Interlock – As with other YORK products, the MV-SSS requires both a hard-wired start command and a serial communications run command. If both are not received within 5 seconds, this message is generated.

71 – Stack Overtemperature Running – One of the Klixon[®] thermal switches has opened on one of the heatsinks while the chiller motor is running.

72 - Stack Overtemperature Stopped – One of the Klixon[®] thermal switches has opened on one of the heatsinks while the chiller motor is stopped.

82 – Network Timeout – This fault occurs if the MV-SSS controller board does not receive a modbus communication from the OptiView panel for more than 60 seconds.

94 – Illegal Software State – This fault occurs if the controller board determines that the software has performed an unexpected operation.

95 – Parameter Storage Loss – During power up the controller board checks all values stored in memory and if any are determined to be invalid, this message is generated. This can occur at times when software versions are changed, and values from the old software are left in memory locations that are no longer used by the new software. If this should occur, hold the “Param” and “Enter” keys down together while applying power to the board. This will clear out the memory.

96 – Illegal Instruction Trap – This fault occurs if the controller board determines the software has performed an instruction that is not part of the normal program.

97 – Software Watchdog – The software program performs tasks in sequence, and after all tasks are performed, the program goes back to the first instruction and begins over again. One of the programmed tasks is to essentially “touch base” as we might do in a game of tag. If the software does NOT "touch base" before going off to follow the list of tasks once again, it generates this fault. This assures that the software program continues to run the program over and over. If the program becomes locked up or if it should get side-tracked, it fails to "touch base" and the controller board shuts down on this fault.

98 – Spurious Interrupt – The controller board has detected an interrupt that was not generated by the program.

99 – Program Storage Fault - The checksum test failed at power up. Check to see that the proper program is loaded to the controller board.

SECTION 10 – TROUBLESHOOTING

SAFETY FIRST!



Under no circumstances should energized troubleshooting be done with cabinet doors open, exposing high voltage components.

All troubleshooting is to be carried out after assuring that the upstream power is de-energized and locked out. Two types of testing may be performed – statistic testing with no power applied at all, and testing performed with just 120 VAC applied to the starter from an extension cord. There is a built-in self test (BIST) routine programmed into the starter controller to enable low voltage operation of all components in a simulated run condition.

The first step in troubleshooting is to remove power from the equipment. It is preferred to open the supply at an upstream motor control center or disconnect. This assures there is no power present at the top section of the starter cabinet. Proper lock-out and tag-out procedures must be followed.

If the upstream power cannot be shutdown, it is satisfactory to remove power at the starter's isolation switch by operating the handle on the front of the starter. Regardless, the front panel isolation switch must always be opened to gain access to the medium voltage internal compartment of the starter cabinet. The front door is interlocked to this switch handle and cannot be opened until the isolation switch has been opened.

Once the isolation switch is in the open position, before opening the starter door, verify the opening of the contacts in all three phases by visually inspecting the switch blades as seen through the clear Lexan viewing window in the front of the starter cabinet. Use a flashlight if necessary.



Unless power has been interrupted upstream, there is still voltage present on the top side of the isolation switch!

The upper cabinet access panel is bolted in place and should never be removed without de-energizing upstream power.


With the isolation switch in the open position and having visually verified the open status of the switch blades, you can now open the lower cabinet door which provides access to the high voltage components.



Before reaching into the starter cabinet, further verify that power is no longer present in the starter by testing with a non-contact type voltage indicator, such as a hot-stick.

The hot-stick device will give a visual and/or audible indication when there is voltage present within a few inches of the end of the hot-stick. If any indication of voltage is perceived, check for the possibility of a second source of power being applied to the starter.

Keep in mind that if 120 VAC from an outside source is applied to control circuits which are normally powered by the starter's own control power transformer – this 120 VAC source can back-feed through the control power transformer and create 4160 volts on the transformer primary. This can cause 4160 volts to be present inside the starter, even if the main supply to the starter is interrupted! Once you have assured there is no longer any voltage present, you can proceed to troubleshooting the starter.



Below the power isolation switch there is a mechanical linkage which interfaces to a bracket on the back of the cabinet door. This linkage is to assure the door is again closed before the isolation switch can be moved to the closed position. Never try to disable or circumvent this linkage.

INITIAL INSPECTION

The first step in actual troubleshooting is to visually examine the interior of the starter and its components. Any signs of arcing or carbon deposits can give an initial indication of where the problem is located. Also note if there is any odor of burning components. If nothing abnormal is detected, proceed to check the power section of the starter using an ohmmeter, measuring phase to phase and phase to ground. Also check all fuses with the ohmmeter to determine if any fuse is open. If nothing is found during the visual inspection or ohmmeter testing, then it is likely best to proceed to the built-in self-test (BIST).

BUILT-IN SELF-TEST (BIST)

To enable the BIST, it is necessary to connect a source of 120 VAC to the control circuits. In the upper right corner of the low-voltage section, there is a 2-position test switch (see FIG. 5). When this switch is moved to the “TEST” position, the internal control power transformer is disconnected from the control circuits, and 120 VAC can be applied to the starter using an extension cord inserted into the male 120 VAC test plug adjacent to the test switch. The test switch assures that 120 VAC is not permitted to back-feed through the control power transformer and cause 4160 volts to be present on components.

With 120 VAC applied in the “TEST” mode, you can verify power is present on the circuit boards. You should see a “CPU” LED flickering on the controller board. There should also be a red “Power OK” LED on the Fiber Optic Transmitter board. Each of the Gate Driver boards should exhibit a green status “OK” LED. If any of these LEDs is not present, check for presence of voltage to each board.

The BIST routine is initiated by entering a password into the controller board. To do so, proceed as follows:

Press “Param” on the Controller board – “P1” should show on the display.
 Press “Up” to get “P2” on the display.
 Press “Enter” – you should see “OFF” on the display.
 Press “Enter” again – you should get a blinking cursor at the left most position.
 Press “Up” to get a “0” in the first position.
 Press “Enter” to move to the 2nd position.
 Press “Up” 6X to get a “5” in the 2nd position.
 Press “Enter” to move to the 3rd position.
 Press “Up” 2X to get a “1” in the 3rd position.
 Press “Enter” to move to the 4th position.
 Press “Down” 1X to get a “9” in the 4th position.
 Press “Enter”
 Press “Up” or “Down” to scroll through lines until “H6” is on the display.
 Press “Enter”
 Press “Up” or “Down” to set the value of H6 to “7”.
 Press “Enter” to begin the BIST

The BIST self-test executes as follows:

- 1- The in-line vacuum contactor pulls in for 3 seconds.
- 2- The bypass vacuum contactor pulls in for 3 seconds.
- 3- The SCR gates are fired sequentially in the following order:
 - a. L1 + for 5 seconds, L1- for 5 seconds
 - b. L2 + for 5 seconds, L2- for 5 seconds
 - c. L3 + for 5 seconds, L3- for 5 seconds
- 4- The SCRs are all fired simultaneously for 60 seconds.

While the BIST test is executing, it is possible to visually confirm operation of contactors and SCR gate signals. It is also possible to connect an ohmmeter across the contacts of the vacuum contactor assemblies to confirm that the vacuum bottles contacts are closing. Furthermore, it is possible to view each SCR gate LED to assure the signal is getting to each gate driver board and is present at the red and white gate wires of each SCR device.

If none of the gate LEDs in a given phase are illuminating, check for 28 volt power to that phase. If any single gate LED is not illuminating, try swapping fiber optic cables with an adjacent SCR, just for a test. If the other SCR now fails to illuminate, the problem is in the fiber optic cable, transmitter board, or controller. If the same LED fails to light, the problem is in the gate driver or could be a shorted SCR. SCRs can be checked for shorted gates using an ohmmeter.

During the BIST test, the following messages may be displayed on the controller:

b od	BIST, open disconnect	BIST will not run until the isolation switch is open.
b rl	BIST, remove line	BIST will not run until line voltage is removed.
b ic	BIST, in-line closed	The in-line test is in progress, the run relay is on.
b io	BIST, in-line open	The in-line test is in progress, the run relay is off.
b bc	BIST, bypass closed	The bypass test is in progress, the UTS relay is on.
b bo	BIST, bypass open	The bypass test is in progress, the UTS relay is off.
b gs	BIST, gate sequence	The sequential gate firing test is in progress.
b ga	BIST, gates all	The all-gates firing test is in progress.
F54	Fault 54	BIST was abnormally exited.
F48	Fault 48	The bypass contactor test failed.
F49	Fault 49	The in-line contactor test failed.
b --	BIST complete	All test have been completed.

SCR TESTING AND REPLACEMENT

The SCR devices in this product are very similar to the SCRs used in YORKS's low-voltage solid-state starter products. These "hockey-puck" like devices can be tested using the same test equipment. Gate tests should yield a result in the range of 0.7 to 2.0 volts, and 20 to 150 mA.

If the gate test results are very low, check the gate to cathode resistance for a shorted condition. Normal gate resistance should be in the order of 10 ohms. The acceptable range for gate resistance is 8 ohms to 50 ohms. These SCR devices can be further tested using an ohmmeter measuring from cathode to anode. The leakage resistance with the snubber disconnected should be greater than 50,000 ohms (50K ohms).

High-voltage breakdown or "hi-pot" testing should be conducted at 1400 volts DC across the anode to cathode. Leakage current should be well below 10 mA. Typically leakage is less than 2 mA. If leakage is detected, make certain the snubber circuits are disconnected from the device. Most cases of high leakage are due to current leaking across the snubber capacitors on the assembly.

Also be aware that if the motor leads are still connected, one leaky stack assembly can show up as being bad in more than one phase. This occurs because the motor is like a dead short across the output of the MV-SSS, with a control power transformer and/or oil pump transformer connected across the input side of the SCR stacks, this causes one bad stack assembly to be in parallel with one or more other stack assemblies. If you find multiple stacks testing bad, remove the motor wires and re-test all three phases.

Should it become necessary to replace SCR devices, this is accomplished by changing a complete SCR pole assembly. There are several reasons for this. The most important reason is that multiple SCRs in a given pole assembly must be very closely matched so that all the SCRs in the same pole turn on together at the exact same instant. If this does not occur, it can cause the voltage across an individual SCR to be much greater than the SCR device's rating. It would be very difficult to stock one size of SCR in many different turn-on sensitivities, and to try to match the sensitivity of existing SCRs in a poles assembly already in the field.

Another reason we replace complete pole assemblies is that removal and replacement of the SCR "hockey puck" device is a very tedious task that is best accomplished with the heatsinks and SCRs mounted in a jig. Application of torque to the SCR clamping bolts must be done such that equal pressure is exerted on the SCR from both sides of the clamp. Also, these clamps have built-in torque gauges that can be damaged if not handled properly.

The built-in torque gauges look like a bolt, nut, and washer located in the middle of the SCR clamping device, between the two long clamping bolts.



Do not loosen, tighten, or in any way disturb this middle nut and bolt!

If the position of this nut on the center bolt is changed, the gauge will be out of calibration and the whole SCR clamping device must be discarded. These components are designed to spin freely when the proper pressure has been exerted by the tension on the two longer bolts that hold the clamping device together. On a completely new assembly it is normal to find this middle bolt and nut appearing to be very loose!

When making electrical connections to the SCR heatsink assembly, make certain the heatsink surface is clean, and then apply a very thin coating of electrical joint compound like Alcoa EJC#2. This will prevent oxidation from forming on the aluminum heatsink surfaces, eventually causing overheating of the connection due to a build up of resistance.

TESTING THE STARTER ON LOW VOLTAGE

If the fault messages, evaluation of LED status, BIST testing, and SCR testing do not point clearly to the cause of the problem, the ultimate test is to convert the MV-SSS to a low voltage (480 VAC) starter and wire it to a 480 volt source and 480 volt motor to continue testing. This requires that the medium voltage incoming and output wiring be disconnected from the MV-SSS.



The upstream supply must first be properly locked out and tagged out.

The three incoming power supply leads should then be disconnected from the MV-SSS input connections, and the three phases tied together and to ground as a safety precaution. A rubber jacketed cable can be routed from a temporary 480 volt source to the input to the MV-SSS.

The MV-SSS output wiring must be disconnected as well. A small 480 volt test motor (10HP to 20HP) can be wired to the starter output. Be certain to also run a ground wire from the test motor to the starter cabinet ground. Also, a three phase fuse block with 20 amp fuses should be wired between the starter and the motor. This is done to protect against a failure occurring in the motor. Should the test motor go to ground, the MV-SSS will not detect fault-level current in the test motor. The test motor could be conducting 250 amps and the motor windings could be starting to burn, and the MV-SSS would not see anything unusual due to the small size of the test motor compared to the size of the starter.

It is necessary to supply 120 VAC control power from an alternate source. With only 480 VAC on the starter input, the internal control power transformer will step this down by the ratio of 35:1 so this transformer must be disconnected and 120 VAC supplied from an alternate source. Remove the primary and secondary fuses from the control power transformer in the bottom section of the cabinet. A temporary source of 120 VAC can be applied from an extension cord.

Before testing can be conducted, it is necessary to make one more change to convert the MV-SSS to operate at 480 VAC. The controller board must be fooled into thinking there is 4160 volts present at the input to TB10. This is accomplished by installing shunt resistors in parallel to the three 5 megohm resistors on the voltage divider board. If you refer back to the section on the divider board, you will recall that the resistors internal to the controller board combine with three resistors on the divider board to create 863.2 ohms in parallel in each phase. This is in series with three 5 megohms resistors.

To cause the controller board to see 0.39 VAC at TB10, we need to lower the value of the 5 megohms resistors. Using the formula for parallel resistance we find that three 680,000 ohm resistors in parallel with the three 5 megohm resistors will yield just under 600K ohms total. This value in series with 863.2 ohms will provide 0.39 VAC measured phase to ground at TB10 with 480 VAC (277 phase to ground) applied at the input. If 680K ohm resistors are not readily available, any value within 10% should work. It is also possible to put other values of resistors in series to achieve the needed 680K.

Having completed all the above tasks, you can now run the MV-SSS with the test motor. You can conduct any of the normal types of tests you might perform on a low-voltage solid-state starter, using any of the normal 600 volt rated test equipment. Keep in mind that you still have 480 volts present, and all the normal safety precautions for 480 volt equipment should be observed. Proper personal protective equipment (PPE) should be worn, and all OSHA and NFPA70e requirements must be met.

TABLE 3 – GENERAL TROUBLESHOOTING

MOTOR WILL NOT START, NO OUTPUT TO MOTOR.

STATUS	CAUSE	SOLUTION
Fault Displayed	Shown on Display	See Fault Code table
Watchdog LED is ON	CPU card problem	Consult factory
Display is blank	Control voltage is absent	Check for proper control voltages
	Ribbon cables	Check ribbon cables
Stopped	Control devices	Check control devices
	Display buttons disabled	Enable display buttons
No line	Missing at least 1 phase of main power.	Check Power system.

MOTOR ROTATES BUT DOES NOT REACH FULL SPEED.

STATUS	CAUSE	SOLUTION
Fault displayed	Shown on display	See Fault Code table
Accel or Running	Mechanical Problems	Check for load binding / Check Motor
	Inadequate current limit settings	Increase max. current setting
	Abnormally low line voltage	Fix line voltage problems

MOTOR STOPS WHILE RUNNING.

STATUS	CAUSE	SOLUTION
Fault displayed	Shown on display	See Fault Code table
Display is blank	Control voltage is absent	Check control wiring and voltage
Stopped	Control devices	Check control system

OTHER SITUATIONS.

STATUS	CAUSE	SOLUTION
Power metering not working, or incorrect display on OptiView.	CT installed wrong	Fix CT installation. White dot to line side.
Motor current or voltage display on OptiView fluctuates with steady load.	Motor	Verify motor is running correctly.
	Power connection	Shut off all power and check connections.
	SCR Fault	Check SCR devices, Gate Drivers, and outputs from Fiber Optic Transmitter Board
Erratic Operation	Loose connections	Shut off all power and check connections.
Accelerates too quickly	Maximum current setting	Decrease Maximum current setting.
	Improper FLA setting	Check FLA setting.
Accelerates too slowly	Maximum current setting	Increase Maximum current setting.
	Improper FLA setting	Check FLA setting.
Motor overheats	Duty cycle	Allow for motor cooling between starts.
	High ambient	Provide better ventilation.
	Too long acceleration time	Reduce motor load.
	Wrong overload setting	Select correct overload setting.
Motor short circuit	Wiring fault	Identify fault and correct.
	Power factor correction capacitors (PFCC) on starter output	Move PFCC to line side of starter.



P.O. Box 1592, York, Pennsylvania USA 17405-1592
Copyright © by JOHNSON CONTROLS, INC. 2006
Form 160.00-M5 (706)
New Release

(717) 771-7890
www.york.com

Subject to change without notice. Printed in USA
ALL RIGHTS RESERVED