



## POWER PANELS 50-95 TON (CONT'D)

### 60 - 65 TON UNIT CONTROL PANEL AND POWER PANEL (100.50-RP1 PAGE 23)

Item	Qty	Description	See Figure	208V	230V	380V	400V-50 Hz	460V	575V
5A	2	Contactors	9	024-34310-000	024-34310-000	024-34308-000	024-34307-000	024-34307-000	024-34306-000
5B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-31816-000	024-31816-000	024-33182-000
5C	2	Surge Suppressor	9	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02104-000
5E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
6A	2	Contactors	9	024-34310-000	024-34310-000	024-34308-000	024-34307-000	024-34307-000	024-34306-000
6B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-31816-000	024-31816-000	024-33182-000
6C	2	Surge Suppressor	9	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02104-000
6E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
8A	4	Surge Suppressor	9	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000
8B	4	Contactors	9	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000
8C	2	Fuseblock	9A	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000
8D	6	Fuse, 600V	9A	025-34142-000	025-34142-000	025-38396-000	025-37618-000	025-38396-000	025-37613-000
11A	2	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
11B	2	Aux Contact Block	9	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000
11C	See Below								
13A	2	Fuse, 600V	9A	025-34430-000	025-37629-000	025-35902-000	025-37659-000	025-37611-000	025-35911-000
13B	1	Fuseblock	9A	025-34427-000	025-34427-000	025-34427-000	025-35667-000	025-34427-000	025-34427-000
13D	1	Transformer	9	025-38388-000	025-38387-000	025-38390-000	025-38390-000	025-38387-000	025-38389-000
13E	1	Fuseblock	9A	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000
13F	1	Fuse, 10 Amp	9A	025-28966-006	025-28966-006	025-28966-006	025-28966-006	025-28966-006	025-28966-006
13G	1	Fuse, 4 Amp	9A	025-37626-000	025-37626-000	025-37626-000	025-37626-000	025-37626-000	025-37626-000
14	1	Smart Relay	9	025-36414-001	025-36414-001	025-36414-001	025-36414-001	025-36414-001	025-36414-001
15	1	Relay Expansion	9	025-36403-000	025-36403-000	025-36403-000	025-36403-000	025-36403-000	025-36403-000
-	4	Aux. Contact Block	-	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000
-	1	Terminal Board	-	025-36388-003	025-36388-003	025-36388-003	025-36388-003	025-36388-003	025-36388-003
25	1	Thermostat	9, 9A	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001

#### MOD A MANEUROP COMPRESSORS

11C	2	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
-----	---	----------------	---	---------------	---------------	---------------	---------------	---------------	---------------

#### MOD B COPELAND COMPRESSORS

11C	2	Relay, Control	9	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000
	2	Relay, Control	9	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000
	2	Surge Suppressor	9	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000

## POWER PANELS 50-95 TON (CONT'D)

### 70 - 75 TON UNIT CONTROL PANEL AND POWER PANEL(100.50-RP1 PAGE 24)

Item	Qty	Description	See Figure	208V	230V	380V	400V-50 Hz	460V	575V
5A	2	Contactora	9	024-34309-000	024-34308-000	024-34306-000	024-34305-000	024-34305-000	024-34304-000
5B	2	Over Load (OL)	9	025-34488-000	024-31816-000	024-33182-000	024-33181-000	024-33181-000	024-33180-000
5C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000
5E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
6A	2	Contactora	9	024-34309-000	024-34308-000	024-34306-000	024-34305-000	024-34305-000	024-34304-000
6B	2	Over Load (OL)	9	025-34488-000	024-31816-000	024-33182-000	024-33181-000	024-33181-000	024-33180-000
6C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02104-000	031-02104-000	031-02104-000	031-02100-000
6E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
7A	2	Contactora	9	024-34309-000	024-34309-000	024-34307-000	024-34306-000	024-34306-000	024-34305-000
7B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-33182-000	024-33182-000	024-33181-000
7C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02104-000	031-02104-000	031-02104-000
7E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
8A	6	Surge Supressor	9	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000
8B	6	Contactora	9	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000
8C	3	Fuseblock	9A	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000
8D	9	Fuse, 600V	9A	025-34142-000	025-34142-000	025-38396-000	025-37618-000	025-38396-000	025-37613-000
11A	2	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
11B	2	Aux Contact Block	9	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000
11C	See Below								
13A	2	Fuse, 600V	9A	025-34435-000	025-34435-000	025-34431-000	025-37653-000	025-35902-000	025-37611-000
13B	1	Fuseblock	9A	025-34427-000	025-34427-000	025-34427-000	025-35667-000	025-34427-000	025-34427-000
13D	1	Transformer	9	025-38393-000	025-38391-000	025-38391-000	025-38392-000	025-38391-000	025-35652-000
13E	1	Fuseblock	9A	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000
13F	1	Fuse, 12 Amp	9A	025-38360-000	025-38360-000	025-38360-000	025-38360-000	025-38360-000	025-38360-000
13G	1	Fuse, 5 Amp	9A	025-35689-000	025-35689-000	025-35689-000	025-35689-000	025-35689-000	025-35689-000
14	1	Smart Relay	9	025-36414-002	025-36414-002	025-36414-002	025-36414-002	025-36414-002	025-36414-002
15	2	Relay Expansion	9	025-36403-000	025-36403-000	025-36403-000	025-36043-000	025-36403-000	025-36403-000
-	4	Aux. Contact Block	-	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000
-	1	Terminal Board	-	025-36416-000	025-36416-000	025-36416-000	025-36416-000	025-36416-000	025-36416-000
25	1	Thermostat	9, 9A	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001
<b>MOD A MANEUROP COMPRESSORS</b>									
11C	3	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
<b>MOD B COPELAND COMPRESSORS</b>									
11C	3	Relay, Control	9	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000
	3	Relay, Control	9	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000
	3	Surge Supressor	9	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000

## POWER PANELS 50-95 TON (CONT'D)

### 80 - 85 TON UNIT CONTROL PANEL AND POWER PANEL (100.50-RP1 PAGE 25)

Item	Qty	Description	See Figure	208V	230V	380V	400V-50 Hz	460V	575V
5A	2	Contactora	9	024-34309-000	024-34309-000	024-34307-000	024-34306-000	024-34306-000	024-34305-000
5B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-33182-000	024-33182-000	024-33181-000
5C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02104-000	031-02104-000	031-02104-000
5E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
6A	2	Contactora	9	024-34309-000	024-34309-000	024-34307-000	024-34306-000	024-34306-000	024-34305-000
6B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-33182-000	024-33182-000	024-33181-000
6C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02104-000	031-02102-000	031-02104-000
6E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
7A	2	Contactora	9	024-34309-000	024-34309-000	024-34307-000	024-34306-000	024-34306-000	024-34305-000
7B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-33182-000	024-33182-000	024-33181-000
7C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02104-000	031-02104-000	031-02104-000
7E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
8A	6	Surge Supressor	9	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000
8B	6	Contactora	9	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000
8C	3	Fuseblock	9A	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000
8D	9	Fuse, 600V	9A	025-34142-000	025-34142-000	025-38396-000	025-37618-000	025-38396-000	025-37613-000
11A	2	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
11B	2	Aux Contact Block	9	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000
11C	See Below								
13A	2	Fuse, 600V	9A	025-34435-000	025-34435-000	025-34431-000	025-37653-000	025-35902-000	025-37611-000
13B	1	Fuseblock	9A	025-34427-000	025-34427-000	025-34427-000	025-35667-000	025-34427-000	025-34427-000
13D	1	Transformer	9	025-38393-000	025-38391-000	025-38392-000	025-38392-000	025-38391-000	025-35652-000
13E	1	Fuseblock	9A	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000
13F	1	Fuse, 12 Amp	9A	025-38360-000	025-38360-000	025-38360-000	025-38360-000	025-38360-000	025-38360-000
13G	1	Fuse, 5 Amp	9A	025-35689-000	025-35689-000	025-35689-000	025-35689-000	025-35689-000	025-35689-000
14	1	Smart Relay	9	025-36414-002	025-36414-002	025-36414-002	025-36414-002	025-36414-002	025-36414-002
15	2	Relay Expansion	9	025-36403-000	025-36403-000	025-36403-000	025-36403-000	025-36403-000	025-36403-000
-	4	Aux. Contact Block	-	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000
-	1	Terminal Board	-	025-36416-000	025-36416-000	025-36416-000	025-36416-000	025-36416-000	025-36416-000
25	1	Thermostat	9, 9A	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001

#### MOD A MANEUROP COMPRESSORS

11C	3	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
-----	---	----------------	---	---------------	---------------	---------------	---------------	---------------	---------------

#### MOD B COPELAND COMPRESSORS

11C	3	Relay, Control	9	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000
	3	Relay, Control	9	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000
	3	Surge Supressor	9	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000

## POWER PANELS 50-95 TON (CONT'D)

### 90 - 95 TON UNIT CONTROL PANEL AND POWER PANEL (100.50-RP1 PAGE 26)

Item	Qty	Description	See Figure	208V	230V	380V	400V-50	460V	575V
5A	2	Contactora	9	024-34310-000	024-34310-000	024-34308-000	024-34307-000	024-34307-000	024-34306-000
5B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-31816-000	024-31816-000	024-33182-000
5C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02104-000
5E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
6A	2	Contactora	9	024-34310-000	024-34310-000	024-34308-000	024-34307-000	024-34307-000	024-34306-000
6B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-31816-000	024-31816-000	024-33182-000
6C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02101-000	031-02104-000
6E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
7A	2	Contactora	9	024-34309-000	024-34309-000	024-34307-000	024-34306-000	024-34306-000	024-34305-000
7B	2	Over Load (OL)	9	025-34488-000	025-34488-000	024-31816-000	024-33182-000	024-33182-000	024-33181-000
7C	2	Surge Supressor	9	031-02101-000	031-02101-000	031-02101-000	031-02104-000	031-02104-000	031-02104-000
7E	2	Ground Lug	9	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000	025-34455-000
8A	6	Surge Supressor	9	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000	031-02104-000
8B	6	Contactora	9	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000	024-34302-000
8C	3	Fuseblock	9A	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000	025-34185-000
8D	9	Fuse, 600V	9A	025-34142-000	025-34142-000	025-38396-000	025-37618-000	025-38396-000	025-37613-000
11A	2	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
11B	2	Aux Contact Block	9	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000	025-35694-000
11C	See Below								
13A	2	Fuse, 600V	9A	025-34435-000	025-34435-000	025-34431-000	025-37653-000	025-35902-000	025-37611-000
13B	1	Fuseblock	9A	025-34427-000	025-34427-000	025-34427-000	025-35667-000	025-34427-000	025-34427-000
13D	1	Transformer	9	025-38393-000	025-38391-000	025-38392-000	025-38392-000	025-38391-000	025-35652-000
13E	1	Fuseblock	9A	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000	025-35667-000
13F	1	Fuse, 12 Amp	9A	025-38360-000	025-38360-000	025-38360-000	025-38360-000	025-38360-000	025-38360-000
13G	1	Fuse, 5 Amp	9A	025-35689-000	025-35689-000	025-35689-000	025-35689-000	025-35689-000	025-35689-000
14	1	Smart Relay	9	025-36414-002	025-36414-002	025-36414-002	025-36414-002	025-36414-002	025-36414-002
15	2	Relay Expansion	9	025-36403-000	025-36403-000	025-36403-000	025-36403-000	025-36403-000	025-36403-000
-	4	Aux. Contact Block	-	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000	024-34320-000
-	1	Terminal Board	-	025-36416-000	025-36416-000	025-36416-000	025-36416-000	025-36416-000	025-36416-000
25	1	Thermostat	9, 9A	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001	025-36346-001


#### MOD A MANEUROP COMPRESSORS

11C	3	Relay, Control	9	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000	024-31885-000
-----	---	----------------	---	---------------	---------------	---------------	---------------	---------------	---------------

#### MOD B COPELAND COMPRESSORS

11C	3	Relay, Control	9	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000	024-31635-000
	3	Relay, Control	9	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000	024-33177-000
	3	Surge Supressor	9	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000	031-02107-000

## ELECTRIC HEAT POWER SUPPLY BOX KIT DISCONNECT SWITCH BOXES (100.50-RP1 PAGE 48)



*Fuse information can be located in Table 3 on page 55.*

### 380V-60V UNITS


Item	Qty	Description	50 Ton Single-Point Disc Sw 40 KW See Fig 19	50 Ton Single-Point Disc Sw 80-108 KW See Fig 19	60 Ton Single-Point Disc Sw 40 KW See Fig 18	60 Ton Single-Point Disc Sw 80-108 KW See Fig 19	50-90 Ton Single-Point Disc Sw 150-200 KW See Fig 18	70-90Ton Single-Point Disc Sw 80-108 KW See Fig 18
2A	1	MOLDED CASE SWITCH, 250A	024-30963-000	N/A	N/A	N/A	N/A	N/A
2A	1	MOLDED CASE SWITCH, 400A	N/A	024-25564-000	024-25564-000	024-25564-000	N/A	N/A
2A	1	MOLDED CASE SWITCH, 600A	N/A	N/A	N/A	N/A	N/A	024-25563-000
	1	OPERATOR MECH	024-31878-000	024-31878-000	024-31878-000	024-31878-000	024-31878-000	025-35695-000
	1	SHAFT, 19.69"	025-35696-000	025-35696-000	025-35696-000	025-35696-000	025-35696-000	025-35696-000
	1	HANDLE, PISTOL	025-35697-000	025-35697-000	025-35697-000	025-35697-000	025-35697-000	025-35697-000
3A	1	GROUND LUG	025-34085-000	025-34085-000	025-34086-000	025-34086-000	025-34086-000	N/A
3A	2	GROUND LUG	N/A	N/A	N/A	N/A	N/A	025-34089-000
5A	3	FUSEBLK, 1P, 200A	N/A	RAM	N/A	RAM	025-32521-000	RAM
5A	1	FUSEBLK, 3P, 100A	RAM	N/A	RAM	N/A	N/A	N/A
5D	1	GROUND LUG	025-34455-000	025-34088-000	025-34455-000	025-34088-000	025-34089-000	025-34088-000
8	1	GROUND LUG	N/A	025-34089-000	025-34085-000	N/A	N/A	N/A
8	2	GROUND LUG	025-34089-000	N/A	N/A	025-34089-000	025-34089-000	025-34085-000

### 400V-50V UNITS

Item	Qty	Description	50-60 Ton Single-Point Disc Sw 40 KW See Fig 19	50-60 Ton Single-Point Disc Sw 80-108 KW See Fig 18	50-90 Ton Single-Point Disc Sw 150-200 KW See Fig 18	70-90Ton Single-Point Disc Sw 80-108 KW See Fig 18
2A	1	MOLDED CASE SWITCH, 250A	024-30963-000	N/A	N/A	N/A
2A	1	MOLDED CASE SWITCH, 400A	N/A	024-25564-000	024-25564-000	N/A
2A	1	MOLDED CASE SWITCH, 600A	N/A	N/A	N/A	024-25563-000
	1	OPERATOR MECH	024-31878-000	024-31878-000	024-31878-000	025-35695-000
	1	SHAFT, 19.69"	025-35696-000	025-35696-000	025-35696-000	025-35696-000
	1	HANDLE, PISTOL	025-35697-000	025-35697-000	025-35697-000	025-35697-000
3A	1	GROUND LUG	025-34085-000	025-34085-000	025-34086-000	N/A
3A	2	GROUND LUG	N/A	N/A	N/A	025-34089-000
5A	3	FUSEBLK, 1P, 200A	N/A	RAM	025-32521-000	RAM
5A	1	FUSEBLK, 3P, 100A	RAM	N/A	N/A	N/A
5D	1	GROUND LUG	025-34455-000	025-34088-000	025-34089-000	025-34088-000
8	1	GROUND LUG	N/A	025-34089-000	025-34085-000	N/A
8	2	GROUND LUG	025-34089-000	N/A	N/A	025-34085-000

## ELECTRIC HEAT POWER SUPPLY BOX KIT

### DISCONNECT SWITCH BOXES (100.50-RP1 PAGE 49)



*Fuse information can be located in Table 3 on page 55.*

#### 460V UNITS

Item	Qty	Description	50-60 Ton Single-Point Disc Sw 40 KW See Fig 19	50-60 Ton Single-Point Disc Sw 80-108 KW See Fig 18	50-60 Ton Single-Point Disc Sw 150 KW See Fig 18	70-90 Ton Single-Point Disc Sw 80-150 KW See Fig 18	70-90 Ton Single-Point Disc Sw 200-250 KW See Fig 18
2A	1	MOLDED CASE SWITCH, 250A	024-30963-000	N/A	N/A	N/A	N/A
2A	1	MOLDED CASE SWITCH, 400A	N/A	024-30963-000	024-25564-000	N/A	N/A
2A	1	MOLDED CASE SWITCH, 600A	N/A	N/A	N/A	024-25563-000	024-25563-000
	1	OPERATOR MECH	024-31878-000	024-31878-000	024-31878-000	024-25563-000	024-25563-000
	1	SHAFT, 19.69"	025-35696-000	025-35696-000	025-35696-000	025-35696-000	025-35696-000
	1	HANDLE, PISTOL	025-35697-000	025-35697-000	025-35697-000	025-35697-000	025-35697-000
3A	1	GROUND LUG	025-34085-000	025-34085-000	025-34086-000	025-34089-000	025-34089-000
5A	1	FUSEBLK, 3P, 60A	RAM	N/A	N/A	N/A	N/A
5A	3	FUSEBLK, 1P, 200A	N/A	RAM	RAM	RAM	025-32521-000
5D	1	GROUND LUG	025-34455-000	025-34088-000	025-34088-000	025-34088-000	025-34089-000
8	2	GROUND LUG	025-34089-000	025-34089-000	025-34089-000	025-34085-000	025-34085-000

#### 575V UNITS

Item	Qty	Description	50-60 Ton Single-Point Disc Sw 40 KW See Fig 19	50-80 Ton Single-Point Disc Sw 80 KW See Fig 19	50-60 Ton Single-Point Disc Sw 108 KW See Fig 18	50-80 Ton Single-Point Disc Sw 108-150 KW See Fig 18	70-90 Ton Single-Point Disc Sw 200 KW See Fig 18	90 Ton Single-Point Disc Sw 108-150 KW See Fig 18	90 Ton Single-Point Disc Sw 250 KW See Fig 18
2A	1	MOLDED CASE SWITCH, 250A	024-30963-000	N/A	N/A	N/A	N/A	N/A	
2A	1	MOLDED CASE SWITCH, 400A	N/A	024-30963-000	024-30963-000	024-35563-000	N/A	N/A	
2A	1	MOLDED CASE SWITCH, 600A	N/A	N/A	N/A	N/A	024-25563-000	024-25563-000	
	1	OPERATOR MECH	024-31878-000	024-31878-000	024-31878-000	025-35695-000	025-35695-000	025-35695-000	
	1	SHAFT, 19.69"	025-35696-000	025-35696-000	025-35696-000	025-35696-000	025-35696-000	025-35696-000	
	1	HANDLE, PISTOL	025-35697-000	025-35697-000	025-35697-000	025-35697-000	025-35697-000	025-35697-000	
3A	1	GROUND LUG	025-34085-000	025-34085-000	025-34085-000	025-34089-000	025-34089-000	025-34089-000	
5A	1	FUSEBLK, 3P, 60A	RAM	N/A	N/A	N/A	N/A	N/A	
5A	3	FUSEBLK, 1P, 200A	N/A	RAM	RAM	RAM	RAM	025-32521-000	
5A	1	FUSEBLK, 3P, 100A	N/A	RAM	N/A	N/A	N/A	N/A	
5D	1	GROUND LUG	025-34455-000	025-34455-000	025-34088-000	025-34088-000	025-34088-000	025-34089-000	
8	1	GROUND LUG	N/A	025-34089-000	025-34089-000	N/A	N/A	N/A	
8	2	GROUND LUG	025-34089-000	N/A	N/A	025-34089-000	025-34085-000	025-34085-000	

